

QUICK REFERENCE GUIDE



TOYOTA

Camry

Camry AWD

Camry Hybrid

2021

2021

CAMRY / CAMRY AWD / CAMRY HV

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Camry.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Camry operations. Every Camry owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

OVERVIEW

Engine maintenance	11
Fuel tank door release & cap	10
Hood release	10
Indicator symbols	6-7
Instrument cluster	4-5
Instrument panel	2-3
Instrument panel light control	10
Keyless entry ^{1,2}	8-9
Smart Key system ^{1,2}	9

FEATURES & OPERATIONS

Air conditioning/heating	28-29
Audio	25
Auto lock/unlock ^{1,2}	12
Automatic transmission/Hybrid transmission	12
Bird's Eye View Camera with Perimeter Scan	34
Blind Spot Monitor (BSM) and Rear Cross Traffic Alert (RCTA)	32
Bottle holders/Cup holders	19
Clock	23
Color Head-Up Display (HUD)	17
Door locks	21
Driving mode select switches	30
Dynamic Torque Control	
AWD system	31
Electric parking brake	15
EV drive mode	30
Front and Rear Parking Assist with Automated Braking (PA w/AB)	35
Garage door opener (HomeLink®) ³	30
Heated/ventilated seats	27
Heated steering wheel	27
Hybrid Synergy Drive System	13
Lights ¹ & turn signals	20
Moonroof	23
Multi-Information Display (MID) ¹	16
Panoramic glass roof with front moonroof	22
Parking brake	14
Power outlet-12V DC	26
Power windows	21
Qi Wireless charger	26
Rear Camera Detection Function (RCD)	33

FEATURES & OPERATIONS (continued)

Rear seats-Folding	18
Rear view monitor system	31
Seat adjustments-Front	18
Seats-Head restraints	19
Steering lock release	14
Steering wheel switches & telephone controls (Bluetooth®)	24
Tilt and telescopic steering wheel	14
USB charge ports	25
USB media port	25
Vehicle Stability Control (VSC)/TRAC OFF switch	31
Windshield wipers & washers	20

TOYOTA SAFETY SENSE™ 2.5+ (TSS 2.5+)

Automatic High Beams (AHB)	49-50
Dynamic Radar Cruise Control (DRCC) or Full-Speed Range DRCC	46-48
Lane Departure Alert with Steering Assist	41-43
Lane Tracing Assist (LTA) System	40
Lane Tracing Assist (LTA) with Lane Centering	44-45
Pre-Collision System with Pedestrian Detection (PCS w/PD)	37-39
Quick overview-Toyota Safety Sense™ 2.5+ (TSS 2.5+)	36
Road Sign Assist	50-51
Sensors	37

SAFETY & EMERGENCY FEATURES

Floor mat installation	58
Rear door child safety locks	53
Safety Connect®	53
Seat belts	52
Seat belts-Shoulder belt anchor	52
Spare tire & tools	54-55
Star Safety System™	57-58
Trunk-Internal release	55
Tire Pressure Monitoring (warning) System (TPMS)	56

BLUETOOTH® DEVICE PAIRING SECTION


60-62

¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the Owner's Manual for instructions and more information.


³ HomeLink® is a registered trademark of Gentex Corporation.

Instrument panel



¹ If equipped.


² For details, refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.




Instrument cluster

CAMRY / CAMRY AWD

Vehicles equipped with 4.2-in display




Vehicles equipped with 7-in display




○ Service indicators and warning lights

Vehicles equipped with 4.2-in display



Vehicles equipped with 7-in display






























○ Service indicators and warning lights

OVERVIEW

Indicator symbols

For details, refer to "Warning lights and indicators," Section 2, 2021 Owner's Manual.

	AGC (Auto Glide Control) indicator ⁶		ECO driving indicator ^{1,5}
	AIRBAG ON/OFF indicator ¹		ECO MODE indicator ⁴
	Airbag SRS warning ¹		Electric power steering warning ¹ [red/yellow]
	Anti-lock Brake System (ABS) warning ¹		EV drive mode indicator ⁶
	Automatic High Beams (AHB) indicator ¹		EV indicator ⁶
	Blind Spot Monitor (BSM) indicator ⁴		Front and Rear Parking Assist with Automated Braking OFF indicator ^{1,2,4,7}
	BSM outside rear view mirror indicators ⁴		Fuel tank door position
	Brake hold operating indicator ^{1,2,4}		Dynamic Radar Cruise Control (DRCC) or Full-Speed Range DRCC indicator/DRCC SET indicator
	Brake hold standby indicator ^{1,4}		Headlight low/high beam indicators
	Brake Override System/Drive-Start Control/Front and Rear Parking Assist with Automated Braking ^{4,7}		Lane Tracing Assist (LTA) ⁴ / Lane Departure Alert with Steering Assist indicator [white/green/yellow ³]
	Brake system warning ¹		Low fuel level warning
	Brake system warning ^{1,4} [yellow]		Low outside temperature indicator
	Constant speed cruise control indicator/Constant speed cruise control SET indicator		Low tire pressure warning ¹
	Driver's and front passenger's seat belt reminder (alarm will sound when the vehicle is on)		



Malfunction/
Check Engine indicator¹



Master warning^{1,2}



Parking brake indicator²



Pre-Collision System (PCS)
warning^{1,2}



RCD (Rear Camera Detection) OFF
indicator^{2,4}



READY indicator⁶



Rear Cross Traffic Alert (RCTA)
Indicator⁴



Rear passenger seat belt reminder



Security indicator



Slip indicator^{1,3}



Sport mode indicator⁴



Turn signal indicator



Vehicle Stability Control (VSC)
OFF indicator¹

¹ If the indicator does not turn off within a few seconds of starting the vehicle, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.

³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.

⁵ Camry / Camry AWD only.

⁶ Camry HV only.

⁷ Refer to section PKSB (Parking Support Braking function) in the Owner's Manual.

OVERVIEW


Keyless entry

UNLOCKING OPERATION



(Camry / Camry AWD)

Smart Key



Push

ONCE: Driver door
TWICE: All doors

Carry Smart
Key remote

Driver door unlock*

Grasp




NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



(Camry / Camry AWD)

Smart Key



Push

Carry Smart
Key remote

All-door lock

Touch




TRUNK LID



(Camry / Camry AWD)


Smart Key



Push and hold

Carry Smart
Key remote

Push



* Driver door unlocking function can be programmed to unlock driver door only, or all doors. In some models, grasping front passenger door handle will unlock all doors.

Please refer to the Owner's Manual for more details on how to program the doors.


NOTE: Doors may also be locked/unlocked using remote.

PANIC BUTTON

Smart Key



(Camry / Camry AWD)



HOLD




Push and hold




Smart Key system (if equipped)

START FUNCTION

Camry / Camry AWD



Camry HV



NOTE: The Smart Key must be carried to enable the start function. With the shift lever in Park and the brake pedal depressed, push the power button.

POWER (WITHOUT STARTING VEHICLE)

Without depressing the brake pedal, pressing the power button will change the operation mode in succession from:






Off - All systems OFF. Emergency flashers can be used.

Accessory – Some electrical components can be used.

On - All electrical components can be used.




Fuel tank door release & cap




NOTE: Tighten until one click is heard. If the cap is not locked or tightened enough, the Check Engine indicator may illuminate.



Hood release




Instrument panel light control




Engine maintenance


2.5 L 4-CYLINDER (A25A-FKS) ENGINE - CAMRY / CAMRY AWD



3.5 L V6 (2GR-FKS) ENGINE - CAMRY / CAMRY AWD




HYBRID MODELS



NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty Maintenance Guide.”

Automatic transmission/Hybrid transmission



* The vehicle must be on and the brake pedal depressed to shift from Park.

"S" (SEQUENTIAL) MODE

Shift the shift lever to "S" position from "D" position.

Shift lever type:

- + : Upshift (push and release)
- : Downshift (pull and release)

Paddle shifters type (if equipped):

- + : Upshift (pull and release)
- : Downshift (pull and release)

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

DEFAULT SETTING

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

CUSTOMIZED SETTING

Speed linked door locking function

- Doors lock when the vehicle speed goes above approximately 12 mph (20 km/h).

Driver's door linked door unlocking function

- Doors unlock when the driver's door is opened.

Refer to the Owner's Manual for more details.

Hybrid Synergy Drive System (Camry HV only)


The Hybrid Synergy Drive System utilizes a computer-controlled gasoline engine and electric motor to provide the most efficient combination of power for the vehicle. To conserve energy, when the brakes are applied, the braking force generates electricity which is then sent to the traction battery. In addition, the engine shuts off when the vehicle is stopped. The benefits are better fuel economy and reduced vehicle emissions.

NOTE: Fuel consumption and energy information of the Hybrid System are shown on the Multi-Information Display (MID) screen or the audio system screen.

TIPS FOR IMPROVED FUEL ECONOMY

- Ensure tire pressures are maintained at levels specified in the Owner's Manual.
- When possible, link trips to reduce engine cold starts.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the air conditioning.


STARTING YOUR VEHICLE




1. Put the shift lever in "P."
2. Depress the brake pedal, and "READY" will be displayed on the Multi-Information Display (MID).
3. Press the "POWER" button briefly and firmly.
4. The "READY" light will blink. After a few seconds, when the light remains steady and a beep sounds, you may begin driving.

Steering lock release

Without Smart Key (if equipped)




Smart Key



When starting the engine, the engine switch may seem stuck in the “LOCK” position. To free it, turn the key while turning the steering wheel slightly left and right.

A message informing the driver that the steering wheel is locked will be displayed on the Multi-Information Display. Check that the shift lever is set in P. Press the power button while turning the steering wheel left and right.


Tilt and telescopic steering wheel



Hold wheel, push lever down, set angle and length, and return lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.


Parking brake (if equipped)




Electric parking brake (if equipped)

PARKING BRAKE

Automatic mode



Manual mode



Automatic (shift lever operation)

To turn automatic mode ON, while vehicle is stopped, pull and hold switch until “EPB Shift Interlock Function Activated” displays on the Multi-Information Display (MID). While depressing brake, shifting into P position will automatically set the brake and turn the parking brake indicator and parking brake light on. To release brake, depress brake and shift out of P. The indicator and the light turn off.

To turn automatic mode OFF, push and hold parking brake switch until “EPB Shift Interlock Function Deactivated” displays on the MID.


Manual

While vehicle is stopped and brake pedal is depressed, pull to set parking brake and turn the parking brake indicator and parking brake light on. To release, press the brake pedal and push switch. The indicator and the light turn off.


Refer to the Owner's Manual for limitations and more details.

BRAKE HOLD

Camry / Camry AWD



Camry HV




The brake hold system keeps the brake applied when the shift lever is in D, S or N with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in D or S to allow smooth start off.

Refer to the Owner's Manual for limitations and more details.




FEATURES & OPERATIONS



Multi-Information Display (MID)

VEHICLES EQUIPPED WITH 4.2-in DISPLAY




Press meter control switches to change and select information in the following:

-  Drive information
-  Audio system-linked display
-  Driving assist system information

-  Warning message display
-  Settings display




VEHICLES EQUIPPED WITH 7-in DISPLAY




Dynamic Radar Cruise Control (DRCC)
or Full-Speed Range DRCC and
LDA/LTA display



* If equipped

Press meter control switches to change and select information in the following:


-  Warning message display
-  Eco-friendly driving information
-  Driving assist system information

-  Audio system-linked display
-  Vehicle information
-  Settings display


Refer to the Owner's Manual for more details.

Color Head-Up Display (HUD) (if equipped)

CAMRY / CAMRY AWD



CAMRY HV



The head-up display is linked to the meters and navigation system (if equipped) and projects a variety of information in front of the driver, such as the current vehicle speed.


Press meter control switches and select “” in the Multi-Information Display (MID) and then select “” to access Head-up display settings. And push “” to enter selection.

Refer to the Owner's Manual for more details.


FEATURES & OPERATIONS

Seat adjustments - Front


MANUAL SEAT (IF EQUIPPED)




POWER SEAT (IF EQUIPPED)



Rear seats - Folding (if equipped)




The release lever is located in the trunk.



Refer to the Owner's Manual for more details.


Seats - Head restraints




Bottle holders/Cup holders

BOTTLE HOLDERS (DOOR MOUNTED)

Front




Rear




CUP HOLDERS

Front




Rear (if equipped)



FEATURES & OPERATIONS

Lights & turn signals

HEADLIGHTS



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.


Automatic light cut off system Automatically turns lights off after 30 second delay, or lock switch on remote is pushed after all doors are locked.

Automatic High Beams (AHB) system* Automatically switches between high and low beams as appropriate to enhance vision at night.

Refer to Toyota Safety Sense™ 2.5+ (TSS 2.5+) in this guide or the Owner's Manual for more details on the Automatic High Beams feature.


* Operating conditions must be met. Refer to the Owner's Manual for details.

TURN SIGNALS



* Move lever partway and release. The signals will flash three times.


Windshield wipers & washers



*** Intermittent windshield wiper frequency adjustment** Rotate to increase/decrease wiper frequency.


Refer to the Owner's Manual for more details.

Door locks




Power windows

Driver side



Window lock switch



All window auto up/down

Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch


Deactivates all passenger windows. Driver's window remains operable.


FEATURES & OPERATIONS


Panoramic glass roof with front moonroof (if equipped, Camry / Camry AWD only)

SLIDING OPERATION

Opening and closing the electronic sunshade





Open - Slide and hold the  switch backward. The electronic sunshade will open fully automatically.*


Close - Slide and hold the  switch forward. The electronic sunshade will close fully automatically.*


* Quickly slide and release the switch in either direction to stop the electronic sunshade partway.

Opening and closing the panoramic moonroof



Open - Slide and hold the  switch backward. The panoramic moonroof and electronic sunshade will open automatically.*





Close - Slide and hold the  switch forward. The panoramic moonroof will fully close automatically.


* Quickly slide and release the switch in either direction to stop the panoramic moonroof partway.


TILTING OPERATION

Tilting the panoramic moonroof up and down



Tilt-up - Press the center of the  switch to tilt the panoramic moonroof up. When the panoramic moonroof is tilted up, the electronic sunshade will open to the half-open position.


Tilt-down - Press and hold the center of the  switch to tilt down. The panoramic moonroof can be tilted down only when it is in the tilt-up position.

Note: The panoramic moonroof can be opened from the tilt-up position. Also, lightly pressing the  switch again stops the panoramic moonroof partway.

Moonroof (if equipped)

SLIDING OPERATION


Push once to open partway.
Push again to open completely.



Recommended open position
to minimize wind noise.

TILTING OPERATION

Push once to open completely.



Lightly press either side of the moonroof switch while opening/tilting is in progress, the moonroof stops partway.

Clock

Select to change the time zone.

Select to set daylight saving
time ON/OFF/Auto¹.

Select to set automatic GPS
adjustment of clock.²

Select to set the 24 hour time
format on/off.



- 1) Push "**MENU**" button next to the screen.
- 2) Select "**Setup**" or "**General**" in the touchscreen to access the general setting screen.
- 3) Select "**Clock**."
- 4) Select desired items to be set.


Refer to the "Navigation and Multimedia System Owner's Manual" for more details.

¹ Premium Audio only

² Audio Plus/Premium Audio only

FEATURES & OPERATIONS

Steering wheel switches & telephone controls (Bluetooth®)




Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel.

Refer to the Bluetooth® device pairing in this guide or the Navigation and Multimedia System Owner's Manual for additional user instructions.

NOTE: Always use safe driving practices and follow all traffic rules.


Audio



Refer to the “Navigation and Multimedia System Owner’s Manual” or visit www.toyota.com/audio-multimedia for additional resources.


NOTE: Always use safe driving practices and follow all traffic rules.

USB charge ports



The vehicle must be in the “ACC” or “ON” position (without Smart Key) / “ACCESSORY” or “IGNITION ON” mode (with Smart Key) for use.


USB media port



Connecting a compatible device and cable into the USB media port will support charging and music playback through the audio multimedia system.



FEATURES & OPERATIONS

Power outlet-12V DC




The vehicle must be in the “ACC” or “ON” position (without Smart Key) / “ACCESSORY” or “IGNITION ON” mode (with Smart Key) for use.

Qi Wireless charger (if equipped)



When the engine is turned off, the last state (ON/OFF) of the charger is memorized.



Place device nearest the center of charging area for best results. Moving device may result in stopping or restarting the charging process.

A mobile device can be charged wirelessly on the tray. **(1)** Press the wireless charger power switch and the green operation indicator light turns on. **(2)** Place a compatible mobile device on the tray as shown in the illustration. An amber indicator illuminates while charging is in progress. When charging is complete, the indicator illuminates green. Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.


The vehicle must be in the “ACC” or “ON” position (without Smart Key) / “ACCESSORY” or “IGNITION ON” mode (with Smart Key) for use.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.


Heated/ventilated seats (if equipped)

HEATED SEAT OPERATION (IF EQUIPPED)

Heated only




Heated and Ventilated




The vehicle must be on for use.

VENTILATED SEAT OPERATION (IF EQUIPPED)



The vehicle must be on for use.

Heated steering wheel (if equipped)




The vehicle must be on for use.

FEATURES & OPERATIONS

Air conditioning/heating (Camry / Camry AWD)


AUTOMATIC AIR CONDITIONING (IF EQUIPPED)

Without “SYNC” button




* If equipped

With “SYNC” button




* If equipped

Airflow mode: In “” or “” mode, use outside air (“” indicator OFF) to reduce window fogging.



* If equipped


Air conditioning/heating (Camry HV)



* If equipped

FEATURES & OPERATIONS

Garage door opener (HomeLink®*) (if equipped)



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.

Refer to the Owner's Manual for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com/toyota>.

* HomeLink® is a registered trademark of Gentex Corporation.

Driving mode select switches (if equipped, Camry / Camry AWD only)

Normal -


Suitable for normal driving.

ECO mode -

Helps achieve lower fuel consumption during trips that involve frequent accelerating and braking.


SPORT mode -

Use when a higher level of response is desired, such as when driving in mountainous regions.



Refer to the Owner's Manual for more details.

EV drive mode (Camry HV only)



Use EV drive mode when driving short distances to reduce noise early in the morning and late at night in residential areas or to cut emissions when parking in a small garage or indoor car park.

Dynamic Torque Control AWD system (Camry AWD only)

The Dynamic Torque Control AWD system is designed to help to enhance performance and ensure reliable handling and stability.


The system will automatically switch from front-wheel drive to all-wheel drive (AWD) according to the driving conditions such as when cornering, going uphill, starting off or accelerating, and when the road surface is slippery due to snow, rain, etc.

DO NOT DRIVE THE VEHICLE OFF-ROAD.

This is not an AWD vehicle designed for off-road driving, proceed with all due caution if it becomes unavoidable to drive off-road.

Refer to the Owner's Manual for limitations and more details.

Vehicle Stability Control (VSC)/ TRAC OFF switch




The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press switch to disable the TRAC system.

To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds.

Refer to the Owner's Manual for limitations and more details.

Rear view monitor system




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press the "MENU" button and select "Display." Select "Camera" to adjust the screen contrast and brightness.

Refer to the Navigation and Multimedia System Owner's Manual for limitations and more details on this system.

FEATURES & OPERATIONS

Blind Spot Monitor (BSM) and Rear Cross Traffic Alert (RCTA) (if equipped)



* RCTA only

BLIND SPOT MONITOR (BSM)

The system is designed to use radar sensors to detect vehicles traveling in the Camry's blind spot when changing lanes. If a vehicle is detected, the driver will be alerted via the outside rear view side mirror indicators.

REAR CROSS TRAFFIC ALERT (RCTA)

While in reverse, when a vehicle approaching from the right or left rear of the Camry is detected, the outside rear view mirror indicators will flash. Also, the RCTA icon for the detected side will be displayed on the audio system screen, and the RCTA buzzer will sound.

SYSTEM ON/OFF

- (1) Press “<>” or “ ” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “ ” switches and select “ ” or “ ” and then press “ .”
The setting screen is displayed.
- (3) Press “<>” or “ ” switches and select the “On/Off” setting function and then press “ .”
- (4) Press “ ” to go back to the menu.


Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Rear Camera Detection Function (if equipped)


The rear camera detection (RCD) function is designed to detect pedestrians in the detection area behind the vehicle when the vehicle is backing up. If a pedestrian is detected, a buzzer will sound and an icon will be displayed on the audio system screen to inform the driver of the pedestrian.

DISPLAY ON AUDIO SYSTEM SCREEN

Toyota parking assist monitor







Panoramic view monitor



Pedestrian detection icon: The icon will be displayed automatically when a pedestrian is detected.


RCD OFF icon: The RCD OFF icon will illuminate when the RCD function is disabled.

SYSTEM ON/OFF

- (1) Press “<>” or “⬢” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “⬢” switches and select “**RCD**” and then press “.” The setting screen is displayed.
- (3) Press “<>” or “⬢” switches and select the “On/Off” setting function and then press “.”
- (4) Press “↩” to go back to the menu.


Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Bird's Eye View Camera with Perimeter Scan (if equipped)



Moving view


Body color setting switch



Rotation pause switch
See-through view switch

See-through view

Body color setting switch



Rotation pause switch
See-through view switch

The Bird's Eye View Camera with Perimeter Scan function assists the driver in viewing the surroundings, when operating at low speeds or parking, by combining front, side and rear cameras and displaying an overhead image on the Audio Multimedia system screen.

To view the moving view/see-through view screen, press the camera switch when the shift lever is in the "P" position. Press the camera switch again to display the previous display screen, such as the navigation screen.


Refer to the Navigation and Multimedia System Owner's Manual" for limitations and more details on this system before attempting to use it.

Front and Rear Parking Assist with Automated Braking (PA w/AB) (if equipped)


The Front and Rear Parking Assist with Automated Braking consists of the following functions that operate when driving at a low speed or backing up, such as when parking. When the system determines that the possibility of a collision with a detected object is high, a warning operates to urge the driver to take evasive action. If the system determines that the possibility of a collision with a detected object is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

FUNCTIONS


For static objects



When traveling at a low speed and the brake pedal is not depressed, or is depressed late.



When the accelerator pedal is depressed excessively.







When the vehicle moves in the unintended direction due to the wrong shift position being selected.


For rear-crossing vehicles



When reversing, a vehicle is approaching and the brake pedal is not depressed, or is depressed late.

CHANGE SETTINGS

- (1) Press “<>” or “⏏” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “⏏” switches and select “ PKSB” and then press “.
 The setting screen is displayed.

- (3) Press “<>” or “⏏” switches and select the “On/Off” setting function and then press “.
- (4) Press “⏏” to go back to the menu.

The system will continue in the last state it was in (ON or OFF) when the engine is started again.

Refer to all of the section “Parking Support Brake function” (static objects and rear-crossing vehicles) in the Owner’s Manual for limitations and more details.

Quick overview-Toyota Safety Sense™ 2.5+

Toyota Safety Sense™ 2.5+ (TSS 2.5+) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS 2.5+ is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to www.toyota.com/safety-sense.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced grille-mounted radar sensor system is designed to work with the forward-facing camera to help recognize a preceding pedestrian or bicyclist, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Tracing Assist (LTA) System

LTA contains all the features of Lane Departure Alert with Steering Assist described below and additionally is designed to help keep the vehicle in the center of a lane by assisting the driver in steering control when using Dynamic Radar Cruise Control (DRCC).



Lane Departure Alert with Steering Assist

Lane Departure Alert with Steering Assist is designed to provide notification when the system detects an unintended lane departure.

The Steering Assist function is designed to provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.

The Sway Warning function is designed to detect vehicle swaying (based on the vehicle location and steering wheel operation) and alert drivers with an audio and visual alert, urging them to take a break.



Dynamic Radar Cruise Control (DRCC) or Full-Speed Range DRCC

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. Full-Speed Range DRCC is the same as regular DRCC except the available speed range is extended down to 0 MPH.



Automatic High Beams (AHB)

AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.




Road Sign Assist (RSA)


RSA is designed to recognize specific road signs using the forward-facing camera to provide information to the driver via the display.

Sensors

TSS 2.5+ combines a forward-facing camera mounted in front of the inside rear view mirror and a grille-mounted radar mounted in the front grille. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System with Pedestrian Detection (PCS w/PD) is designed to help detect a vehicle, a bicyclist, or a pedestrian in certain situations. Using both a camera and radar, PCS w/ PD can provide an audio/visual alert to warn you of a possible collision under certain circumstances. If you don't react, the system is designed to automatically brake.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the Pre-Collision System yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle or pedestrian or bicyclist may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

PRE-COLLISION SYSTEM (CONTINUED)

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS 2.5+ package may also help to detect a pedestrian or bicyclist in front of your vehicle using the forward-facing camera and front grille-mounted radar. The forward-facing camera of PCS detects a potential pedestrian or bicyclist based on size, profile, and motion of the detected pedestrian or bicyclist. However, a pedestrian or bicyclist may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian or bicyclist, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota Owner's Manual for additional limitations and information.


CHANGING PCS ALERT TIMING



- (1) Press “<>” or “↕” switches and select “⚙️ (4.2-in display)” or “⚙️ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “↕” switches and select “🚗 PCS” and then press “OK.” The setting screen is displayed.
- (3) Press “<>” or “↕” switches and select “Warning sensitivity” and then press “OK” to select the desired setting. Each time it is pressed, the response to the PCS warning timing changes as shown above.
- (4) Press “↩” to go back to the menu.

Note: PCS is enabled each time the vehicle is turned on. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)

DISABLING PRE-COLLISION SYSTEM (PCS)



- (1) Press “<>” or “↕” switches and select “⚙️ (4.2-in display)” or “⚙️ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “↕” switches and select “🚗 PCS” and then press “OK.” The setting screen is displayed.
- (3) Press “<>” or “↕” switches and select “PCS” and then press “OK” to select the desired setting.
- (4) Press “↩” to go back to the menu.

Note: The system is enabled each time the vehicle is turned on.


Refer to the Toyota Owner's Manual for additional information on PCS operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Tracing Assist (LTA) System

TURNING THE LTA SYSTEM ON/OFF


Press and hold the LTA switch to turn the LTA system OFF.

Press the LTA switch again to turn it on.



Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset. The LTA indicator is illuminated when the LTA system is on.

LANE TRACING ASSIST SYSTEM




While driving on a road with clear white (yellow) lane lines, the LTA system warns the driver if the vehicle may deviate from the current lane or course, and also can slightly operate the steering wheel to help avoid deviation from the lane or course.

Functions included in the LTA system are Lane Departure Alert with Steering Assist, Vehicle Sway Warning and Lane Centering.

Refer to the Toyota Owner's Manual for additional information on LTA operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Departure Alert with Steering Assist

Press and hold the LTA switch to deactivate Lane Departure Alert with Steering Assist.



By detecting visible white/yellow lane markings or the road's edge at speeds above 32 mph, Lane Departure Alert with Steering Assist is designed to issue an audio/visual alert if an inadvertent lane departure is detected. If the driver does not take corrective action, the Steering Assist function is designed to provide gentle corrective steering.*


* See www.toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

LANE DEPARTURE ALERT

LTA system display

Operation display of steering wheel operation support



Lane markers/road edge

LTA indicator



The LTA indicator is illuminated when Lane Departure Alert is active. The LTA indicator and lane markers flash orange when operating.


LANE DEPARTURE ALERT (CONTINUED)



(1)



(2)

The LTA system  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

- (1) The system displays solid white lines and a white Lane Departure Alert indicator on the MID when visible lane markers or the road are detected and system is operating. Both the Lane Departure Alert indicator and a side line flash yellow to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the Lane Departure Alert indicator when lane markers or the road are not detected or the function is temporarily canceled.










Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, Lane Departure Alert may not function on the side(s) where white/yellow lines are not detectable.

ADJUSTING LANE DEPARTURE ALERT SENSITIVITY

The driver can adjust the sensitivity of the Lane Departure Alert function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Standard - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” or “” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “” switches and select “” and then press “.” The setting screen is displayed.
- (3) Press “<>” or “” switches and select “Alert sensitivity” and then press “” to select the desired setting.
- (4) Press “” to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.








Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.






SWS is a function of LTA and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning display on the MID.

DISABLING LTA SWAY WARNING SYSTEM

- (1) Press “<>” or “◇” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “◇” switches and select “” and then press “.” The setting screen is displayed.
- (3) Press “<>” or “◇” switches and select “Sway warning” and then press “” to select the desired setting.
- (4) Press “↶” to go back to the menu.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.


ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press “<>” or “◇” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “◇” switches and select “” and then press “.” The setting screen is displayed.
- (3) Press “<>” or “◇” switches and select “Sway sensitivity” and then press “” to select the desired setting.
- (4) Press “↶” to go back to the menu.

Refer to the Toyota Owner's Manual for additional information on LTA operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Tracing Assist (LTA) with Lane Centering

Press and hold the LTA switch to deactivate Lane Tracing Assist.




When Full-Speed Range Dynamic Radar Cruise Control (DRCC)* or Dynamic Radar Cruise Control is enabled and lane markers are detectable, Lane Tracing Assist (LTA) uses the lines on the road and/or preceding vehicles to help keep the vehicle centered in its lane.

** Not available on all models. See www.toyota.com/safety-sense for model applicability.*

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

LANE TRACING ASSIST w/LANE CENTERING

LTA function display









The lane centering function is linked with Full-Speed Range Dynamic Radar Cruise Control (DRCC) and provides the required assistance by operating the steering wheel to keep the vehicle in its current lane.

When dynamic radar cruise control with full-speed range is not operating, the lane centering function does not operate.



DISABLING LANE CENTERING FUNCTION

- (1) Press “<>” or “⬆” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “⬆” switches and select “” and then press “.
 The setting screen is displayed.- (3) Press “<>” or “⬆” switches and select “Lane center” and then press “.
 to select the desired setting.- (4) Press “.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

Refer to the Toyota Owner's Manual for additional information on LTA operation, settings adjustments, limitations, and precautions before attempting to use it.


Dynamic Radar Cruise Control (DRCC) or Full-Speed Range DRCC

Intended for highway use, Dynamic Radar Cruise Control (DRCC) lets you drive at a preset speed. DRCC is designed to function at speeds of 25-110 mph and uses vehicle-to-vehicle distance control, helping maintain a preset distance from the vehicle ahead of you.*

Full-Speed Range DRCC is designed to function between 0-110 mph.*

* Not available on all models. See www.toyota.com/safety-sense for model applicability.


Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.



TURNING SYSTEM ON/OFF

(1)

Radar Ready




Push once: On
Push twice: Off

Refer to page 48 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET SPEED

(2)


Increase speed/Resume



60
MPH

Decrease speed

(3)





Cancel*


Vehicle will cruise at a set speed, decelerate to maintain a selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push “” to turn DRCC system ON. The “Radar Ready” and “” indicator will come on.
- (2) Use the steering wheel controls to increase speed by pushing “+RES” or decrease the speed by pushing “-SET”. Push and hold to make a large adjustment or push each time to make fine adjustments (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments).
- (3) Push “Cancel” to cancel the speed control.

* The speed control may also be canceled by depressing the brake pedal.




To change the vehicle-to-vehicle distance

Push the “” button to cycle through the settings, which will change progressively.

This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a slower vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system may apply the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)


(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.


SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



If you are already using DRCC “”, push button again to turn the system off first, then push and hold button for at least 1.5 seconds to switch.

Note: When the vehicle is turned off, it will automatically default to DRCC.

SETTING CONSTANT SPEED (CRUISE) CONTROL




To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 46.


Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)

(1)



(2)



The Automatic High Beams (AHB) safety system is designed to help you see more clearly at night. At speeds above 25 mph, AHB can detect the headlights of oncoming vehicles and taillights of preceding vehicles, then automatically toggles between high and low beams accordingly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

ACTIVATING THE AHB SYSTEM

(1) Turn the headlight switch to the “” or “AUTO” position.

(2) Press the “” switch.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Push the lever away from you to manually turn on high beams. Press the AHB switch to turn the AHB system off.

The AHB indicator will turn off and “” or “” will turn on. To activate the system again, pull the lever its original position or press the “” switch.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY


When all of the following conditions are met, the high beams will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few street lights on the road ahead.

If any of the following conditions occur, the high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

TEMPORARILY SWITCHING TO THE LOW BEAMS



Pull the lever toward you and then return it to its original position to switch to the low beams temporarily.

The high beams are on while the lever is pulled toward you, however, after the lever is returned to its original position, the low beams remain on for a certain amount of time. Afterwards, the Automatic High Beams will be activated again.

NOTE: It is recommended to switch to the low beams when the high beams may cause problems or distress to other drivers or pedestrians nearby.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

Road Sign Assist (RSA)


Using an intelligent camera, Road Sign Assist (RSA) is designed to detect speed limit signs, stop signs, do not enter signs and yield signs, and display them on the Multi-Information Display (MID).*

* All vehicle actions must be driver-initiated and are not automated.


See www.toyota.com/safety-sense for model applicability.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

RSA DISPLAY



When the driving assist system information is selected, a maximum of 3 signs can be displayed.



When a tab other than the driving assist system information is selected, the following types of road signs will be displayed.

- Speed limit sign
- Do Not Enter sign (when notification is necessary)

SUPPORTED TYPES OF ROAD SIGNS



Speed limit



Stop








Do Not Enter



Yield

SETTING RSA



- (1) Press “<>” or “↕” switches and select “ (4.2-in display)” or “ (7-in display)” from the Multi-Information Display (MID).
- (2) Press “<>” or “↕” switches and select “ RSA” and then press “.” The setting screen is displayed.
- (3) Press “<>” or “↕” switches and select “RSA” and then press “” to select the desired setting.
- (4) Press “↩” to go back to the menu.

Note: If the vehicle was last turned off while a speed limit sign was displayed on the Multi-Information Display, the same sign displays again when the vehicle is turned back ON.

Refer to the Toyota Owner's Manual for additional information on RSA operation, settings adjustments, limitations, and precautions before attempting to use it.

SAFETY & EMERGENCY FEATURES


Seat belts



NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic Locking Retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.


To find more information about seat belts, and how to install a child restraint system, refer to the Owner's Manual.

Seat belts - Shoulder belt anchor




Rear door child safety locks

Rear door



Moving the lever downward will allow the door to be opened only from the outside.

Safety Connect®



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is staffed with live agents at the Toyota response center, which operates 24 hours per day, 7 days per week.

Services for subscribers include:

- Automatic collision notification
- Stolen vehicle locator
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance


For limitations and additional information, refer to the "Owner's Manual" or visit www.toyota.com/connected-services.

SAFETY & EMERGENCY FEATURES


Spare tire & tools

TOOL LOCATION


Camry



Camry AWD



Camry HV




* If equipped.


REMOVING THE SPARE TIRE

- (1) Remove the tool tray.


Camry / Camry HV



Camry AWD




- (2) Loosen the center fastener that secures the spare tire.



Refer to the Owner's Manual for tire changing and jack positioning procedures.

Trunk - Internal release







SAFETY & EMERGENCY FEATURES

Tire Pressure Monitoring (warning) System (TPMS)






VEHICLES EQUIPPED 4.2-in DISPLAY

VEHICLES EQUIPPED 7-in DISPLAY



The tire pressure warning system can be selected on “ (4.2-in display)” or “ (7-in display)” of the Multi-Information Display (MID).

System reset initialization

- (1) Select “Vehicle Settings” and then push “” (4.2-in display)/“” and then push and hold “” (7-in display.)
- (2) Select “TPWS” and then push “”.
- (3) Select “Set Pressure” then push and hold “” until the warning light blinks three times. Then a message will be displayed on the Multi-Information Display.

The tire pressure detected by the tire pressure warning system can be displayed on the Multi-Information Display (MID).

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

If the tire pressure indicator flashes for approximately 1 minute and then remains on, take the vehicle to your local Toyota dealer.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

SAFETY & EMERGENCY FEATURES

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).


Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION

Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of the multimedia system.


Bluetooth® Pairing for your phone

Pairing your phone is the first step in connecting with your Toyota. This pairing process is quick and easy. All you have to do is setup the phone and multimedia system to form a connection.¹




Audio / Audio Plus / Premium Audio

STEP 1 Press [MENU] on the audio system faceplate, then select "Setup" on display screen.



STEP 2 Ensure Bluetooth is turned on for your phone.

STEP 3 Select "Bluetooth," then select "Add New Device" on display screen.



STEP 4 Select "Phone Name."

STEP 5 Check the display on your phone. Does the PIN XXXX match the PIN displayed? If it does, select "Pair."

¹ Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

Bluetooth® Pairing for your phone (cont.)




STEP 6 "Connecting" displays while phone is forming the connection to the multimedia system.



STEP 7 Enable Notifications (text message). While pairing your phone, a message will be displayed:
"You may need to allow message access on your phone."

Note: You may also select "Skip" on display screen to skip enabling notifications. If skipped, proceed to **Step 8**.



STEP 8 Turn on "Show Notifications" for iPhone or "ON" for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.

NOTES

NOTES



TOYOTA

Quick Reference Guide 2021



00505QRG21CAMR1



Printed in U.S.A. 7/21
21-MKG-15903

toyota.com