

BRAKE FLUID TESTER B10








Product Structure



Α	Probe tip	В	Display screen	
С	[🔆] Press to turn off the backlight	D	[6] Select brake fluid type	
E	[▶] Press to test	ne i	[(b)] Long press to turn on / (
G	Battery cover (rear of the tester)		the tester	

Operating temperature	-10°C~60°C	Operating voltage	6V
-----------------------	------------	-------------------	----

Interface Display



Display	Indication
Δ	Water content of brake fluid warning
X	Suggested to replace
ОК	Water content of brake fluid is good
8.8%	Percentage of water content in brake fluid

Standard Mode		
DOT3	DOT4	DOT5.1

Expert Mode				
For MOTUL DOT4	For ATE DOT4	For FERODO DOT4		
For MOBIL DOT4	For BREMBO DOT4	For TRW DOT4		
For BOSCH DOT4	For CASTROL DOT4	For TOTAL DOT4		
For VALEO DOT4	For FUCHS DOT4	For TEXTAR DOT4		

Battery Installation Instructions

- Open the battery cover on the back of the device.
- Insert the batteries (4 x 1.5V AAA batteries), paying attention to the correct polarity.
- Close the battery cover securely.

Operations Instruction

- The probe should be wiped clean before each measurement.
- Press and hold the [(b)] key for more than 2s to power on the tester.
- Press [] for mode selection: standard mode and expert mode.
- Submerge the probe in the brake fluid.
- Press [>] to perform a brake fluid water content measurement.
- The interface will display the percentage of water content.
- Indicates [oκ] when the water content is between 0%-2%, [△] when the water content is between 2%-3% and [X] when it is higher than 3%.
- The instrument will automatically power off after 5 minutes of no activity.



SHENZHEN SHANGJIA TECH CO., LTD



aftersale@mrcartool.net

% +86-755-27807580

Shenhua Innovation Park, Shenzhen, China











MADE IN CHINA