



# Instruction Manual



## Learn & Go Train Set



**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

**vtech** 

**Toys that will stimulate their interest in different textures, sounds and colours**

**I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

**Birth-36 months**



**Pre-School**

**Interactive toys to develop their imagination and encourage language development**

**I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

**3-6 years**



**Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

**I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

**4-10 years**




To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Drivers® Learn & Go Train Set**.

Experience the excitement of rail travel and the fun of exploring different iconic train locations with the **VTech® Toot-Toot Drivers® Learn & Go Train Set**. It's time to chug along the tracks! As your children grow, switch modes to emphasise language development, guided pretend play, and exercising your children's imagination by creating their own stories.



# INCLUDED IN THE PACKAGE

**NOTE :** To exit Try-Me Mode, please turn the motorised train on and off again.



One **SmartPoint™** Motorised Train



Two straight tracks **A**



Three short tracks **B**




Five two-colour curved connector tracks **C**



One curved joint track **D**  
Colours may vary



Five curved joint tracks **E**



One curved connector track **F**  
Colours may vary



One train switch **G** + one train switch **H**  
Colours may vary



Two gate switches  
Colours may vary



Railway crossing track I



Railway crossing sign



Three gates



Forest track J



Forest



Bridge track K




Railing A



Railing B




Two bridge ramps



Tunnel track L



Rocks




Tunnel



Tunnel support



Tree top



Farm track M




Farm



Farmhouse



Train station



Train station track N



Sticker Sheet

## WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

## NOTE

Please save this Instruction Manual as it contains important information.

**If there are no locks inside the package, disregard this message.**

### Removing the Packaging Locks:



① Turn the packaging locks anticlockwise several times.

② Pull out the packaging locks and discard.



## WARNING:


Adult assembly required for battery installation.

Keep batteries out of reach of children.

# INSTRUCTIONS

## Battery Removal and Installation – Train

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit.
4. Install 3 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



## IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.



## RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point\* so all of its materials can be recycled.

Learn more at:



[www.vtech.co.uk/recycle](http://www.vtech.co.uk/recycle)

[www.vtech.com.au/sustainability](http://www.vtech.com.au/sustainability)

\* Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

# LABEL APPLICATION

Please stick the labels to the play set securely as indicated on the following page:



# ASSEMBLY INSTRUCTIONS


With the VTech® Toot-Toot Drivers® Learn & Go Train Set, safety comes first. To ensure your child's safety, adult assembly is required.

Assemble and attach the track components following the steps as below:


1. Attach a **gate** to the **train station track**, then attach the **train station track** to the **train station**.




2. Attach the **railway crossing sign** and **two gates** to the **railway crossing track** to complete the **railway crossing**.




3. Attach the **forest** to the **forest track**.





4. Attach the **two railings** to the sides of the **bridge track**. Attach the two **bridge ramps** to form the **bridge**. Please pay attention to the direction of the railings and bridge ramps during installation .





5. Attach the **tunnel support** and the **rocks** to the **tunnel track**. Attach the **tunnel** into the **tunnel support** and slide it onto the **tunnel track** to create the tunnel.



6. Snap the **tree top** onto the **tree trunk**. This tree button will spin the sheep. Attach the **farmhouse** to the side of the **farm**. Then, attach this farm structure to the side of the **farm track**.



7. Place the **red gate switch** on the **blue train switch track** and the **blue gate switch** on the **red train switch track**.




All pieces have now been assembled. Please select from the below configurations to create the train track that best fits your space and needs.

## Main Configuration



This is the most compact assembly using all of the pieces. It has a footprint of approximately 109.4 x 100 cm.




Begin by assembling the track pieces as shown:



Connect tracks C and H with the bridge. Once you've completed the above steps, you are ready to play!












# PRODUCT FEATURES

## 1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** (  ) position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (  ) position.







## 2. Automatic Shut-Off

To preserve battery life, when the **Motorised Train** is off the track, it will automatically power down after approximately 5 minutes without input. When the **Motorised Train** is on the track, it will continue running without entering sleep mode, until it automatically shuts off.

**Note:** This product is in Try-Me mode in the packaging. After opening the package, turn the **SmartPoint™ Motorised Train** off and on again to proceed with normal play. If the unit powers down while playing, we suggest changing the batteries.

## 3. Mode Switch

To switch the mode, slide the **Mode Switch** to the Play mode (  ) or the Imagination mode (  ) or the Learning mode (  ) position. You will hear sounds when switching to Imagination mode or a song and phrase when switching to Play or Learning Modes. Play Mode is more focused on role play responses while Learning Mode features early alphabet, first word, and vocabulary-building responses.




For your child's safety, use the Motorised Train only on the **Toot-Toot Drivers® Learn & Go Train Set**. Do not roll the train on your clothing, body or hair while the vehicle is turned on. Do not block the path of the Motorised Train with any part of your body when the vehicle is moving forward or backward. If something gets caught in the train's wheels while the motor is on, lift the train up so the base and wheels are no longer touching your child or slide the power switch to the off position to turn off the motor. Adult supervision required.



# ACTIVITIES

## Motorised Train

1. Press the **Light Up Face Button** to hear fun phrases, songs, sounds and melodies. The light will flash with the sounds.
2. Press the **Stop Button** to hear brake sounds and to stop the motor. Release the **Stop Button** to start the motor again.
3. Place the **Motorised Train** on one of the play set's six **SmartPoint™** locations to see the **Motorised Train's** lights flash and to hear fun sounds, short tunes and phrases.



# Train Tracks

1. Use the train track's different locations (Train Station, Tunnel, and Farm) to trigger the stop button and stop the train.




2. Trigger various mechanical features for fun effects or to create engaging role play opportunities.

A. Train Station Sign




B. Spinning Sheep



C. Forest



D. Railway Crossing



E. Rock Tunnel



# MELODY LIST

1. Wheels on the Bus
2. Take Me Out to the Ball Game
3. One, Two, Buckle My Shoe
4. March of the Toys
5. Gladiator's March
6. Funiculi, Funicula

## SONGS

### Song 1

Chugga choo choo, Let's go to see,  
Where the railway's taking me.

### Song 2

All aboard, we're moving.  
Do you hear the whistle blow?  
Let's discover places to go,  
We're on our way to play now.

### Song 3

I'm a Toot-Toot Drivers Train.  
All aboard for fun journeys (Toot-Toot!)  
Chugging along the long railway.  
Let's Toot-Toot and see! (Toot-Toot)

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to play with again.
5. If the unit is not working properly, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

# CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## **UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)  
Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

## **Australian Customers:**

Phone: 1800 862 155  
Website: [support.vtech.com.au](http://support.vtech.com.au)

## **NZ Customers:**

Phone: 0800 400 785  
Website: [support.vtech.com.au](http://support.vtech.com.au)

# PRODUCT WARRANTY/ CONSUMER GUARANTEES

## **UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

## **Australian Customers:**

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –  
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***www.vtech.co.uk***  
***www.vtech.com.au***

