

EASY CLICK SETUP (MACROS)

1 Enable MACRO

Press **MR** or **ML** together to set Macro.
Current LED will Blink and Controller will vibrate for 0.5sec.

1. YOU CAN USE UP TO 16 BUTTON IMPRESSIONS TO SET UP THE MACRO.

2. THE BUTTON SHOULD BE PRESSED ONLY IN THE SEQUENCE TO CREATE THE MACRO.

3 CLEAR MACRO'S

Long Press **MR** for 5sec to clear All the MACROs
Your MACRO is now cleared.

2 Disable Macro

Repeat the above step 1.

-9-

TURBO SETTINGS

1 Enter the TURBO Speed Function:

ENABLE: Press the TURBO button and press the following button LB,LT,RT,A,B,X,Y
DISABLE: Repeat above step to disable the turbo

2 Adjust TURBO Speed:

Press the TURBO button with the DPAD to increase or decrease the turbo speed

3 Clear ALL TURBO Setting:

Long press the TURBO button until gamepad vibrates.

-10-

CHANGING VIBRATION LEVELS

Press **MR** + Left Joystick Up to increase the vibration level

Once Connected

Press **MR** + Left Joystick Down to increase the vibration level

LEVELS

High Vibration

Medium Vibration

Low Vibration

No Vibration

THERE ARE 4 LEVELS TO ADJUST THE VIBRATION

-11-

ENHANCE JOYSTICK PRECISION

Enable Joystick Precision

Press **MR** + LEFT JOYSTICK

Disable Joystick Precision

Again Press **MR** + LEFT JOYSTICK

DISABLING DIAGONAL DIRECTION

Press **MR** + UP for 3 Sec.
Controller Vibrates for 0.5 Sec.

CALIBRATION AND RESET THE GAMEPAD

In the unlikely event the Gamepad is not responsive, use a pin to press the RESET button located at the back.

-12-

TROUBLESHOOTING

Why is this Gamepad not being detected by my device?

Make sure it is charged.

Make sure it is in the correct pairing mode.

Make sure it is not connected to any other device.

You may need to unpair and repair it.

Why is the Gamepad disconnecting?

The Gamepad needs to be charged or Use the provided USB Extender Cable.

Facing any trouble with the connection?

The gamepad may require you to unpair and reset it for further use.

Why is the Gamepad not working in all my games on Android or iOS?

Ensure the game has support of Gamepads.

SPECIFICATIONS

Working Platforms	: iPhone, iPad, Android, PS3, PS4, PC, Switch	Charging Time	: ~ 2 hrs
Working Mode	: PC - X-Input/D-Input, PS3/PS4, Android HID, iOS MFI	Working Distance	: 10m
Play Time	: 8-10 hrs (With Vibration) 14-16 hrs (No Vibration)	Battery	: 400mAh
Connectivity Modes	: Bluetooth, 2.4G, Wired	Product Dimensions	: 150 x 101 x 40mm
		Product Weight	: 207g

-13-

WARRANTY STATEMENT

Amkette EvoFox One S Universal Wireless Gamepad is backed by a 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discrete under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.

- The warranty does not cover the damage caused by misuse, abuse or improper storage.

- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Technical Support Line and/or send the defective product, postage pre-paid, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return postage will be paid by us.

CUSTOMER CARE SERVICE CENTER

Amkette House, C-64/4, Okhla, Phase-II, New Delhi-110020

1800-11-9090 (Toll Free)

(9:30 AM - 6:00 PM Mon-Sat)

+91 9312691448

(9:30 AM - 6:00 PM Mon-Sat)

techsupport@amkette.in

FOR HASSLE FREE SERVICE REGISTER YOUR PRODUCT AT WWW.AMKETTE.COM/REGISTER

EVOFOX

ONE S

UNIVERSAL WIRELESS GAMEPAD

QUICK START GUIDE

PRODUCT OVERVIEW

TURBO Button

SELECT Button

Charging LED

EZ CLICK Button

START Button

RB - Bumper

LB - Bumper

ABXY Action Buttons

D Pad

L Joystick

R Joystick

Led Indicator

Home Button

EZ Click Button Right

Reset Button

EZ Click Button Left

Analog Trigger-RT

Analog Trigger-LT

TYPE-C Charging Port

POWER SAVING

1. SLEEP AFTER 10 SEC OF DISCONNECTION.

2. TURNS OFF AFTER 5 MIN OF NO ACTION.

3. TO POWER OFF PRESS THE HOME BUTTON FOR 5 SEC.

-2-

IN THE BOX

Wireless Gamepad

Charging Cable

USB Extender Cable

Docs

Receiver

CHARGING THE GAMEPAD

CHARGING LED BLINKS

FULLY CHARGED STABLE LED

ENSURE GAMEPAD IS FULLY CHARGED BEFORE FIRST USE

-3-

MODES AND PLATFORMS

The One S supports the following Modes and each Mode supports the following Platforms respectively.

Bluetooth

2.4G Wireless

Wired

android STEAM

iOS SWITCH

PC PS4

STEAM SWITCH

PC PS4

STEAM SWITCH

PC PS4

BLUETOOTH MODE

PC X-INPUT

1 Press **X** + Home button

2 Open Bluetooth Settings on the device.

3 Connect to "Xbox Wireless Controller" : LED will be Stable.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

-4-

BLUETOOTH MODE

ANDROID/iOS MFI

1 Press **X** + Home button

2 Open Bluetooth Settings on the device.

3 Connect to "Xbox Wireless Controller" : LED will be Stable.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

BLUETOOTH MODE

ANDROID HID

1 Press **A** + Home

2 Open Bluetooth Settings on the device.

3 Scan the devices and pair with "EvoFox One S" : LED will be stable.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

-5-

BLUETOOTH MODE

PS3/PS4

1 Connect to PS4 or PS3 with the provided cable.

2 Press Home button.

3 White LED will be stable after successful connection.

4 Disconnect the cable for wireless mode.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

BLUETOOTH MODE

SWITCH

1 Press **Y** + Home

2 The console assigns the controller channel light color as follows:
User 1: Blue
User 2: Red
User 3: Green
User 4: Pink
User 5 and above: Purple

THE CONTROLLER IS XBOX BUTTON LAYOUT. WHEN CONNECTING TO THE N-S CONSOLE. ABXY BUTTON PRESS A TO GET OUT OF B, PRESS B TO GET OUT OF A, PRESS Y TO GET OUT OF X, AND PRESS X TO GET OUT OF Y

-6-

2.4G MODE

PC X-INPUT/SWITCH

1 Press **LB** + Home button for 2sec.

2 Purple LED will be stable after successful connection.

3 Then connect your 2.4G receiver to your device and it will connect to your PC X-input/Switch.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

D-INPUT

1 Press **Start** + **Select** to Switch into D-Input.

-7-

USB WIRED MODE

PC X-INPUT/PS3/PS4/SWITCH

1 Simply just connect your gamepad using type c cable and start to play.

2 Blue LED will be stable after successful connection.

RECONNECTING: SIMPLY PRESS THE HOME BUTTON TO POWER ON AND RECONNECT THE GAMEPAD.

D-INPUT

1 Red LED will be stable after successful connection for D-Input.

-8-