



INFLATABLE LARGE RIDE ON BOUNCERS

ASSEMBLY INSTRUCTIONS

Remove the vinyl inflatable from packaging and spread it out flat on the ground. Place the nylon body cover over the vinyl body inflatable.

- 1 Pull the tail of the vinyl inflatable through the large opening in the nylon cover.
- 2 Continue pulling the tail through the smaller hole at the opposite end. At this point, the tail should stick out of the smaller hole, and the head should protrude from the larger hole.
- 3 To confirm that assembly is correct, the small hole on the side of the nylon cover should align with the air valve on the vinyl inflatable

INCLUDED PARTS

- 1 vinyl inflatable
- 1 nylon body cover
- 1 patch kit (for repairs)

WEIGHT CAPACITY
250 LBS

INFLATION INSTRUCTIONS

Inflation can be done by mouth, hand or electric pump. In all cases be careful not to over inflate.

- 1 Locate the air valve on the body and remove black insert and cap plug. Locate the air valve on the head and remove cap plug.
- 2 Begin with body valve by inserting pump nozzle into open air value to inflate. Once inflated, remove the air pump nozzle and plug the air valve black insert and cap tightly in place.
- 3 Repeat step 2 for head valve.

* Hand & electric pumps sold separately.

USAGE INSTRUCTIONS

To ride, simply step onto the Bouncer, grab onto the handles, and have fun! The Bouncer is designed to stay upright at all times. When knocked over, it will pop back up! The Bouncer is meant for both indoor and outdoor use. Do not drag the Bouncer on the ground. Although the protective nylon cover has reinforced, double-stitched seams, dragging it along the ground may damage the cover or even the vinyl inflatable. The handles are only to be used when riding the Bouncer.



Bounce, Play, & Race!



INFLATABLE LARGE RIDE ON BOUNCERS

REPAIR INSTRUCTIONS

- One vinyl patch kit is included with your Bouncer to repair air leaks.
- Locate the source of the air leak. You can do so by spraying the Bouncer with soapy water and looking for bubbles or by submerging it in water.
- Thoroughly clean the damaged area using rubbing alcohol. To remove excess dirt, use a sponge with soapy water. Let dry for a minimum of 15 minutes.
- Completely deflate the Bouncer and lay it flat on the ground.
- Remove the paper backing and place the patch on the vinyl Bouncer. Be sure to center the patch over the hole, ensuring it extends 1 inch beyond the hole on all sides. Cut the patch to resize if necessary.
- Apply continuous pressure onto the patch. Place something flat and heavy on the patch. Let sit for 30 minutes before inflating.

CARE INSTRUCTIONS

- Spot clean with mild soap only.

LIABILITY WARNING

We make every attempt to design and manufacture our Bouncers with the highest quality and safety in mind. Each Bouncer is inspected prior to boxing and preparation for sale. However, the user assumes all risk of injury due to usage, as we cannot guarantee freedom from injury or a user's safety. By purchasing and inflating this Bouncer for use, the user assumes responsibility for their actions, which no representative from Waddle can waive or change.

WARNINGS

- * Only 1 person may ride the Bouncer at a time.
- * Hold onto the safety handles at all times.
- * Wear loose or comfortable clothing when using the Bouncer.
- * Not for use in water. The Bouncer is not designed as a flotation device and will not stay upright in water.
- * Remove jewelry or other sharp objects before use. Use in an open space free of potential collision or sharp objects that may harm the user or the inflatable.
- * Children should always use the Bouncer under adult supervision. Check the Bouncer for proper air pressure prior to use. Fluctuation in temperature may change the air pressure within.
- * Misuse of the Bouncer may lead to serious or permanent injury.
- * Do not try to jump on the Bouncer while standing up.
- * Do not attempt any form of somersault or flip on the Bouncer. Doing so may result in permanent injury or death.
- * Do not use the Bouncer to hit anyone at any time.
- * The Bouncer is designed for children ages 5 and up. Use the Bouncer on dry surfaces only, as it may be very slippery when wet and could result in injury.
- * Use the Bouncer in calm weather conditions only. Not for use on windy days as it may be carried away by the wind. Similarly, store the Bouncer inside when not in use so that it does not get blown away or potentially popped if it collides with something sharp.
- * Not for commercial use.
- * Keep away from open flames.