

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm soapy water before first use (only select accessories are dishwasher safe).



STEP 1: Place your food in the Shaq Pan.

Never fill the Pan more than two thirds full.



STEP 2: Place the Pan in the Unit Base.

Ensure that the Unit Base is placed on a flat, level surface. Add the Glass Lid if necessary.



STEP 3: Plug in the Smart Cooker.

Plug the Quick-Release Power Cord into the Smart Cooker and then the outlet.



STEP 4: Select a preset cooking mode.

Rotate the Program Dial left or right to select a cooking mode. The selected mode will light up on the Digital LED Display.



STEP 5: Press the Program Dial to confirm the cooking mode.

Follow your recipe and add more ingredients if necessary.



STEP 6: Once the cooking process is complete, serve food.

The Smart Cooker will automatically switch to Keep Warm mode with most cooking modes.