

## TROUBLESHOOTING

### Why is the Gamepad not being detected by my computer?

- Make sure the computer USB port is working. Try a different USB Port.
- Some PC's may require you to install the Software Driver - Please visit - [www.amkette.com/elitepro](http://www.amkette.com/elitepro)

### Why is the Gamepad Disconnecting?

- The Gamepad needs to be charged.

### Why is the Gamepad not working in all my games?

- Ensure that the game has support for Gamepads.
- Set the Gamepad mode to D Input and try again.

### Why is the Gamepad not vibrating?

- Not all Games have vibration or the vibration setting needs to be turned on (in the game).
- Some PC's may require you to install the Software Driver - Please visit - [www.amkette.com/elitepro](http://www.amkette.com/elitepro)

## SPECIFICATIONS

Working Platforms : Windows 7 and above	Connection Types : Wireless
Working Modes : PC – Xinput / DInput	Charging Time : ~ 2 Hours
Play Time : ~ 8hrs	Working Distance : 30 Feet
	Net weight : 210g

## WARRANTY STATEMENT

Amkette EvoFox ElitePro Wireless PC Gamepad is backed by a 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.
- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Technical Support Line and/or send the defective product, postage pre-paid, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return postage will be paid by us.

### Customer Care Service Center

Amkette House, C-64/4, Okhla, Phase-II, New Delhi-110020



1800-11-9090 (Toll Free) (9:30 AM - 6:00 PM)



+91 9312691448 (9:30 AM - 6:00 PM)



[techsupport@amkette.in](mailto:techsupport@amkette.in)

For Hassle Free Service Register Your Product at [www.amkette.com/register](http://www.amkette.com/register)




PC



**ELITEPRO**  
Wireless Gamepad

# QUICK START GUIDE

## PRODUCT OVERVIEW



### POWER ON/OFF

**Power ON**  
Press the Mode (Ⓜ) Button to start.

**Power OFF**  
1. The Gamepad enters sleep state after 1-minute disconnection.  
2. The Gamepad enters sleep state after 5-minute no action.

### CHARGING INDICATION

**Connected**  
Active LEDs will blink slowly

**Not Connected**  
All 4 LEDs will blink slowly

**FULL CHARGE** - LEDs will stop blinking

## BOX CONTENTS



Elite Pro Wireless Gamepad



USB Receiver



Charging Cable



Quick Start Guide

## USING THE GAMEPAD

### COMPATIBILITY - SUPPORTED WINDOWS VERSION

Windows 7, 8, 10

### HOW TO CONNECT

1. Connect the USB receiver in a free USB port on your PC
2. Simply press the (Ⓜ) button to turn the Gamepad ON



Elite Pro PC Gamepad




USB Receiver



Windows PC/Laptop

3. When connected, Gamepad will be in XInput mode(Default mode) and LED 2 ON.

X-Input LED Status



**Note:** For older systems you may need to install the Software Driver.

To download the Driver visit  
[www.amkette.com/elitepro](http://www.amkette.com/elitepro)

## CHANGING MODES IN WINDOWS PC


### X Input vs D Input

To change modes between X Input mode and D Input mode long press MODE (Ⓜ) Button, until the LEDs indicator change.

X- Input LED Status



D- Analog LED Status



### D Input Analog to D Input Digital

To change modes between D Input Analog and D Input Digital short press MODE (Ⓜ) Button for about 2 seconds, until the LEDs indicator change.

D-Analog LED Status



D-Digital LED Status

