


# Manual

## Laser Groove Bluetooth Speaker

SPK-BTRB




### WHAT'S IN THE BOX:

- 1 x Laser Groove Bluetooth Speaker
- 1 x Micro USB Cable
- 1 x Instruction Manual

## SPECIFICATIONS:


Features:	USB, SD Card, Bluetooth, FM, AUX, Hands Free Calls and True Wireless Stereo.
Speaker Size:	2"
Speaker Impedance:	4Ω
Speaker Power:	5W x 2
Frequency Response:	100Hz – 20KHz
Bluetooth Version:	5.0
Bluetooth Name:	SPK-BTRB
Bluetooth Range:	10m
Battery Capacity:	1200mAh
Charging Voltage:	5V/1500mA

## REAR PANEL:



1. USB Slot – Only supports MP3 files on USB drives up to 32GB, in FAT32 or exFAT file system.
2. DC 5V – Connect one end of Micro USB cable into speaker, and the other end into a sufficient USB charging source. When listening to FM radio, connect the Micro USB cable to improve reception.
3. AUX – Insert the 3.5mm AUX cable to receive audio via an AUX source device.
4. ON/OFF – Turn the speaker ON or OFF.
5. Micro SD Card Slot – Only supports MP3 files on Micro SD Cards up to 32GB, in FAT32 or exFAT file system.

## CONTROLS:



1. Volume Down / Previous Track / Previous Station – Press and hold to decrease volume or tap to skip previous track/station.
2. Play / Pause / Auto Scan – Tap to Play/Pause audio. In FM mode tap to Auto Scan radio stations. Press and hold to turn ON/OFF LED lights.
3. Volume Up / Next Track / Next Station – Press and hold to increase volume or tap to skip next track/station.
4. M – Tap to switch between sources FM, Micro SD, USB, AUX and Bluetooth. Please note Micro SD, USB and AUX sources will only appear if connected.
5. Hands Free – Tap during incoming call to answer.

## **TROUBLESHOOTING:**

### **No Power:**

- Check battery level and charge if required.
- Try turning on speaker while connected to power source.
- Try charging with USB Wall Adapter instead of a laptop/computer.

### **Radio not clear:**

- Change speaker location.
- Connect a Micro USB cable into the DC 5V port to improve FM reception as this also doubles as an aerial.
- Isolate speaker from other devices as this may be caused by interference.

### **USB or Micro SD Card not recognised or files not playing:**

- Make sure the USB or Micro SD Card is 32gb or less.
- Check USB or Micro SD Card has been formatted to the FAT32 or exFAT file system. If not please format on a Windows based computer.
- Make sure to only use MP3 music files copied to the USB or Micro SD Card.

# WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage. **Please retain your receipt as proof of purchase**

## How to make a product warranty claim:

1. Find your receipt with date of purchase. If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
2. Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
3. If your original place of purchase cannot be contacted, please contact Laser with a description of the fault. To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
  - Phone: (02) 9870 3355
  - Email: [support@laserco.com.au](mailto:support@laserco.com.au)
  - Online: [www.laserco.net/support/warranty](http://www.laserco.net/support/warranty) and follow the website instructions
  - Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia
4. Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you without the need to return the product.
5. If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment. If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
6. Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more helpful guides visit us at



LASER  
[www.youtube.com/LasercoAu](http://www.youtube.com/LasercoAu)



SCAN ME