

AnyLink NeuroQ Edge Gateway Power-Up Guide

Step 1: Power on the AnyLink box, insert the AnyLink driver U disk into the USB port

Step 2: Connect the computer to the WiFi hotspot SSID: AnyLinkIoT, password: Welcome!

Step 3: Open the URL <http://192.168.101.204> in the browser, enter the username/password (default: admin/admin)

Step 4: Click the menu Advanced->Network configure to configure the network to connect to the AnyLink cloud server. If the connection is normal, the "Cloud Connection" status in the upper right corner will display "Connected" with a blue circular icon.

Step 5. Log in to the AnyLink cloud server and register your device.

The screenshot displays the AnyLink NeuroQ web interface. The top header includes the 'ANYLINK' logo, 'NeuroQ' model name, and user information 'admin Log Off'. The firmware version is 'NeuroQ-2.3.0' and the language is set to 'English'. The status bar shows 'Good' for the signal and 'Cloud Connection: Connected' with a blue icon. The left sidebar contains a menu with 'Gateway Status', 'Network Config' (highlighted), 'Agent Config', 'Modbus Publish', 'Time Config', 'Modify Password', 'Restart', and 'Factory Default'. The main content area is titled 'WAN Mode' and 'Network Configuration'. It features radio buttons for 'Ethernet', 'wifi' (selected), and '4G'. A red warning message states: '*You must restart the gateway after you switch the mode'. Below this, the 'Hostname' is set to 'id2856'. The 'WAN IP Settings' are configured with 'Static IP' selected and 'DHCP' as an option. 'Save' and 'Reset' buttons are present. The 'Wi-Fi' section shows 'Wi-Fi status: On', 'Wi-Fi network: OurFamily_5G' (selected from a dropdown), 'IP: 192.168.110.21', and 'Signal strength: Good'. At the bottom, there are buttons for 'Turn On', 'Turn Off', 'Refresh', and 'Configure'. A right sidebar contains a 'Help' section with the text: 'Configure the IP address, subnet mask, and gateway address.'

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.