

THE SHARPER IMAGE®

Automatic Eyeglass Cleaner

SI632 Instructions



Read and save these instructions.

Dear Sharper Image Customer,

Thank you for your purchase of a Sharper Image product. We appreciate your business very much.

This item was created by Sharper Image Design, our company's own product development group. Please accept my personal assurance of your complete satisfaction with this product's quality and performance. We offer generous return privileges and excellent warranties on all our products.

For more than 25 years, The Sharper Image has shared the fun of discovering innovative products that make life better and more enjoyable. We've been in business a long time because we are an exciting place to shop and — just as importantly — we strive to deliver great customer service that exceeds your expectations.

Enjoy your purchase!

Respectfully,

A handwritten signature in cursive script that reads "Richard".

Richard Thalheimer

Founder, Chairman and Chief Executive Officer

*Call 1-800-344-4444 for 24-7 ordering and customer service,
or go to **www.sharperimage.com**, our complete online store.*


Table of Contents

General Description	4
Battery Requirements	5
Battery Safety	6
Cleaning and Conditioning Concentrate	7
Attaching Glasses.....	8
Operation	10
Warranty	12

General Description

The Automatic Eyeglass Cleaner and the specially formulated concentrate work in conjunction to loosen grime and to condition your glasses.


The complete cleaning and drying cycle requires less then 60 seconds.



Battery Requirements

1. The battery compartment is located on the bottom of the Base. To remove the battery cover, press the tab in the direction indicated on the cover door.
2. Install four new AA alkaline batteries ensuring proper +/- polarities are observed.
3. Replace battery cover.

Note: Battery fit will be tight when the unit is new. Press batteries firmly into place.



Battery Safety

- Batteries may leak or explode if recharged, inserted improperly, inserted in the wrong direction, disposed of in a fire or mixed with different battery types.
- Only replace with fresh, new batteries. It is important batteries are inserted in the correct orientation. (See the diagram inside the battery compartment.) Batteries positioned incorrectly may leak.

Cleaning and Conditioning Concentrate


To raise the Cleaning Tank Cover, press **OPEN**.

Note: The Cleaning Tank can be removed from the Base.

Shake the bottle of concentrate each time before opening. Pour two capfuls of the concentrate into the Cleaning Tank. Add water up to the fill-line indicated inside the tank.

Replace the mixture every two weeks, or as needed, to maintain clean, fog-resistant lenses.

For additional information, refer to the concentrate bottle label. If the Cleaning Tank was removed, return it to the Base.



Cleaning and Conditioning Concentrate

Replacement Concentrate is available from The Sharper Image catalog, stores and Website.

Call toll free at 1-800-344-4444 or go to www.sharperimage.com and order item number SI932BLU.

Attaching Glasses



1. To raise the Tank Cover, press **OPEN**.
2. Grasp the **CLIP** by one of the tabs and pull it from the **CLIP DOCK**. Clip is held in place by a magnet. To remove it from the dock, pull or twist it.
3. Pinch the **CLIP** open and slip the bridge of the glasses into the clip grips.

Note: Glasses should be facing the same direction as the square-shaped form of the Clip.

4. Return the **EYEGLASS CLIP** and glasses to the **CLIP DOCK**. The magnet holds the clip and glasses in the proper position for cleaning. Be careful not to pinch the Clip open.

To close and latch the Tank Cover, press the center of the Cover.

Attaching Glasses



Operation


Solution that may have splashed into the unit could cause the product to operate incorrectly. Normal operation resumes after the unit has had an opportunity to dry.

- To start, press **ON/OFF**.
- The glasses are agitated in the solution for approximately 40 seconds. The vibration continues as the glasses are lifted out of the solution, reducing residual solution on the lenses.

After the cycle stops:

Grasp the **CLIP** by one of the tabs and pull it from the **CLIP DOCK**.

Remove the glasses and use the polishing cloth to wipe the lenses.



Do not soak glasses for an extended period of time.

Do not use on frames with delicate or unstable finishes.

One-Year Warranty

What Is Covered

This warranty covers any defects in materials or workmanship, with the exceptions stated below.

How Long Coverage Lasts

This warranty runs for one year from the date of original purchase.

What Is Not Covered

This warranty does not cover damage caused by misuse or use other than as intended and described in the product instruction manual, or loss or damage to batteries or removable parts.

What The Sharper Image Will Do

The Sharper Image will repair any defects in materials or workmanship. In the event repair is not possible, The Sharper Image will either replace this product with one of similar features and price, or refund the full purchase price of the product, whichever you prefer.

How to Obtain Service

Return the product and receipt, along with a brief explanation of the problem, to:

**T.S.I. - Returns Department
2901-A West 60th Street
Little Rock, AR 72209**

If you have questions please feel free to contact our customer service representatives at 1-800-344-5555 or by email at care@sharperimage.com.

This warranty gives you specific legal rights, and you may have other legal rights that vary from state to state.

Copyright 2003

Sharper Image Corporation
650 Davis St., San Francisco, CA 94111
(415) 445-6000

Shop online: **www.sharperimage.com**

Due to continuing improvements, actual product may differ slightly from the product described herein.

V2 09/03