



SMART
Make Life Better



English	01-10
Spanish	11-20
German	21-30
French	31-40
Italian	41-50



STEP COUNT



ALARM CLOCK



CALORIES




MESSAGE

BW1847



How To Adjust The Size of LIGE Watch Strap Band?



If you find that the steel belt is too short for your needs, we are pleased to offer free steel belt accessories that can be used to extend the strap. These accessories will arrive within 1-3 days.

If you have any additional questions or concerns, please feel free to contact us via email at service2023@126.com. We are committed to providing exceptional service and support to our valued customers, and we are always happy to assist in any way we can.



WEEE-Reg-Nr.
DE81400428

RoHS



| Charging and active

A: Connect the BW1847 charging cable to a 5V-1A adapter and plug it in. Charging the device for 2-3 hours.

B: Align the magnetic suction tube with the metal plate on the bottom of the device's outer shell. The magnet will automatically attach to the positive and negative poles and charge the device. Ensure that the charging contacts are clean and free from dirt and debris.

NOTE: If the device is not used for a long time, the battery may enter a 0 voltage protection state. Charge the device for at least 15 minutes to accumulate enough charge to start the watch at a sufficient level. It is recommended to charge the device once a month. Keep the device fully charged and power off when not in use.

APP download

- ① Search “FitCloudPro” in the APP store
- ② Scan QR code to download.



Long press 5 seconds
turn on/off, Short press
back, Menu

Close Screen

How to customize your watch face?

Long-press the current watch face to enter the watch face settings. Smart watch comes with a variety of pre-installed watch faces and also allows you to download additional watch faces from the watch face app market.

Limitations of Customization:

You can only save one custom watch face at a time. If you choose to download another watch face or customize a new watch face, the previously saved watch face will be replaced. This means that you will lose the previous customization and it cannot be recovered.



use the touch screen





Please Turn On The Bluetooth of Mobile Phone Frist.

Step 1: Open “FitCloudPro” APP--“OK, Allow”--“Device”--“Add peripheral Now”--“Search Now”--Find **K-57**.



Step 2. Connect the Bluetooth Call function



Note: Only after this connection can you play music and answer calls

a .Swipe down on the standby screen of the watch, as shown in the lower left image . Tap the "Audio Bluetooth Call" icon to enter to the "Audio Bluetooth settings " screen, as shown in the image below right .



Turn on the call audio and media audio switches


b . If you don't want your watch to play audio when you receive calls, you can turn off this function . This is helpful if you're in a noisy environment or want to maintain personal privacy . Simply disable the function manually. (This switch only turns off Bluetooth call and Bluetooth play)

****Every time the watch is turned off/ restarted or returned to the factory settings, the call function will be turned off by default .

c . If the wristband is too far from your phone for over 2 minutes, it will automatically disconnect to save battery life. To reconnect, you may need to manually connect via Bluetooth .

d . To switch back to the watch when answering or making a call on your mobile phone, simply manually select the bracelet on your phone, as shown in the picture below .

Switch back to K-57 on the bracelet



Why is the weather forecast inaccurate?

After connecting your phone and watch via Bluetooth, the weather forecast may not be accurate. You need to open the weather reports button in the "FitCloudPro" to get the accurate local weather forecast.

| Why the watch can't receive the message notification?

Please make sure that the mobile phone Bluetooth is turned on, the FitCloudPro APP is running, and the bracelet is always connecting to the mobile phone Bluetooth!

Note: Smart watch won't push messages when your phone is being used, unlocked, or when software such as WhatsApp, SMS, or Facebook is logged in on your computer. This is to save power and avoid interruptions.

To ensure message notifications are received on your smartwatch, make sure to turn on message push in the FitCloudPro settings and ensure that message notifications are visible on the notification bar of your mobile phone. Note that unused apps on Android phones may be automatically cleaned up in the background, which can cause your watch to disconnect and stop receiving notifications.

XIAOMI

Setting-apps-permissions-Autostart-open the FitCloudPro

HUAWEI

Setting-apps&services-app launch-open the FitCloudPro

SAMSUNG

"Smart Manager "- find the "Auto-Run Application" option, --enter the "Auto-Start Application" setting interface - open the auto-start setting program.



NOTE:

1. If the exercise, sleep and heart rate data are not synchronized to the APP, please try to disconnect Bluetooth and reconnect.
2. The watch should be unbound from the current account before binding another account;
3. If watch doesn't work or has a bug, please try to reset the watch or reinstall the APP.

| The watches have various sensors and algorithms to monitor users' physiological indicators :

1. These indicators include heart rate, blood pressure, blood oxygen, sleep, calories, and steps.
2. The functions are simulated by AI software to provide users with information about their health status.
3. It is recommended that users consult a doctor for personalized advice if we have any health problems or are starting a new exercise program.
4. The data from smartwatches should only be considered as a reference and not be used to replace professional medical advice or diagnosis.