

SALTER®

SINCE 1760

Pull Chopper

Instruction Manual

Please retain instructions for future reference.

Before First Use

Hand-wash thoroughly.

Using the Pull Chopper

STEP 1: Remove the lid from the bowl.

STEP 2: Add the chosen ingredients into the bowl. For best results, it is recommended to only fill the bowl by $\frac{1}{4}$.

STEP 3: Replace the lid and make sure it is secured into position.

STEP 4: Place the chopper onto a flat, stable surface. Holding the chopper securely, gently pull the easy-grip handle and pull cord out to its full length, and then slowly release it back in towards the bowl.

STEP 5: Repeat until all of the ingredients are chopped as required.

Cleaning the Pull Chopper

This chopper is not dishwasher safe.

Hand-wash in warm, soapy water using a mild detergent and soft cloth. Rinse and dry thoroughly.

Using extreme caution, clean the stainless steel blade attachment with a soft brush. Rinse and dry carefully.

Storage

Do not store wet; store in a clean, dry place.

Store the stainless steel blade attachment carefully and safely. To prevent injury or damage, it is recommended to always store it in the bowl.

Warning: Suitable for small fruit and vegetables only, i.e. garlic, chilli, spring onion.

Large fruit and vegetables, i.e. apple or carrot, must be cut into small chunks before using with the chopper. Sharp blades; handle with care.

Exercise caution when attaching, removing, cleaning or storing the stainless steel blade attachment.



Distributed by:
UP Global Sourcing UK Ltd.,
UK. Manchester OL9 0DD.
Germany. 51149 Köln.

Made in China.

©Salter trademark. All rights reserved.

CD150922/MD000000/V1