



Nintendo Switch OLED Model Screen Replacement

Use this guide to replace the screen in your...

Written By: Alex Diaz-Kokaisl



INTRODUCTION

Use this guide to replace the screen in your Nintendo Switch OLED.

Unlike the original model's plastic cover and LCD backing, the Switch OLED's screen is a glass cover that's fused to an OLED display.

This means there's a significant chance that you may break the unreinforced and fragile display panel during this procedure. Be sure to apply plenty of heat and be extremely careful during the prying stage.

For your safety, discharge the battery below 25% before disassembling your Switch. This reduces the risk of fire if the battery is accidentally damaged during the repair. If your battery is swollen, [take appropriate precautions](#).

The Switch OLED uses JIS screws, but you can use a Phillips screwdriver in a pinch. Be very careful not to strip the screws. iFixit's Phillips bits are designed to be cross-compatible with JIS-style screws.

Note: When you remove the shield plate, you'll need to replace the thermal compound between the plate and the heatsink. Since normal thermal paste isn't designed to bridge large gaps, the closest replacement is K5 Pro viscous thermal paste.

You'll need replacement adhesive in order to complete this repair.



TOOLS:

[Phillips #00 Screwdriver](#) (1)
[Tri-point Y00 Screwdriver](#) (1)
[JIS #000 Screwdriver](#) (1)
[Spudger](#) (1)
[K5-PRO Viscous Thermal Paste](#) (1)
[ESD Safe Blunt Nose Tweezers](#) (1)
[Tweezers](#) (1)
[Isopropyl Alcohol \(90% or Greater\)](#) (1)
[Coffee Filters or a lint-free cloth](#) (1)
[iFixit Opening Picks \(Set of 6\)](#) (1)
[iOpener](#) (1)
[Suction Handle](#) (1)



PARTS:

[Nintendo Switch OLED Screen](#) (1)
[Tesa 61395 Tape](#) (1)

Step 1 — Release the Joy Con controller locking tabs



ⓘ Before you begin this repair, make sure the device is completely powered off.

- Press and hold down the small round button on the back of the Joy Con controller.
- While you hold down the button, slide the controller upward.

Step 2 — Remove the Joy Con controllers



- Continue sliding the Joy Con upward until it's completely removed from the console.
- ⓘ Repeat this same process for the other Joy Con.

Step 3 — Remove the top screw



- Use a Phillips driver, or a JIS driver, to remove the 2 mm-long screw securing the top of the rear case to the frame.
- ⓘ To prevent these tight screws from [stripping](#), apply firm downward force, work slowly, and try another JIS or Phillips driver if the screws won't come out.

Step 4 — Remove the bottom screws



- Use a Phillips driver to remove the two 2 mm-long screws securing the bottom of the rear case to the frame.

Step 5 — Remove the right screw



- Use a Phillips driver to remove the 3.8 mm screw securing the right Joy-Con sensor rail to the rear case.
 - ① To prevent these tight screws from [stripping](#), apply firm downward force, work slowly and try another JIS 000 or PH 000 driver if the screws won't come out.

Step 6 — Remove the left screw



- Use a Phillips driver to remove the 3.8 mm screw securing the left Joy-Con sensor rail to the rear case.

Step 7 — Open the kickstand



- Use your finger to flip up the kickstand on the back of the device.
- ❗ If there's a microSD card in the microSD card slot, remove it now before you continue to the next step.

Step 8 — Remove the back-side screws




- Use a Y00 screwdriver to remove the two 4.3 mm screws securing the rear case to the frame.

Step 9 — Remove the rear case




- Lift the rear case up from the top of the device and remove it.
 - ① If you're having trouble removing the case, use an opening pick to pry up the plastic clips.

Step 10 — Remove the shield plate's tape



- Use the flat end of a spudger to separate a corner of the tape from the shield plate.

Step 11




- Use [tweezers](#), or your fingers, to peel back and remove the tape.
- ☑ Store the tape in a clean space for reinstallation.

Step 12 — Disconnect the primary Wi-Fi antenna




- Use tweezers, or your fingers, to pull up and disconnect the primary Wi-Fi antenna's coaxial cable.
- ☑ During reassembly, these can be tricky to reconnect. One at a time, hold each connector in place over its socket and press down with the flat end of a spudger. The connector should snap into place.

Step 13 — Reroute the primary antenna's coaxial cable




- Use tweezers, or your fingers, to reroute the primary antenna's coaxial cable out of its slots in the shield plate.

Step 14 — Unfasten the primary Wi-Fi antenna




- Use a Phillips driver to remove the two 4.4 mm screws securing the primary Wi-Fi antenna to the shield plate.

Step 15 — Remove the primary Wi-Fi antenna



- Insert an opening pick between the primary Wi-Fi antenna and the shield plate.
- Pry up with the pick to separate the primary Wi-Fi antenna from the shield plate.

Step 16




- Remove the primary Wi-Fi antenna.

Step 17 — Disconnect the secondary Wi-Fi antenna




- Use tweezers, or your fingers, to pull up and disconnect the secondary Wi-Fi antenna's coaxial cable.

Step 18 — Reroute the secondary Wi-Fi antenna's coaxial cable




- Use the point of a spudger to reroute the secondary Wi-Fi antenna's coaxial cable from its slot in the frame.

Step 19 — Unfasten the secondary Wi-Fi antenna



- Use a Phillips driver to remove the 4.4 mm screw securing the secondary Wi-Fi antenna to the shield plate.


Step 20 — Remove the secondary Wi-Fi antenna



- Insert an opening pick between the secondary Wi-Fi antenna and the shield plate.
- Pry up with the pick to separate the secondary Wi-Fi antenna from the shield plate.


⚠ Don't attempt to completely remove the antenna yet, as its coaxial cable is still routed through the frame.

Step 21




- Use the point of a spudger to reroute the secondary Wi-Fi antenna's coaxial cable out of its slot in the frame.
- Remove the secondary Wi-Fi antenna.

Step 22 — Unfasten the shield plate



- Use a Phillips driver to remove the six 4.4 mm screws securing the shield plate to the frame.

Step 23




- Use your fingers to lift the top of the shield plate up and away from the frame.
 - ① You may feel a bit of resistance. This is normal, since the shield plate is slightly bonded to the heat sink with thermal paste.
- Remove the shield plate.
- ★ A thick pink thermal compound bridges the gap between the shield plate and the copper heat sink underneath. Whenever the shield plate is removed, refer to our [thermal paste guide](#) to remove the old thermal compound and replace it with an appropriate compound, such as [K5 Pro](#), during reassembly.

Step 24 — Disconnect the battery




- Use the point of a spudger to pry up and disconnect the battery.

Step 25 — Remove the tape




- Use [tweezers](#), or your fingers, to remove the piece of tape obscuring the daughterboard's screw.

Step 26 — Unfasten the daughterboard




- Use a Phillips driver to remove the 4 mm screw securing the daughterboard to the frame.

Step 27 — Remove the daughterboard




- ① The bottom of the daughterboard is connected to the motherboard via a [press connector](#).
- Insert a spudger between the edge of the daughterboard and the motherboard.
 - Pry up with the spudger to disconnect the press connector and separate the daughterboard from the frame.
 - Remove the daughterboard.
- ★ To re-attach [press connectors](#) like this one, carefully align and press down on one side until it clicks into place, then repeat on the other side. Do not press down on the middle. If the connector is misaligned, the pins can bend, causing permanent damage.

Step 28 — Disconnect the display's ZIF connector



- Use an opening tool, spudger, or your fingernail to flip up the hinged locking flap on the display's ZIF connector.

Step 29



- Use a pair of [tweezers](#) to pull the display cable straight out of its connector on the motherboard.

Step 30 — Heat the right edge




- Apply a [heated iOpener](#) to the right edge of the screen for 90 seconds to loosen the adhesive underneath.

Step 31 — Insert an opening pick



- Once the screen is warm to touch, apply a suction handle to the bottom edge of the screen and as close to the edge as possible.
- ① If your screen is badly cracked, covering it with a layer of clear packing tape may allow the suction cup to adhere. Alternatively, very strong tape may be used instead of the suction handle. If all else fails, you can superglue the suction cup to the screen.
- Lift the screen with the suction handle to create a small gap between the screen and the frame.
- Insert an opening pick into the gap between the frame and the screen.

Step 32 — Separate the right edge adhesive




- Slide the pick along the right edge of the screen to separate the adhesive.
- Leave the opening pick in place to prevent the adhesive from resealing.

Step 33 — Heat the top edge



- Apply a heated iOpener to the top edge of the device for 90 seconds to loosen the adhesive underneath.

Step 34 — Separate the top-right corner adhesive



- Insert a new opening pick into the gap you created.
- Rotate the opening pick around the top-right corner of the device.
- Leave the opening pick in place to prevent the adhesive from resealing.

Step 35 — Separate the top edge adhesive



- Insert a new opening pick into the gap you created.
- Slide the new pick along the right edge of the device towards the top-left corner.
- Repeat the heating and slicing process on the remaining edges to separate the adhesive.

Step 36 — Remove the screen



- Lift the screen off the device, threading the display cable through the frame as you do.

⚠ Take care not to snag any of the ribbon cables on the frame as you remove the screen.

- ☑ You can reuse the screen adhesive if it is still sticky. Otherwise, replace the adhesive with double-sided tape such as [Tesa tape](#).
- ☑ During reassembly, make sure to thread the display cable through the frame before securing the screen adhesive.

To reassemble your device, follow these instructions in reverse order.

Compare your new replacement part to the original part—you may need to transfer remaining components or remove adhesive backings from the new part before you install it.

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Nintendo Switch OLED Answers community](#) for help.