






01 Packing List Thank you for choosing our product! We sincerely hope that wiarPOS will enable smart payments and enhance the convenience of your daily business. Before powering up the device, please check the terminal and accessories as follows:  1 Q3 min 2 USB Cable 3 5V 2A Adaptor Please contact your product provider if anything is missing.	02 Front View  1 PIN on Glass / Contactless on Glass 2 Camera 3 SIM Card Slot + TF/SIM Card Slot	03 Left / Right View  1 Power key 2 Wrist Strap Hole	  www.wizarpos.com										
04 Top / Bottom View  1 IC Card Reader 2 Microphone 3 USB Type-C 4 Speakers	05 Back View 	06 Environment and Trouble Shooting Environment Operating temperature -10°C-50°C (+14°F to 122°F) Operating humidity 5%-95% No condensation Storage temperature -20°C-70°C (-4°F to 158°F) <table><tr><th>Trouble</th><th>Trouble shooting</th></tr><tr><td>Cannot connect the mobile network</td><td> ◆ Check whether the function of “data” is open. ◆ Check whether the APN is correct. ◆ Check whether the data service of SIM is activated. </td></tr><tr><td>Display unstable</td><td> ◆ The display may be interfered by instability voltage when charging, please reconnect the plug. </td></tr><tr><td>No response</td><td> ◆ Restart the APP or operation system. </td></tr><tr><td>Operation very slow</td><td> ◆ Please exit APPs which are not necessary. </td></tr></table>	Trouble	Trouble shooting	Cannot connect the mobile network	◆ Check whether the function of “data” is open. ◆ Check whether the APN is correct. ◆ Check whether the data service of SIM is activated.	Display unstable	◆ The display may be interfered by instability voltage when charging, please reconnect the plug.	No response	◆ Restart the APP or operation system.	Operation very slow	◆ Please exit APPs which are not necessary.	Thank you for choosing WizarPOS ! Intelligent + Security 
Trouble	Trouble shooting												
Cannot connect the mobile network	◆ Check whether the function of “data” is open. ◆ Check whether the APN is correct. ◆ Check whether the data service of SIM is activated.												
Display unstable	◆ The display may be interfered by instability voltage when charging, please reconnect the plug.												
No response	◆ Restart the APP or operation system.												
Operation very slow	◆ Please exit APPs which are not necessary.												

To verify the functionality of the equipment, utilize the terminal's self-check capabilities. Click Settings > Self-check and choose the functionality or parts that you want to test.

Chip Card Transactions: Insert the card with the chip facing up (down) fully into the chip card slot, and remove it after the reading is completed.

www.wizarpos.com

The device can be used in portable exposure condition without restriction.

9. In case of abnormal odors, overheating, or smoke, immediately disconnect the power supply.
10. Do not place the battery in fire, disassemble it, drop it, or apply excessive pressure. If the battery is damaged, immediately discontinue use and replace it with a new one. The battery charging time should not exceed 24 hours.
If the battery is not used for an extended period, charge it every six months.
For optimal performance, replace the battery after two years of continuous use.
11. The disposal of batteries, equipment, and accessories must comply with local regulations. These items cannot be discarded as household waste. Improper disposal of batteries may lead to hazardous situations such as explosions.

For more information, please log on to the company's official website
<http://www.wizarpos.com>