


## Quickstart Guide for Smart Micro Egg

-Micro Smart Egg is a smart companion designed to be used on Micro Mini and Micro Maxi scooters. The Smart Egg can also be mounted on other Micro Scooter T-bars.

### Know the Smart Micro Egg



A - LED indicator, B - Dust cover, C - Charging port, D - power cable

### Getting started

**Step 1.** Download the **Smart Micro Egg** App in the App Store or Google Play to your smart device (Phone, Tablet, TV)

(Illustration 2: [App download info, name and link and QR code](#))

(illustration 2a: [Chinese store and info for Chinese manual only](#)).



**Step 2.** Activate the egg:

- 1) Open the dust cover (B) to find the charging port (C), connect the device to a safe power source (5V = 1A) using the provided power cable (D).
- 2) Shake it or gently knock it against hard surface for 5 seconds, when the LED indicator blinks in blue, your Smart Egg is activated. See Fig. 2

**Step 3.** Unplug the cable, put the dust cover back in place. Strap the device to your Mini or Maxi scooter using the silicon belt provided. See Fig 3

**Step 4.** Open the **Smart Micro Egg APP**, follow the instruction to start your ride! (more info see below instructions) Reminder: please keep the scooter straight for calibration before starting any ride.

For installation instruction video, please visit our YouTube channel  
[www.Youtube.com/xxxxxxx](http://www.Youtube.com/xxxxxxx)

### Smart Micro Egg – Hardware

**LED indicator:**

No Light – The device is not activated, please go back to “Getting started”

Red Light – Battery is low, please charge.

Slow blinking blue light – Smart Micro Egg is activated and in idle mode.

Frequent blinking blue light – Smart Micro Egg is disconnected but is actively looking for connection.

Constant blue light – Smart Micro Egg is connected to your smart device.

**Battery Charging.**

Connect the device to a 5V = 1A USB power adaptor, using the provided charging cable.

DC 3.5 mm

The LED indicator turns red while charging, and turns off when fully charged.

Recharge time: 2 hours

**Bluetooth Set up info** (only by factory):

- The operating frequency bands of this device are: 2.400 - 2.4835 GHz ISM band.
- The maximum output power of this device is: +4dBm.
- Recommended range: 5 meters.

## Smart Micro Egg – App

Start with registering an account. Note that you need to be over 16 or have a guardian present to create an account for the first time.

From the account, you can create profiles for each Micro Mini or Micro Maxi that is to be used within the account.

- Choose the scooter you ride and your color of choice.
- Add a nickname, choose gender and your basic profile design (only nickname is mandatory)
- Follow the instructions in the app to connect the smart egg. If this doesn't work, see below section for more help.
  - Make sure your Smart Micro Egg is activated (see Getting Started and LED indicator)
  - Turn on Bluetooth on your smart device (Phone, Tablet, TV)
  - Shake the Smart Micro Egg while your smart device is searching for Bluetooth devices to make sure it's awake and discoverable.
  - If there are more than one Smart Micro Egg present, the APP automatically recognizes the egg which it was connected to.
  - If the Egg isn't visible from the beginning, please go under "settings" and press on "connect".
- Congratulations! It's now time to have some fun! Note that you can always go back to create additional profiles or choose to enter the app in parent mode.

### Things to do in the app as a child:

Open the map and press "START" to see how fast, far and long you have driven. You can also see hot spots where you have spent at least five minutes as well as statistics over time. Press "STOP" if you want the statistics to update. (we recommend never to use the map function while driving)

To open up the "BEAT THE CLOCK" and "RACE" modes you first need to pass your driving test.

- Open "TUTORIAL" and learn how to operate the app and smart egg. Follow the instructions and try to collect 60 coins to pass the test. You will learn to control the steering, avoid hitting people and objects and stop to wait for green lights at street crossings. If you hit an object you lose three coins and if you hit a person you lose one heart.

Did you get the license? Congratulations! Time for more fun activities.

- In "BEAT THE CLOCK" you simply want to get as far as possible without losing your lives. If you hit an object you lose 3 seconds and if you hit a person you lose one of your hearts. Be aware, the further you get the faster you will drive!
- In "RACE" you can choose "OFFLINE RACE" to race against the computer or "QUICK CHALLENGE" to race against friends. To race against friends, first you need to add friends through your profile page.

There are two currencies in the app.

- Coins are collected in the game modes and can be used to buy new accessories and cool items in the SHOP. After purchasing new items, you can go to "EDIT" to equip your profile with the newly bought items and make your profile completely unique!
- Diamonds are collected by taking your scooter and smart egg out for a ride WITHOUT being connected to a smart device. For every two minutes spent driving you will collect one diamond when the Smart Egg is connected to your smart device again. Diamonds can be used to access new worlds in the WOLRDS tab in the SHOP.

### **Profile**

Under the PROFILE button you can see your overall statistics, search for profiles that you want to add as friends, see your achievements and see a leaderboard with either friends or global users.

To add a friend, press SEARCH PROFILE and tap in the nickname/username of your friend. Add the friend and wait for your friend to accept your invitation. If you have received an invitation from a friend you can find it in the mailbox (ICON). You can always BLOCK friends that you added by mistake or who you no longer wish to remain friends with.

### **Continue as a parent**

The app contains two primary areas with the kid's area covered above. When opening the APP, you can alternatively access the parents/guardians section by pressing "CONTINUE AS A PARENT".

The parent section is there for added safety and allows you to see how the app and smart egg is used. You can also access a GPS function to see where your child is. You cannot play games or compete in the parent area.

Switch between the user profiles in the main parental screen to follow the various profiles in the account. The profile that is showing is the one currently covered in all the functions in the parental view.

To see where your child is, press MAP and START. Note that the tracking function only works if the child has brought a smart device (phone or tablet) when out riding and that smart device is connected to the smart egg. You can also see HOTSPOTS where the child spends more time. A minimum of 5 minutes spent in an area will trigger a hotspot and when a hotspot is pressed you see when it was last visited. Under STATISTICS you can see speed, distance and time spent over time so long as the child has been riding with a smart device connected to the smart egg. Note that the MAP features are created for increased usability and should never be used in emergencies.

Under STATISTICS you can see general statistics about your child driving history as well as see who he/she has befriended. For extra safety, you can also block friends that you haven't

approved. In addition, you can see what ACHIEVEMENTS the child has passed and a leaderboard.

Under SEND NOTIFICATION you can send messages to the child when he/she is using a smart device connected to the smart egg. Note that this is a feature for increased usability and should never be used in emergencies.

#### **Warnings:**

- The device is not recommended for use by children under 3 years of age
- Read instructions thoroughly and keep for future reference.
- This device contains electrical equipment that could cause injury if not handled properly.
- This toy contains a battery that is non-replaceable. Do not attempt to replace the battery or open the enclosure or disassemble the device. Doing so can result in a safety hazard and will void the warranty.
- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Do not use the device if it is damaged. Substances in the device and its battery may harm the environment or cause injury if handled or disposed improperly.
- Do not dispose the device in a fire. The battery could explode.
- Do not expose the device to extremely high or low temperatures or heavy rain.
- The device is water splash-proof only (IPX4). Do not immerse in water.
- Store the product in a dry and moisture free environment.
- Keep a safe distance to other people and objects. Collision hazard. Use of 1 or more devices by several people within the same playing area can cause serious injuries.
- Usage of the device while under the influence of alcohol or drugs is prohibited.
- Do not charge the device while it is wet.
- Do not use the device while charging it.
- Limit the time of continuous usage (make regular stops).

#### **Caution:**

- Disposal of a battery into fire or a hot oven, mechanically crushing or cutting, can result in an explosion.
- Leaving a battery in an extremely high temperature environment can result in explosion, leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure may result in explosion, leakage of flammable liquid or gas.
- Regularly check for damage to the power cable, charging port, device sealing condition, and in the event of damage, it shall not be used until the damage is repaired.

#### **Maintenance**

Clean the product with a soft, moist cloth after each use, and regularly check for visible damage or changes. Do not use solvents, detergent, soap powder or hot water under any circumstances.

#### **Disposal and recycling Information:**

- The symbol on the device and its packaging signifies that this device must be disposed separately from the ordinary household wastes at its end of life because it contains a battery and is electronic equipment. For information about where to recycle contact your local waste disposal authority or the retailer where you bought the device.

#### **Regulatory Information:**

Federal Communications Commission (FCC) Statement:

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) this device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2A2I4MICROSE

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Statement:

- Micro Mobility Systems AG is authorized to apply the CE mark on its product, thereby declaring conformity to the essential requirements and other relevant provisions of Directive 2014/53/EU and other applicable Directives.

### **Warranty:**

Warranty Conditions

The Micro Smart Egg is subject to a warranty period of 2 years.

To make a warranty claim, please contact our dealer network or customer service by telephone on

+41 (0) 44 910 11 22 or by e-mail: [info@micro.ms](mailto:info@micro.ms)

The warranty does not include damage caused by:

- Accidents or unforeseeable events (e.g. lightning, flooding, fire, etc.)
- Improper use or transport
- Ignoring safety and maintenance rules
- Any other improper handling or alterations
- Wear and tear