

SETTING UP VOICE CONTROL WITH THE GOOGLE ASSISTANT OR AMAZON ALEXA
 For more information, visit www.irobot.com/alexa or www.irobot.com/google

VOICE CONTROL COMMANDS FOR THE GOOGLE ASSISTANT OR AMAZON ALEXA:

- Through the app:**
- To 4: Assign a task to a robot (e.g. "Clean the living room")
 - To 4: Assign a task to a robot (e.g. "Clean the living room")
 - To 4: Assign a task to a robot (e.g. "Clean the living room")
- Through the robot:**
- "Alexa, tell me to clean the living room"
 - "Alexa, tell me to clean the living room"
 - "Alexa, tell me to clean the living room"

SETTING UP THE SHARKCLEAN™ APP

Download the SharkClean™ app from the app store or Google Play store. Follow the instructions on the app to connect to the robot.

To ensure the app successfully pairs with the robot:

- Confirm that Wi-Fi is enabled on both systems and that you are on the same network.
- Confirm that the robot is powered on.

CAN'T CONNECT TO WI-FI


- Restart your phone
- Restart your robot
- Press the power button on the back of the robot for 10 seconds to factory reset the robot.
- Restart your Wi-Fi network equipment
- Restart the SharkClean™ app

MAINTENANCE


CAUTION: Turn off power before performing any maintenance.

EMPTYING THE DUST BIN

EMPTY THE DUST BIN REGULARLY



Remove the dust bin and empty it into a dust container.




Reinsert the dust bin and ensure it is properly seated.




Remove the filter and clean it.

CLEANING THE FILTER


CLEAN THE FILTER REGULARLY. REPLACE FILTER EVERY TWO MONTHS.




Use a soft brush to clean the filter. Do not use harsh chemicals.



Reinsert the filter and ensure it is properly seated.




Remove the multi-surface brushroll.




Clean the brushroll with a soft brush.

CLEANING THE MULTI-SURFACE BRUSHROLL


THE MULTI-SURFACE BRUSHROLL OCCASIONALLY MAY REQUIRE CLEANING. REPLACE THE MULTI-SURFACE BRUSHROLL EVERY 6 MONTHS OR WHEN IT BECOMES WEAR.




Remove the multi-surface brushroll.



Clean the brushroll with a soft brush.



Reinsert the multi-surface brushroll and ensure it is properly seated.




Reinsert the multi-surface brushroll and ensure it is properly seated.


NOTE: The multi-surface brushroll is designed to last for 6 months. If you notice the brushroll becoming worn or damaged, it may be time to replace it.

CLEANING SENSORS AND CHARGING PADS

CLEAN THE SENSORS AND CHARGING PADS REGULARLY. Wipe the sensors and charging pads with a soft, damp cloth.




Wipe the sensors and charging pads with a soft, damp cloth.



CLEANING SIDE BRUSHES

CLEAN THE SIDE BRUSHES REGULARLY. Wipe the side brushes with a soft, damp cloth.




Remove the side brush and clean it with a soft, damp cloth.


NOTE: The side brush is designed to last for 6 months. If you notice the side brush becoming worn or damaged, it may be time to replace it.

CLEANING THE WHEELS

REMOVE ANY DEBRIS FROM THE WHEELS REGULARLY. Wipe the wheels with a soft, damp cloth.




Wipe the wheel with a soft, damp cloth.




Wipe the wheel with a soft, damp cloth.

NOTE: The wheel is designed to last for 6 months. If you notice the wheel becoming worn or damaged, it may be time to replace it.




Remove the battery and clean it with a soft, damp cloth.

REPLACING THE BATTERY



Insert the battery and ensure it is properly seated.



Insert the battery and ensure it is properly seated.

NOTE: The battery is designed to last for 6 months. If you notice the battery becoming worn or damaged, it may be time to replace it.

TROUBLESHOOTING

Refer to the troubleshooting section of the user manual for more information on resolving issues.

| ERROR CODE | SOLUTION |
|---------------------------|---|
| AL-001 (Battery Error) | Check the battery level and ensure it is fully charged. If the battery is low, recharge it. |
| AL-002 (Sensor Error) | Clean the sensors with a soft, damp cloth. Ensure the sensors are not blocked by debris. |
| AL-003 (Motor Error) | Check the motor for any obstructions. Clean the motor and ensure it is properly seated. |
| AL-004 (Wi-Fi Error) | Restart your Wi-Fi network and the robot. Ensure both are on the same network. |
| AL-005 (App Error) | Restart the SharkClean™ app and the robot. Ensure the app is updated to the latest version. |
| AL-006 (Charging Error) | Check the charging pad and ensure it is clean and dry. Ensure the robot is properly seated on the pad. |
| AL-007 (Navigation Error) | Check the robot's navigation system and ensure it is not blocked by obstacles. Clean the sensors and ensure the robot is properly seated. |
| AL-008 (Cleaning Error) | Check the brushroll and ensure it is clean and properly seated. Clean the brushroll with a soft, damp cloth. |
| AL-009 (Side Brush Error) | Check the side brush and ensure it is clean and properly seated. Clean the side brush with a soft, damp cloth. |
| AL-010 (Wheel Error) | Check the wheel and ensure it is clean and properly seated. Clean the wheel with a soft, damp cloth. |
| AL-011 (Filter Error) | Check the filter and ensure it is clean and properly seated. Clean the filter with a soft, damp cloth. |
| AL-012 (Dust Bin Error) | Check the dust bin and ensure it is clean and properly seated. Empty the dust bin and reinsert it. |
| AL-013 (Power Error) | Check the power source and ensure it is properly connected. Restart the robot and the app. |

REFURBISHED PRODUCT LIMITED NINETY DAYS WARRANTY

The **Refurbished Product Service Center** offers the following WARRANTY to the ORIGINAL purchaser of a product which we have refurbished.

This product that has been refurbished is warranted against any electronic or mechanical defects for a period of NINETY DAYS from the date of the original purchase by the consumer. Since this unit was sold as a refurbished item, the warranty does not apply to any cosmetic appearance items such as scratches. Should a defect occur, the **Refurbished Product Service Center** will repair or, at its option, replace defective unit/parts with new or rebuilt materials without charge for either parts or labor. Replacement unit/parts will be warranted for the remaining portion of the original warranty period.

This warranty does not cover installation or damage from accident, misuse, abuse, improper wiring, incorrect voltage, operating the unit against the instructions in the owner's manual or any product which has been opened, altered, or tampered with.

This warranty does not cover costs for removal and/or installation of the unit for repair. Under no circumstances shall the service center be liable for any special, incidental or consequential damages or for any other expenses incurred by reason of use or sale of this product. This warranty is in lieu of any other warranties expressed or implied warranty of merchantability of fitness for particular use or otherwise.

This warranty gives the consumer specific legal rights and they may also have other rights which vary from State to State. Some States do not follow the exclusion or limitation of incidental or consequential damages, hence the above exclusion and limitations may not apply.

Refurbished Product Service Center
 9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

WARRANTY REPAIR INFORMATION

If you need service on your unit and this product requires repair during the 90 days warranty period; please go to www.ConsumerServiceRefurbish.com or call the **Refurbished Product Service Center** at 562-946-3531 to obtain the required return authorization (RA) number. Pack the unit properly (the original carton is ideal for this purpose) along with a copy of your purchase receipt and a letter describing the problem. Send the unit freight prepaid and insured to:

Refurbished Product Service Center,
 Attn: Customer Service Department 9043 Siempre Viva Rd Suite 110/120, San Diego CA, 92154

Your unit will be promptly repaired and returned to you. We will refuse to accept delivery of the returned unit unless the assigned RA number appears on the outside of the shipping carton.

Owner's Information
 (Keep for your permanent records)

NAME: _____
 ADDRESS: _____
 CITY: _____ STATE: _____ ZIP CODE: _____
 PHONE: _____ E-MAIL: _____
 MODEL: _____ SERIAL NO.: _____

804106926 PRINTED IN MEXICO Elbrd: J.E.
 OBPN: av752-av753_IB_REV_Mv2_200914
 SC: 10-01-2023_TAB MODEL: AV752R01US_B