

SR600 User Manual

Application scenario

The SR600/USA LTE:

- * Provide Internet access for Wi-Fi® devices and computers
- * Expand LAN coverage together with a hub or a switch

Appearance



1. TYPE-C Power input Connect to compatible power adapter
2. Indicator lights
3. RESET Restore the LTE SR600 to its factory settings.
4. LAN port
 - Working as a LAN port when connected to a computer, switch, or other LAN device.

Indicator Meanings:

*** PWR LED indicator**

Off: Power off

On: Power on

*** SYS LED indicator**

Off: System is not running

Blinking in Blue: System startup

Blue: System is in service

*** LTE LED indicator**

Off: LTE is not in service

Blinking: Data is in connecting

Blue: Data service ready

SR600 SETUP

1 Step:

Simply plug the device in to the provided power adaptor, and allow roughly 3 minutes for all 3 status lights to come online(Solid Color). This all that is needed to connect your home to the internet!

Note:

Use the provided power adapter. Use of an incompatible power adapter, or one from an unknown manufacturer may cause the LTE SR600 to malfunction, fail, or could even cause a fire. Such use voids all warranties, whether expressed or implied, on the product.

CONNECTING TO YOUR SR600 WI-FI NETWORK

Once the router has connected to a carrier, you can connect your computer, tablet, laptop, or mobile phone to the router' s Wi-Fi network to access the Internet.

Please refer to the label on the bottom of the router for the wireless network name (SSID) and password.



Note:

- 1.) When the SYS LED indicator is steady on, Wi-Fi is enabled.
- 2.) Scanning the QR code will bring up registration page for Warranty registration

Package Contents:

- SR600 Modem/Router
- 5V 2A Power Supply
- 1.5M(4 Foot) Power Cable

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.