



Atlas 15.6" Windows 11 Pro Laptop

4GB, 128GB

KAL15E700PB

Safety & Warnings

- Read all instructions and warnings before first use and retain this user guide for future reference.
- This laptop is designed for use in non-tropical regions and at altitudes below 2,000 metres.
- Do not drop the laptop.
- Do not subject the laptop to strong impacts from heavy objects or surrounding elements.
- Do not use the laptop for extended periods in environments that are extremely cold, hot (above 45°C), highly humid, or dusty.
- Do not expose the laptop to direct sunlight.
- Avoid using the laptop in areas with strong magnetic or static fields.
- Do not allow water or any other liquid to come into contact with the laptop. If liquid splashes onto the laptop, close it immediately and unplug the power adaptor. Do not use the laptop until it is completely dry.
- Do not clean the laptop with chemical detergents or any other liquids, as this may cause damage.
- Back up data regularly to avoid the risk of accidental data loss.
- Do not attempt to modify or disassemble the laptop.
- Replacing the laptop battery with an incorrect type may cause an explosion. Only use original batteries. For assistance, contact **help.Kogan.com**.

Components



Laptop



Power Adaptor



User Guide

Overview

Front View



1	Camera	Used for photos, recording video and video calls.
2	Display	HD LCD display panel.
3	Microphones	Built-in twin microphones can be used to record audio and interact in video calls.
4	Indicators	These respective indicators will illuminate when power, caps lock, or the digital key lock is used.
5	Power Button	Used to control the power status of the laptop.
6	Keyboard	QWERTY keyboard with Windows key and function options.
7	Track Pad	Used as a mouse for on-screen navigation and gestures.
8	Left/Right Track Pad Buttons	Used as the left and right-click buttons of a traditional mouse.

Bottom View



9	Speakers	Two built-in speakers allowing for stereo audio output.
---	----------	---

Left View



10	Charging Indicator	Illuminates red when the laptop is being charged.
11	Charging Port	Plug the power adaptor into the charging port to charge the laptop.
12	USB 3.0 Port	Input for flash drives, additional keyboard/mouse and other compatible devices supporting USB 3.0 or older.
13	HDMI Port	Suitable for connecting a TV or external monitor using an HDMI cable (not provided).
14	USB-C Port	<ul style="list-style-type: none">• This port is used for charging the laptop with suitable adaptor.• Suitable for connecting a device for data transfer.• Suitable for connecting a monitor for video playing.

Right View



15	MicroSD Card Slot	MicroSD card reader suitable for transferring files.
16	3.5mm Audio Port	Suitable for connecting audio devices (for example, headphones, external speakers, amplifiers) using an AUX cable (not provided).
17	USB 3.0 Port	Input for flash drives, additional keyboard/mouse and other compatible devices supporting USB 3.0 or older.

Operation

Getting Started

- Connect one end of the power adaptor to the charging port on the laptop and the other end to an electrical outlet. Switch on the power at the outlet. The 'Charging' indicator will illuminate red.
- Press the 'Power' button to turn on the laptop. During the first startup, you may be prompted to set up Windows 11. Follow the on-screen instructions to complete the setup.

Note:

Charge the laptop for at least 3 hours before turning it on for the first time.

Using Windows 11

Desktop

Once the setup is complete, the laptop will boot to the desktop. Icons on the desktop serve as shortcuts to access applications. To open an application, double-click its icon.




Note:

You may need to log into your Microsoft account for programs to run with full compatibility.

Start Menu

- Click the Windows icon at the bottom of the screen to access the Start menu.
- Installed apps can be accessed from the Start menu. Recently used apps will appear under the 'Recent' section for quick access.
- Additional apps can be downloaded and installed via the Microsoft Store.



Notification Menu

- Click the time/date in the lower-right corner of the screen to open the notification menu.
- This menu displays notifications such as updates, emails, and calendar reminders and provides quick access to settings like Wi-Fi, Bluetooth, and brightness adjustments.



Multitasking

- Drag one window to the left or right side of the screen. Release it when an overlay appears, occupying half the screen.
- Select another open window to fill the remaining half of the screen.



Sleep, Restart and Shut Down

- Click the Windows icon at the bottom of the screen, then select the 'Power' icon.
- Choose Sleep, Restart, or Shut Down to perform the desired action.
- To wake the laptop from sleep, press the 'Power' button.
- If the laptop becomes unresponsive, press and hold the 'Power' button to force a shutdown. Press the 'Power' button again to restart the laptop.



Power Icon

Cleaning & Care

- Ensure the laptop is switched off before cleaning.
- Wipe the laptop surface with a dry, soft cloth or paper towel.

Specifications

Display	
Screen size	15.6"
Screen resolution	1920 x 1080
Performance	
CPU	Intel Celeron Processor N4020
CPU speed	1.1-2.8GHz
GPU	Intel UHD Graphics 600
Operating system	Windows 11 Pro
System memory (RAM)	4GB
Power	
Battery capacity	5000mAh
Battery life	4 hours
Battery type	Lithium-ion polymer battery
Storage	
Storage capacity	128GB
Storage type	eMMC
Ports	
3.5mm audio port	Yes
HDMI	x1, 1.4a
USB 3.0	x3
USB-C	x1
MicroSD card slot	x1
Connectivity	
Bluetooth	Yes, V5.0
Wi-Fi	Yes
Wi-Fi protocols	802.11b/g/n/ac
Speaker	x2, 2W
Other	
Dimensions	358 x 226 x 20.5mm
Weight	1.56kg
Built-in webcam	Yes

Troubleshooting

The Laptop is Not Turning On

- The battery may be fully depleted. Charge the laptop for at least an hour before attempting to turn it back on.
- Observe whether any indicators or internal components, such as fans, turn on during the process.

Note:

If the laptop is stored for an extended period, it is recommended to charge it periodically to maintain battery health. Batteries naturally deteriorate over time and may lose capacity or fail entirely.

The Laptop is Not Charging

Inspect the laptop, charging port and power adaptor for any physical damage. If damaged, cease use immediately and contact help.Kogan.com for support.

The Laptop is Not Connecting to Wi-Fi

- Restart your modem and router (or both if you have separate units).
- Reconnect any range extenders being used.
- Restart the laptop.
- Move the laptop closer to the modem/router.
- Ensure the Wi-Fi password is entered correctly.
- If the laptop connects to Wi-Fi but the connection is slow or weak, disconnect and reconnect to the network.

The Laptop Screen Becomes Dark When the Power Adaptor is Unplugged

This will be occurring due to your power plan settings. Go to the Control Panel and change your power plan settings to allow the screen to remain on when the laptop is not charging/unplugged.

Forgotten Password

If you forget your Microsoft account password, you can reset it using one of the following methods:

- Use a password reset disc via USB.
- Reset your Microsoft account password online using another device.
- Reset Windows 11 to factory default settings.

Note:

Resetting to factory defaults will erase all personal data stored on the laptop. Ensure you back up any important files beforehand.

Notes

[illegible]

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.Kogan.com**.

