

Wi-Fi Speaker with
Amazon Alexa Voice



User Guide
SWF1002

Before You Begin...

Questions & Customer Support



For assistance with this item, please call our customer support line at **1 - 877 - 768 -8481** (Mon - Fri, 8am - 10pm EST) or visit our website at **SouthernTelecom.com** and click on **Product Support**.

In the Box

- SWF1002 - **Wi-Fi Speaker** (x1)
- Micro-USB Charging Cable (x1)
- User Manual (x1)
- Quick Start Guide (x1)

Location of Controls

1. [🔇] Button: Mute/unmute Alexa voice activation
2. [—] Button: Decrease volume
3. [⏻] Button: (**Long Press**) Power speaker ON/OFF
4. [🔊] Button: Alexa activation
5. [+] Button: Increase volume
6. [M] Button: Change input mode
7. Color Ring
8. 3.5 mm Auxiliary Jack
9. Micro-USB Charging Port
10. Charging LED Indicator



Using the Speaker



EDGE
by Sharper Image
Android 4.03+
iOS 7.0+

Connecting with the EDGE App

NOTE: When connecting the speaker to your Wi-Fi network with the **EDGE by Sharper Image** mobile app, make sure the Wi-Fi network your device is connected to is a 2.4G network, NOT a 5G network.

1. Search for the **EDGE by Sharper Image** app on the **Google Play Store** or **App Store**. Download and install.
2. Long press the [⏻] button to power the speaker ON.
3. Open the EDGE app and follow the directions on-screen to connect to the speaker.

While the speaker is in Wi-Fi mode, the color ring will turn solid **LIGHT BLUE**.

Pairing with Bluetooth

1. Press the [M] button to switch to Bluetooth mode. A voice will be heard and the speaker lights will flash.
2. Set your mobile device to search for Bluetooth devices. When it appears, select **SWF1002** from the list of found devices.
3. After a successful pairing, a tone will be heard indicating that the pairing was a success.

While the speaker is in Bluetooth mode, the color ring will turn solid **BLUE**.



Connecting with the Auxiliary Cable

Attach one connector of a 3.5 mm auxiliary cable (*not included*) to the 3.5 mm auxiliary input jack on the back of the speaker. Attach the other connector to the headphone jack on your media-playing device.

While the speaker is in auxiliary mode, the color ring will turn solid **GREEN**.

NOTE: All Wi-Fi and Bluetooth connections will be disabled while using the auxiliary input. Playback is controlled through your connected device.



Charging the Speaker

Attach the small connector of the supplied micro-USB cable to the micro-USB charging port on the side of the speaker. Attach the large connector to the USB port on a computer, USB charging device, or **5V USB adapter** (*not included*) and plug into a wall socket.

The LED indicator will turn **RED** while charging and turn OFF when fully charged.

Powering ON/OFF

- Long press the [⏻] button to power the speaker ON or OFF.

Changing Input Modes

- Quick press the [M] button to change between Wi-Fi, Bluetooth, and Auxiliary input modes.

Adjusting Volume

- Long press the [+] and [—] buttons to adjust volume or use the controls on your paired device or in-app controls.

Using Alexa (Alexa ONLY)

- After it is set up, Alexa can be activated with your voice or by pressing the [🔊] button for immediate access.
- To mute/unmute voice access, press the [🔇] button.
 - Press the [🔊] button to immediately access Alexa **without** voice activation.

Playing Music

Music can be played via the **EDGE by Sharper Image** mobile app, pairing your device via Bluetooth, or by connecting a 3.5 mm auxiliary cable. Please refer to the appropriate section in the column to the left for more information on connecting to your speaker.

Listen Outloud with Spotify Connect

1. Connect your **Wi-Fi Speaker** to your Wi-Fi network via the **EDGE by Sharper Image app**.
2. Open up the Spotify app on your phone, tablet, or laptop using the same Wi-Fi network.
3. Play a song and select **Devices Available**.
4. Select your **Wi-Fi Speaker** and start listening.

Setting Up Amazon Alexa

The **SWF1002** has extensive integration with Amazon Alexa. To use the speaker with Alexa you must login (or create an Amazon account if you do not have one), then log in via the **EDGE by Sharper Image** app.

Once logged in, you will be able to use Alexa functions with the speaker. Please consult Amazon's Alexa website for tutorials on how to use Alexa and adjust your Alexa settings.

Using the Speaker with Alexa

Once you have logged into and set up Alexa through the **EDGE by Sharper Image** app, you may interact with Alexa by speaking aloud and starting your sentences with "Alexa."

You may ask questions such as "Alexa, what is the weather?" or make requests, such as "Alexa, play some music" or "Alexa set a timer."

NOTE: For best results with Alexa voice, keep the speaker around 75% in the **EDGE** app.

While using the speaker **in conjunction with Alexa**, the color ring will display different colors to visually communicate its actions:

- **Solid Light Blue** - Alexa is idle
- **Solid Blue**- Alexa is listening
- **Flashing Blue** - Alexa is thinking
- **Flashing Light Blue and Blue** - Alexa is speaking
- **Flashing Red** - Alexa has encountered an error
- **Solid Red** - Microphone is off

For tutorials on how to use Alexa or to adjust your Alexa settings, please consult Amazon's Alexa website at **Alexa.Amazon.com**

Legal Information

READ CAREFULLY AND KEEP THIS MANUAL

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Wi-Fi Speaker SWF1002

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undersired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARNING Li-ion Battery Inside

This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).



The crossed-out garbage bin symbol means that you must not dispose of this product together with unsorted household waste.

Rain/Moisture Warning

- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid conditions, or wet conditions.
- Do not submerge in water.
- Do not open this product or attempt to repair the unit yourself should it not be working.

Limited Warranty

90 Days Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:


- Call the Customer Support number located below, or go to our website portal to receive an SRO number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

 **Customer Service Dept. 36**
c/o Southern Telecom
400 Kennedy Drive
Sayreville NJ 08872

Should you have any questions or problems concerning this product, please contact our customer service department at:

 **1 - 877 - 768 -8481**
Monday - Friday, 8AM - 10PM (EST)

Or visit our website at:

 **SouthernTelecom.com**
Click on **Product Support**

Warranty Service Not Provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty

• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

• REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Android, Google and the Google Play store logo are registered trademarks of Google Inc., used with permission.

Apple, iOS, and the App Store are registered trademarks of Apple Inc., registered in the U.S. and other countries.

The Spotify Software is subject to third party licenses found here: <http://www.spotify.com/connect/third-party-licenses>

2018 Sharper Image® name and logo are registered trademarks. Manufactured, marketed, and distributed under license by Southern Telecom, Inc. Brooklyn, NY 11220. © Sharper Image. All Rights Reserved.

All other trademarks and trade names are those of their respective owners.