





SWEETFOX

## CHILD'S HIGH CHAIR



INSTRUCTION MANUAL MODEL : Q1

**WARNING IMPORTANT !  
READ CAREFULLY AND KEEP  
FOR FUTURE REFERENCE**


CONFORMS TO NORM EN14988:2017+A1: 2020  
EN12790:2009

TUTORIAL-VIDEO

<https://youtu.be/qK2H-n6aDdg>




## PARTS



1. BUTTON TO ADJUST THE ANGLE OF THE SEAT BACK
2. ANCHORING HOLES FOR THE BELT
3. FABRIC COVER HOOKS
4. BUTTON TO ADJUST THE SEAT HEIGHT
5. BUTTON TO FOLD THE CHAIR FRAME
6. TRAY HOOK
7. WHEEL
8. PLAY ARCH
9. FIVE-POINT HARNESS
10. TRAY
11. TRAY SCREW
12. CROTCH RESTRAINT POST
13. FOOTREST ADJUSTMENT BUTTON
14. FOOTREST
15. LEG

## WARNING


- This product is intended for children from 6 to 36 months old weighing a maximum of 15kg and capable of sitting up on their own when used as a high chair. When used in the reclining position, this product is intended for children from 0 to 6 months old, 9kg.
- **NEVER** leave the child unattended.
- **Always** use the restraint system.
- **Do not** use the product if all of the parts are not properly attached and adjusted.
- **Risk of falling: do not let the child climb on the product.**
- **Be aware of the risk of tipping over if the child pushes against a table or other structure with their feet.**
- **Be aware of the risks caused by open fireplaces or other sources of high heat near the product.**
- Assembly and adjustment of the product must be carried out by an adult.
- Prevent the child from falling or slipping: use the safety straps and check that they are correctly fastened.
- Never leave the child unattended.
- Follow the manufacturer's instructions.
- Always use the restraint system.
- Do not use the high chair before the child is able to sit up on their own.
- Do not use the chair if a part is broken, damaged or missing.
- Use the high chair on a flat, even and horizontal floor, and do not put it on a high structure or table.
- Do not put your fingers in the mechanisms and pay attention to the position of the child's limbs when making adjustments.
- Always use the safety harness to prevent sliding and falling. the child must always be strapped into the high chair with the harness, both when lying down and when sitting upright. The tray is not designed to hold the child in the chair.
- Risk of falling: do not allow the child to climb on the product.
- To avoid any risk of suffocation, throw away the plastic bags/protection.
- Do not use the product as a reclining chair when the child is able to sit up on their own.
- This seat is not designed for long naps. The reclining high chair does not replace a cot. If the child wants to sleep, it is important to move them to a suitable bed.
- Risk of strangulation: never leave the child in the reclined chair when the straps are loose or unfastened.
- Do not leave the seat in the sun for long periods of time. Wait until it cools down before putting the child inside.
- It is forbidden to use any accessories other than those provided by the manufacturer.



**When you receive your high chair, all the pieces are stowed to fit in as small a space as possible. You must therefore follow these steps to make the best use of it.**



Remove the product from its box, remove the plastic bags. You can easily adjust the angle of separation of the legs by pushing simultaneously on both buttons on the right and on left of the seat and pulling the legs apart until you hear a 'click', indicating they are in place.

**Attention: Make sure the legs are securely locked into the correct position.**



Adjust the seat height by pushing the two black buttons on the sides of the seat, behind the seat back at bottom left and right. Keeping the buttons pushed in, lift the seat to the desired height and make sure you hear the 'click' indicating the seat is in place. There are seven possible heights for this seat.

**Attention: Make sure the height is securely locked into one of the seven notches.**



Adjust the angle of the footrest by pushing the two black buttons on the sides of the footrest. There are three possible positions.

**Attention: Make sure the footrest is securely locked into one of the three notches.**

You can adjust the angle of the chair using the large black button behind the seat back. There are five possible positions.

**Attention: Make sure the seat back is securely locked into one of the five notches.**

**Attention: Use the vertical position for babies over 6 months and under 15 kg (33 lbs). The horizontal position is not suitable for naps or for baby to sleep in overnight. This product should never be used as an alternative to a bed.**

**0 m - 9 Kg**




**"WARNING!**

It is dangerous to use this reclining high chair on an elevated surface, e.g. a table.

This reclining high chair is not intended for prolonged periods of sleeping.

Always use the restraint system."

**High chair conforms to the ASTM F404, EN14988:2017+A1: 2020 and EN12790:2009 standard. Arch conforms to ASTM F963 standard.**




You can now place the tray on the chair. It is stored on two posts on the back legs of the chair. Pull it upwards (not directly towards you) off its posts.

Once you are holding it in your hands, push the button on the tray. This will put the bars on the right and left sides of the tray into position to insert them into the chair. Gently push the tray all the way into place and release the button.

**Attention: Make sure the tray is securely in place, pull gently on it to make sure that it can't fall off on its own.**

**Attention: Always leave the tray in place while your child is in the high chair.**



To use the belt, make sure you fit the buckles securely into the anchor until you hear a 'click', which indicates the belt is secured. Make sure both straps are secured in the anchor to make sure that baby is properly attached. To remove the belt, just push the center button to release both sides simultaneously.

**Attention: Your child must remain attached at all times while the high chair is in use.**

You can also adjust the height of the belt buckle. There are two possible heights with two holes. Make sure the straps are free and attached around the back of the seat. Remove the two buckles and pull on them to pull the straps through the seat. Place each one in the correct hole at the desired height and pull them to the front of the seat. Secure the buckle at the back of the seat.

**Attention: Your child must remain attached at all times while the high chair is in use.**

**You can also add the arch by clipping it on as shown in the picture above.**