


DANGER



• To reduce the risk of electric shock, always unplug this appliance from the electrical outlet immediately after using and before cleaning.

- There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- Rechargeable battery is only to be charged by an adult. Adult Supervision is required while charging the battery.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products.
- Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong odor.
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts, and in the event of such damage, they must not be used until the damage has been repaired.
- Recycle or dispose of battery according to federal, state, and local laws.

RECHARGEABLE BATTERY WARNINGS

CONGRATULATIONS ON YOUR PURCHASE OF THE SHIATSU FULL BODY

Keep this instruction manual as it contains important information for future reference.

Due to continuous product improvements, the picture on the manual may differ slightly from the actual product.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING THE 77 LOGO AND TOMORROW'S TOMORROW) ARE TRADEMARKS OR REGISTERED TRADEMARKS. DISTRIBUTED BY AND © 2021 MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED. FOR CUSTOMER SUPPORT, PLEASE CALL 1-800-374-2744.

Item # 1014508

Printed in China

- Not a children's item. Keep out of the reach of children.
- As with any massage, bruising may occur. Test your comfort level and check targeted areas often. Stop massage immediately if you feel any increase in physical discomfort or pain.
- Do not use this item if you are pregnant or have an injury or illness. Consult your physician if you have a medical condition that may prevent safe use of this item.
- Do not use attachments of any kind other than those that may be included.
- Do not fall asleep while using.
- Keep long hair away from this item while it is in use.
- Do not leave this item unattended when it is plugged in.
- Always allow item to cool if it becomes too hot.
- Never operate under blankets where air opening may be blocked. Excessive heat can occur and cause fire, electric shock, or injury to persons.
- Do not expose to extreme temperatures or moisture.
- Keep away from sources of water and heated surfaces.
- Never touch the power plug with wet hands.
- Do not carry this item by its cord.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.

SAFETY WARNINGS: PLEASE READ BEFORE USE



SHARPER IMAGE®

SHIATSU FULL BODY



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.


WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CARE INSTRUCTIONS

- Spot clean only. Unplug and wipe with a damp cloth.
- Air-dry only. Never place in a dryer.
- Allow to dry fully before plugging in.
- Do not submerge in water.
- Do not use detergent or soap when cleaning.


GETTING STARTED

1. Plug the power adapter into the massager and then into a wall outlet.
2. Before first use, allow massager to fully charge. A white light will appear once the massager is fully charged. The massager can be used wirelessly after the massager is fully charged.
3. Put on the massager then press and hold the power button.
 - Press the reverse spin button for direction control.
 - Press speed button to adjust low and high speed.
 - The default massage length is 15 minutes. Press the timer button to increase your massage to 30 minutes.
4. Multifunction strap can be removed for foot massages.
5. Enjoy your massage!




CONTENTS

- Massager
- Multifunction Strap
- Power Adapter




Massager




Power Adapter

FEATURES


- Shiatsu massage with deep kneading
- Adjustable pressure with arm straps
- Reverse the spin at the touch of a button




Abdomen




Neck + Shoulder




Waist




Thigh




Neck



Back



Feet



Chair