

# CYCLONE NS

MULTI-PLATFORM  
WIRELESS GAME CONTROLLER



[E-MANUAL]  
<https://www.gamesir.com/zh/manual/gamesir-hc4c>


## PACKAGE CONTENTS

Cyclone™ \*1 USB-C Cable (1m) \*1 User Manual \*1 Thank You & Alter-sale Service Card \*1 Gamesir Sticker \*1 Certification \*1

## REQUIREMENTS

- Switch
- Windows 7/10 or above
- Android 8.0 or above
- iOS 13 or above

## DEVICE LAYOUT



## CONNECTION STATUS

Home Button	Description
Slowly blink	Reconnection status *Reconnection status, it can only be connected by the last paired device in this mode.
Fast blink	Paring status *Paring status, it can only be searched and paired by the device
Steady	Connected

## HOMEBUTTON STATUS

Color	Mode	Connection	System
Blue	XInput	A+Home	Win 7/10 or above, iOS 13 or above
Green	Receiver	Y+Home	Win 7/10 or above
Red	NS Pro	X+Home	Switch
Yellow	Android	B+Home	Android 8.0 or above

## PAIR WITH USB RECEIVER

To pair with the receiver, turn the controller before leaving the factory if the receiver cannot be properly connected to the controller during use, please use the following method to re-pair:

1. Plug the receiver into the USB port of the connected device and click the receiver's Pair button. The receiver's indicator will blink to indicate pairing status is entered.
2. When the controller is turned off, press the Y+Home buttons until the Home button blinks green, then hold the controller's Pair button until the Home button blinks fast and wait for the receiver's indicator to stop blinking.
3. After a successful connection, the receiver's indicator will be solid white, and the controller's Home button stays solid.

## CONNECT TO YOUR PC VIA USB RECEIVER

1. Plug the receiver into the PC's USB port.  
2. When the controller is turned off, short press the A+Home buttons to power on. The Home button will blink quickly.

3. Turn on the computer's Bluetooth, click XInput Wireless Controller and pair.

4. The Home button will become solid yellow to indicate a successful connection.

5. Once again, turn the controller off to connect automatically.

\*In Non-Switch mode, the values of the A-button & B-button, and X button & Y button of the controller will be swapped.



## CONNECT TO YOUR DEVICE VIA USB CABLE

To use the included USB-C cable to connect the controller to the switch.

\*To connect to Switch, go to Switch's Home menu, top system settings>Controller and Sensors>Pro Controller: Wired Connection and set it to "On".

\*In non-switch mode, the values of the A-button & B-button, and X button & Y button of the controller will be swapped.



## CONNECT TO IPHONE VIA BLUETOOTH

1. When the controller is turned off, short press the A+Home buttons to power on. The Home button will blink quickly.


2. Turn on the phone's Bluetooth, click XInput-Cyclone and pair.

3. The Home button will become solid yellow to indicate a successful connection.

4. Once again, turn the controller off to connect automatically.

\*If the controller was not connected using the A+Home buttons last time, it needs to be turned on using the button combinations.

\*In Non-Switch mode, the values of the A-button & B-button, and X button & Y button of the controller will be swapped.



## CONNECT TO ANDROID DEVICES VIA BLUETOOTH

1. When the controller is turned off, short press the A+Home buttons to power on. The Home button will also turn.


2. Turn on the phone's Bluetooth, click XInput-Cyclone and pair.

3. The Home button will become solid yellow to indicate a successful connection.

4. Once again, turn the controller off to connect automatically.

\*If the controller was not connected using the A+Home buttons last time, it needs to be turned on using the button combinations.

\*In Non-Switch mode, the values of the A-button & B-button, and X button & Y button of the controller will be swapped.



## CONNECT TO SWITCH VIA BLUETOOTH

1. Go to Switch's Home Menu, select "Controllers" -> Change/Grip/Order" to enter the pairing mode.

2. When the controller is turned off, short press the X+Home buttons to power on. The Home button blinks fast to wait for pairing.

3. The Home button will become solid red to indicate a successful connection.


4. Once again, turn the controller off to connect to Switch, just short press the Home button and the console will wake up.

\*If the controller was not connected using the X+Home buttons last time, it needs to be turned on using the button combinations.

\*In Non-Switch mode, the values of the A-button & B-button, and X button & Y button of the controller will be swapped.



## BACK BUTTONS SETTINGS



Programmable as single or multi-button (Up to 16)

Can be programmed to: Home, 12Hz, 10Hz, 20Hz, 30Hz, 40Hz, 50Hz, 60Hz, 70Hz, 80Hz, 90Hz, 100Hz, 110Hz, 120Hz, 130Hz, 140Hz, 150Hz, 160Hz, 170Hz, 180Hz, 190Hz, 200Hz, 210Hz, 220Hz, 230Hz, 240Hz, 250Hz, 260Hz, 270Hz, 280Hz, 290Hz, 300Hz, 310Hz, 320Hz, 330Hz, 340Hz, 350Hz, 360Hz, 370Hz, 380Hz, 390Hz, 400Hz, 410Hz, 420Hz, 430Hz, 440Hz, 450Hz, 460Hz, 470Hz, 480Hz, 490Hz, 500Hz, 510Hz, 520Hz, 530Hz, 540Hz, 550Hz, 560Hz, 570Hz, 580Hz, 590Hz, 600Hz, 610Hz, 620Hz, 630Hz, 640Hz, 650Hz, 660Hz, 670Hz, 680Hz, 690Hz, 700Hz, 710Hz, 720Hz, 730Hz, 740Hz, 750Hz, 760Hz, 770Hz, 780Hz, 790Hz, 800Hz, 810Hz, 820Hz, 830Hz, 840Hz, 850Hz, 860Hz, 870Hz, 880Hz, 890Hz, 900Hz, 910Hz, 920Hz, 930Hz, 940Hz, 950Hz, 960Hz, 970Hz, 980Hz, 990Hz, 1000Hz, 1010Hz, 1020Hz, 1030Hz, 1040Hz, 1050Hz, 1060Hz, 1070Hz, 1080Hz, 1090Hz, 1100Hz, 1110Hz, 1120Hz, 1130Hz, 1140Hz, 1150Hz, 1160Hz, 1170Hz, 1180Hz, 1190Hz, 1200Hz, 1210Hz, 1220Hz, 1230Hz, 1240Hz, 1250Hz, 1260Hz, 1270Hz, 1280Hz, 1290Hz, 1300Hz, 1310Hz, 1320Hz, 1330Hz, 1340Hz, 1350Hz, 1360Hz, 1370Hz, 1380Hz, 1390Hz, 1400Hz, 1410Hz, 1420Hz, 1430Hz, 1440Hz, 1450Hz, 1460Hz, 1470Hz, 1480Hz, 1490Hz, 1500Hz, 1510Hz, 1520Hz, 1530Hz, 1540Hz, 1550Hz, 1560Hz, 1570Hz, 1580Hz, 1590Hz, 1600Hz, 1610Hz, 1620Hz, 1630Hz, 1640Hz, 1650Hz, 1660Hz, 1670Hz, 1680Hz, 1690Hz, 1700Hz, 1710Hz, 1720Hz, 1730Hz, 1740Hz, 1750Hz, 1760Hz, 1770Hz, 1780Hz, 1790Hz, 1800Hz, 1810Hz, 1820Hz, 1830Hz, 1840Hz, 1850Hz, 1860Hz, 1870Hz, 1880Hz, 1890Hz, 1900Hz, 1910Hz, 1920Hz, 1930Hz, 1940Hz, 1950Hz, 1960Hz, 1970Hz, 1980Hz, 1990Hz, 2000Hz, 2010Hz, 2020Hz, 2030Hz, 2040Hz, 2050Hz, 2060Hz, 2070Hz, 2080Hz, 2090Hz, 2100Hz, 2110Hz, 2120Hz, 2130Hz, 2140Hz, 2150Hz, 2160Hz, 2170Hz, 2180Hz, 2190Hz, 2200Hz, 2210Hz, 2220Hz, 2230Hz, 2240Hz, 2250Hz, 2260Hz, 2270Hz, 2280Hz, 2290Hz, 2300Hz, 2310Hz, 2320Hz, 2330Hz, 2340Hz, 2350Hz, 2360Hz, 2370Hz, 2380Hz, 2390Hz, 2400Hz, 2410Hz, 2420Hz, 2430Hz, 2440Hz, 2450Hz, 2460Hz, 2470Hz, 2480Hz, 2490Hz, 2500Hz, 2510Hz, 2520Hz, 2530Hz, 2540Hz, 2550Hz, 2560Hz, 2570Hz, 2580Hz, 2590Hz, 2600Hz, 2610Hz, 2620Hz, 2630Hz, 2640Hz, 2650Hz, 2660Hz, 2670Hz, 2680Hz, 2690Hz, 2700Hz, 2710Hz, 2720Hz, 2730Hz, 2740Hz, 2750Hz, 2760Hz, 2770Hz, 2780Hz, 2790Hz, 2800Hz, 2810Hz, 2820Hz, 2830Hz, 2840Hz, 2850Hz, 2860Hz, 2870Hz, 2880Hz, 2890Hz, 2900Hz, 2910Hz, 2920Hz, 2930Hz, 2940Hz, 2950Hz, 2960Hz, 2970Hz, 2980Hz, 2990Hz, 3000Hz, 3010Hz, 3020Hz, 3030Hz, 3040Hz, 3050Hz, 3060Hz, 3070Hz, 3080Hz, 3090Hz, 3100Hz, 3110Hz, 3120Hz, 3130Hz, 3140Hz, 3150Hz, 3160Hz, 3170Hz, 3180Hz, 3190Hz, 3200Hz, 3210Hz, 3220Hz, 3230Hz, 3240Hz, 3250Hz, 3260Hz, 3270Hz, 3280Hz, 3290Hz, 3300Hz, 3310Hz, 3320Hz, 3330Hz, 3340Hz, 3350Hz, 3360Hz, 3370Hz, 3380Hz, 3390Hz, 3400Hz, 3410Hz, 3420Hz, 3430Hz, 3440Hz, 3450Hz, 3460Hz, 3470Hz, 3480Hz, 3490Hz, 3500Hz, 3510Hz, 3520Hz, 3530Hz, 3540Hz, 3550Hz, 3560Hz, 3570Hz, 3580Hz, 3590Hz, 3600Hz, 3610Hz, 3620Hz, 3630Hz, 3640Hz, 3650Hz, 3660Hz, 3670Hz, 3680Hz, 3690Hz, 3700Hz, 3710Hz, 3720Hz, 3730Hz, 3740Hz, 3750Hz, 3760Hz, 3770Hz, 3780Hz, 3790Hz, 3800Hz, 3810Hz, 3820Hz, 3830Hz, 3840Hz, 3850Hz, 3860Hz, 3870Hz, 3880Hz, 3890Hz, 3900Hz, 3910Hz, 3920Hz, 3930Hz, 3940Hz, 3950Hz, 3960Hz, 3970Hz, 3980Hz, 3990Hz, 4000Hz, 4010Hz, 4020Hz, 4030Hz, 4040Hz, 4050Hz, 4060Hz, 4070Hz, 4080Hz, 4090Hz, 4100Hz, 4110Hz, 4120Hz, 4130Hz, 4140Hz, 4150Hz, 4160Hz, 4170Hz, 4180Hz, 4190Hz, 4200Hz, 4210Hz, 4220Hz, 4230Hz, 4240Hz, 4250Hz, 4260Hz, 4270Hz, 4280Hz, 4290Hz, 4300Hz, 4310Hz, 4320Hz, 4330Hz, 4340Hz, 4350Hz, 4360Hz, 4370Hz, 4380Hz, 4390Hz, 4400Hz, 4410Hz, 4420Hz, 4430Hz, 4440Hz, 4450Hz, 4460Hz, 4470Hz, 4480Hz, 4490Hz, 4500Hz, 4510Hz, 4520Hz, 4530Hz, 4540Hz, 4550Hz, 4560Hz, 4570Hz, 4580Hz, 4590Hz, 4600Hz, 4610Hz, 4620Hz, 4630Hz, 4640Hz, 4650Hz, 4660Hz, 4670Hz, 4680Hz, 4690Hz, 4700Hz, 4710Hz, 4720Hz, 4730Hz, 4740Hz, 4750Hz, 4760Hz, 4770Hz, 4780Hz, 4790Hz, 4800Hz, 4810Hz, 4820Hz, 4830Hz, 4840Hz, 4850Hz, 4860Hz, 4870Hz, 4880Hz, 4890Hz, 4900Hz, 4910Hz, 4920Hz, 4930Hz, 4940Hz, 4950Hz, 4960Hz, 4970Hz, 4980Hz, 4990Hz, 5000Hz, 5010Hz, 5020Hz, 5030Hz, 5040Hz, 5050Hz, 5060Hz, 5070Hz, 5080Hz, 5090Hz, 5100Hz, 5110Hz, 5120Hz, 5130Hz, 5140Hz, 5150Hz, 5160Hz, 5170Hz, 5180Hz, 5190Hz, 5200Hz, 5210Hz, 5220Hz, 5230Hz, 5240Hz, 5250Hz, 5260Hz, 5270Hz, 5280Hz, 5290Hz, 5300Hz, 5310Hz, 5320Hz, 5330Hz, 5340Hz, 5350Hz, 5360Hz, 5370Hz, 5380Hz, 5390Hz, 5400Hz, 5410Hz, 54

