

Access Point (AP) Deployment Guide

Introduction

AX83H is an enterprise portable Wi-Fi IP color screen phone that caters to the communication needs of mobile offices. It finds extensive applications in small and medium-sized enterprises, offices, warehouses, supermarkets, hotels, and other mobile office scenarios. Featuring a built-in Bluetooth 5.0 module and a dual-band 2.4G/5G Wi-Fi 6 module, coupled with advanced seamless roaming technology, it enables you to keep pace with the ever-evolving trends in the wireless era and stay ahead of the game.

With the continuous expansion of Wi-Fi network coverage, wireless access points (AP) are now widely employed in small and medium-sized enterprises, multi-story offices, commercial establishments, and branch offices to provide seamless Wi-Fi access and mobile solutions. This guide offers comprehensive insights and step-by-step instructions for deploying an Access Point (AP) environment.

Access Point Feature Requirements

- 1. Embedded Wireless Controller
- 2. Wi-Fi roaming Protocol Suport 802.11k, 802.11v, 802.11r
- 3. Wi-Fi Protocol Support 802.11ac, 802.11ax, 802.11n
- 4. Interfaces: At least 1x 10/100/1000 Base-T (Ethernet) Uplink Interface, support POE
- 5. Radio Support: 2.4GHz,5GHz

Recommended AP List

The following table lists the APs that have been tested by Yealink and have good compatibility with AX83H for reference.

Cisco Wireless Access Points

Feature	Cisco Catalyst 9105i Access Point	Cisco Catalyst 9115 Access Point
Embedded Wireless Controller	\[$\sqrt{}$
Wi-Fi roaming support 802.11k, 802.11v,802.11r	$\sqrt{}$	$\sqrt{}$
Wi-Fi Protocol Support 802.11ac, 802.11ax, 802.11n	$\sqrt{}$	$\sqrt{}$
Interfaces: At least 1 * 10/100/1000 Base-T (Ethernet) Uplink Interface, support POE	$\sqrt{}$	$\sqrt{}$



☆ TIP

AC Controller: Not required (one AC can be reused)

HPE (Aruba) Wireless Access Points

Feature	503 Series	610 Series
Embedded Wireless Controller	×	×
Wi-Fi roaming support 802.11k, 802.11v, 802.11r	√	$\sqrt{}$
Wi-Fi Protocol Support 802.11ac, 802.11ax, 802.11n	√	$\sqrt{}$
Interfaces: At least 1 * 10/100/1000 Base-T (Ethernet) Uplink Interface, support POE	$\sqrt{}$	$\sqrt{}$
Radio Support: 2.4GHz, 5GHz	√	$\sqrt{}$

☆ TIP

AC Controller: HPE Aruba Networking 7005 (it is recommended that at least 2 AP management licenses be configured).

Rucks Wireless Access Points

Feature	R350	H350
Embedded Wireless Controller	×	×
Wi-Fi roaming support 802.11k, 802.11v, 802.11r	√	$\sqrt{}$
Wi-Fi Protocol Support 802.11ac, 802.11ax, 802.11n	√	$\sqrt{}$
Interfaces: At least 1 * 10/100/1000 Base-T (Ethernet) Uplink Interface, support POE	√	$\sqrt{}$
Radio Support: 2.4GHz, 5GHz	√	$\sqrt{}$

☆ TIP

AC Controller: SmartZone 100 (it is recommended that at least 2 AP management licenses be configured).

Deployment Guidance

AP Deployment Requirements

When deploying a Wi-Fi network with multiple APs for AX83H roaming, follow these guidelines:



- 1. Make sure the AP is properly powered on and connected to your network.
- 2. Connect your PC to the same network as the AP. This PC is used to configure the AP and other necessary devices through the Web GUI.
- 3. Access the AP using the PC's Web GUI. Configure the AP for settings.
- 4. Set the same SSID for all APs. SSID is case-sensitive.
- 5. Make sure the IP addresses assigned to the APs belong to the same network segment and the same VLAN.

Conventional Obstacle Penetration Loss Comparison Table

Certain building structures and obstacles can directly interfere with or attenuate AP signals. The signal attenuation after penetrating different obstacles can be found in the following table:

Classic Obstacle	Thickness (mm)	2.4G Signal Attenuation (dB)	5G Signal Attenuation (dB)
Regular Brick Wall	120	10	20
Thickened Brick Wall	240	15	25
Concrete	254	25	30
Asbestos	8	3	4
Foam Board	8	3	4
Hollow Wood	20	2	3
Regular Wooden Door	40	3	4
Solid Wood Door	40	10	15
Regular Glass	8	4	7
Thickened Glass	12	8	10
Bulletproof Glass	30	25	35
Load-bearing Column	500	25	30
Roller Shutter Door	10	15	20
Steel Plate	80	30	35
Elevator	80	30	35

Recommended Overlap Range for AP Signal Coverage


During the deployment phase, it is essential to carefully consider the cell edge coverage for each access point (AP). It is recommended to design the cell edge of each AP with a signal strength of -67dBm to ensure optimal performance. Moreover, it is advised to maintain a 20% - 30% overlap between adjacent APs at this signal level. Failure to meet these requirements may lead to potential packet loss or blind areas at the cell edge, hindering the seamless switchover process for AX83H devices. To ensure uninterrupted roaming capabilities, it is highly recommended that AX83H devices consistently receive an RSSI of -67dBm or higher from the associated access point.




AP Placement

The placement of APs is crucial in the construction of wireless networks. Through a well-designed AP layout, signal interference can be avoided, signal attenuation can be minimized, and better network performance and user experience can be achieved.

Improper placement of APs: Signals pass through multiple walls



Reasonable placement of APs: Signals pass through a single wall



(i) IMPORTANT

- 1. Minimize the number of obstacles that the signal passes through.
- 2. Ensure that the AP is facing the target coverage area and is placed away from interference sources.
- 3. For scenarios that require a PoE power supply, the distance between the AP placement location and the weak current room (PoE power supply end) must be considered. The distance is recommended to be less than 100 meters.

Important WI-FI Parameters on APs

There are several crucial parameters in Wi-Fi configuration for APs. Proper configuration of these parameters will enhance the roaming performance of AX83H.

Parameter	Description
Beacon Interval	The beacon interval defines the frequency at which the AP sends 802.11 beacon management frames. The default value is typically set to 100ms. It is recommended to keep the default value on the AP.



	This is the Delivery Traffic Indication Message (DTIM) period within the beacon.
DTIM	
Unicast Mode and Multicast Mode	In unicast mode, the controller unicasts each multicast data packet to every associated access point. In multicast mode, the controller sends multicast data packets to the CAPWAP multicast group. This method reduces the overhead on the controller's processor and offloads the packet replication work to your network. It is recommended that unicast mode be used to ensure call quality.
	WMM is a wireless QoS protocol and a subset of the 802.11e protocol used to ensure high- priority packets are sent first, thus guaranteeing quality of service for applications such as voice and video.
WMM (Wi-Fi Multimedia)	 QoS for SIP Layer 3 Defines the QoS parameters for Layer 3 packets of SIP messages in decimal format. This value is used for IP precedence, Diff-Serv, or MPLS. The default setting is 26, equivalent to the DSCP name constant CS6. QoS for Audio Layer 3 Defines the QoS parameters for Layer 3 packets of RTP messages in decimal format. This value is used for IP precedence, Diff-Serv, or MPLS. The default setting is 46, equivalent to the DSCP name constant CS6.
Band Steering	Dual-band operation with band steering detects clients capable of operating at 5 GHz frequency and guides them to that frequency, making the more congested 2.4 GHz band available for traditional clients. This helps improve the end-user experience by reducing channel utilization, especially in high-density environments. It is recommended to enable band steering on the AP, which means that by default, the 5 GHz band should be used (if the 5 GHz signal is weak, users can switch to 2.4 GHz).

For the above important parameters, the following sections provide configuration methods for different vendor APs for reference.

Cisco Embedded Wireless Controller


☆ TIP

If you need more detailed information, you can visit the Cisco Support website.


1. Log in to the web user interface.




2. Switch the configuration mode to the **Expert** mode.



3. Add new WLAN. Go to Configuration > Tags & Profiles > Wlans > Add.











4. Set the authentication method and fast roaming 802.11r.






5. Set the fast roaming 802.11k, 802.11v, and Wi-Fi 6.





6. After saving and submitting, edit and assign the policy profile again.




Aruba

☆ TIP


If you need more detailed information, you can visit the Aruba Support website.

- 1. Log in to the web user interface.
- 2. Go to **Dashboard** > **Configuration** > **WLANs** > to add a new WLAN.


















3. 5G cannot be turned off individually, but 2.4G can be enabled individually when **Allowed band** is set to **a** or **g**.






4. Set the 802.11R fast roaming feature profile.




5. In SSID, select Apply 802.11r Profile.





6. Save.



Ruckus


♥ TIP

If you need more detailed information, you can visit the Ruckus Support website.

(i) NOTE


802.11v is enabled by default and cannot be configured in the GUI or the CLI.


1. Log in to the web user interface.





2. Add a new WLAN. We will add a 2.44GHZ WLAN as an example.

















3. Add the newly created WLAN ruckus 2.4g to the WLAN group 2.4g.




编辑 WLAN 组





4. Access Point Configuration.





5. The current configuration is that the WLAN group **2.4g** uses 2.4GHZ, and the WLAN group **5g** uses 5GHZ. If you need WLAN to support dual-band, set the WLAN group in the Radio settings to **Default**. The WLAN in the **Default **group can use dual-band transmission signals.

