

X-11 PRO SCOOTER

NBPROCSCOTA

SAFETY & WARNINGS

Ensure to read and follow all the warnings and instructions written in this user guide before using the scooter.

- Ensure all components listed in this user guide are included in the package.
- Always wear protective equipment when riding the scooter (for example, helmet and protective pads) to reduce the risk of injury.
- Ensure the correct size helmet is worn to provide the highest level of protection.
- The scooter is for children above 8 years old.
- Maximum load: 100 kgs. Any load heavier will strain the scooter and may result in accident or personal injury.
- Maximum of one rider at any time. Never operate the scooter with two or more people.
- Never leave children unsupervised while they are riding the scooter.
- The scooter is made for use on clear, dry, flat surfaces. Use outside of these environments may lead to accidents or personal injury.
- Do not ride the scooter on slippery surfaces.
- Do not ride the scooter on stairs as it may overturn, causing serious injury.
- The scooter is not suitable for extreme sports.
- Avoid riding the scooter at night or during poor visibility.
- Do not ride the scooter under bad weather conditions (for example, in strong winds, heavy rain, or snow).
- If road conditions become poor while riding the scooter, stop riding to avoid risk of injury.
- This scooter, under no circumstances, should be ridden on a public highway, busy road, or any place with incoming traffic.
- Keep fingers and toes away from all moving parts of the scooter.
- The scooter's braking mechanism will get hot with continuous use. Do not touch the brake after operation.
- Obey all traffic and pedestrian laws and regulations.

Children's Safety

- Always check for any loose screws, nuts, and bolts before letting children ride the scooter.
- Ensure children wear all safety equipment to avoid risk of injuries (for example, helmet, gloves, knee pads, elbow pads and wrist guards).
- When riding the scooter on the pavement, ensure children keep a safe distance from incoming pedestrians and pets to avoid potential injuries.


Scooter Safety

- Always keep hands on the handlebars to ensure complete control while riding the scooter.
- If riding under poor lighting conditions, it is recommended to wear light reflective clothing to alert others around the rider of their presence.
- Take care when riding on wet pavements. The wheels will have reduced traction and capacity to brake quickly.
- When riding on pavement, avoid wearing anything that may obstruct visibility to incoming pedestrians and pets.
- Avoid uneven pavements or potholes, as this may cause the rider to lose control of the scooter.
- Avoid wearing loose clothing, scarves, or anything that hangs as this may get caught in the scooter's wheels, leading to injury.
- Avoid using earphones/headphones, as this may restrict hearing and the ability to detect potential obstructions around the rider.
- Always wear shoes when riding the scooter.
- When riding near parked vehicles, stay alert for car doors being opened.

COMPONENTS



A Handlebars and stem



B Scooter deck and wheels



C Allen key

ASSEMBLY

Step 1:

Slide the handlebars and stem (A) over the threaded locking section on the top of the scooter deck (B).

Step 2:

Ensure the arrow on the fork of the scooter deck (B) is facing forward and the handlebars sweep backwards.

Step 3:


Tighten the bolts evenly and tightly using the Allen key (C) provided. Ensure the wheels are facing forward while the handlebars are held facing straight.

Step 4:

The scooter is now assembled. Perform a final check to ensure all screws and fittings are secure and that all locking devices are engaged.

Note:

Bolts that may seem fully tightened may loosen after the tightening other bolts. Ensure all bolts are tightened properly before use.



OPERATION

Step 1:

With your hands, hold both handgrips firmly and put one foot towards the front of the scooter deck.

Step 2:

With the other foot, push off the ground to propel the scooter forward. Lift that foot onto the scooter deck behind the front foot when desired speed has been reached.

Step 3:

Step on the brake at the back of the scooter deck with the rear foot, then gently put your rear foot the ground to come to complete stop.

Note:

Please keep your feet on the scooter's plate and never ride with one hand.

CLEANING & CARE

Cleaning should be done periodically.

- Clean the scooter by wiping with a damp cloth and mild detergent, then leave it to dry to avoid damage.
- Lubricate the scooter with oil from time to time to ensure a smooth ride.
- Check and tighten all the self-locking nuts and fixings periodically, as these may loosen over time.
- Do not store the scooter under direct sunlight to avoid damage.
- Replace bearings when worn.

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com