

D-Link®

Wi-Fi 7 BE3600 Mesh
Gigabit Wireless Router
DIR-BE3602

QUICK INSTALLATION GUIDE

Packing List:
The Device
Quick Installation Guide
Power Adapter
Ethernet Cable
Warranty Card

If any of these items are missing from your packaging,
contact your reseller.

Schematic Diagram of Router Connection

Connect Your Device

Connect via Wi-Fi

Connect your device to the Router's Wi-Fi.



The default Wi-Fi name and password are printed on the label on the bottom of the device.



Or

Connect via a Network Cable

Connect your PC to the Router's LAN1, LAN2, LAN3 or LAN4 port using a network cable.



Connect to ISP Connection Box

Using the included Ethernet cable, connect the Router's WAN port to the Ethernet port on your NBN or UFB Connection Box.

OPTION 1 - D-LINK WI-FI APP SETUP

Step 1. Install the D-Link Wi-Fi Assist App.



Step 2. Connect your phone to your Router's Wi-Fi. The Wi-Fi Name and password are printed on the label at the back of the Router.

Step 3. Open the D-Link Wi-Fi Assist app and tap on the Router icon. Access the setup options by tapping on the Settings icon.

Step 4. Tap on Quick Setup.



Select your Internet Connection type and enter the required details.



Enter your desired Wi-Fi Name and assign a secure password to your Wi-Fi.



After completing the Quick Setup, the Router will restart. Reconnect to your Router's Wi-Fi using the new name and password.

OPTION 2 - WEB BROWSER SETUP

You can also use a Web browser on your computer or on your phone to set up the Router.

Step 1. Connect your computer or phone to your Router's Wi-Fi. The Wi-Fi Name and Password are printed on the label at the back of the Router. Alternatively you can connect you computer to one of the Router's LAN ports using a network cable.

Step 2. Open your Web browser and enter <http://192.168.0.1> in the address bar. You will be prompted to enter the Router's admin password – the factory password is printed on the label at the back of the Router.



Step 3. The Quick Setup Wizard will take you through the initial Router set up. Select your Internet Connection type and enter the required details.



Enter your desired Wi-Fi Name and assign a secure password to your Wi-Fi.



After completing the Quick Setup Wizard, the Router will restart. Reconnect to your Router's Wi-Fi using the new name and password.

TECHNICAL SUPPORT

For configuration guides and the latest software updates, please visit support.dlink.com.au

You can contact our **Technical Support Team**:

- Via website: <https://www.dlink.com.au/contactus>
- Via Live Chat: <https://support.dlink.com.au/>
- Via phone (24x7):

Australia: 1300 700 100
New Zealand: 0800 900 900

D-Link®