

USER MANUAL

SMART WATCH LW41

If you have any questions during the use, please contact us at first, our professional customer service team will give you a satisfactory solution within 24 hours.

If you are looking for a more detailed and convenient way to understand this smartwatch, you can study it on our user manual, Amazon page Customer Questions & Answers, Videos, Onwear Pro APP FAQs, and the below QR code of the video tutorial.

If you still can't solve your issue, welcome to contact the below customer service email.



English Video Tutorial



Download "Onwear Pro"
App (Main)



Download "Onwear Pro"
App (Spare)

Customer Service:

smartwatch_service@outlook.com

EN 01 | ES 16

Product Introduction



Button


*Long press to power on/off the watch

*Short press to return to the home screen



Note:

When you get the product for the first time, please fully charge it to activate the watch.



Magnetic Charging Cable

Accessories List


Accessories List	
Smartwatch	x1
USB Magnetic Charging Cable	x1
User Manual	x1
Connect Bluetooth Guide	x1
Warranty card	x1

Wearing



For daily wearing, please wear the watch on your wrist about a finger width from your wrist bone and adjust the strap to a comfortable size.

Tips: If the watch is worn too loosely, the data collected by the heart rate sensor may be affected.



Connection



Scan the QR code to install the "OnWear Pro" APP


1. Search and download the "OnWear Pro" APP from the Apple Store or Google Play. You can also scan the below QR code to download and install it.

- 02 -

2. Open the "OnWear Pro" APP; register an account and log in. (Please set the basic information according to the actual situation to avoid affecting the measurement accuracy).

3. Open the phone's Bluetooth and back to "OnWear Pro" APP to select the watch on [Me]>>[Connect Device] to establish a connection.

(Add device: search for devices and select "LW41 XXX" to bind, or scan the QR code in the [Settings] of the watch to bind).



- 03 -

Tips:

1. In the process of pairing, please check if the Bluetooth of the mobile phone is turned on to ensure that the watch can be connected to the mobile phone normally.
2. If the device cannot be found in the process of adding the device, or the device cannot be connected during use, please reset it on the operation interface of the watch([Settings]>>[Reset]) and then add the device again.
3. If the watch still cannot be found, please exit and re-open the APP. The connection status of the watch is shown in the figure below.



Connected state



Unconnected state

Operation

1. **Open the control panel:** Swipe down the home screen on the watch from the top.



[Do No Disturb Mode]: When enabled, the watch will no longer notify and vibrate, except for alarm clock.



[Brightness Adjustment]: Click the icon to adjust the screen brightness. 5 levels of adjustable brightness.



[Power Save Mode]: When enabled, the watch will disconnect Bluetooth and reduce the screen brightness.



[Raise wrist to brighten the screen]: When enabled, the screen will brighten when you raise your wrist.




[Flashlight]: Click to turn on the flashlight function.



[Settings]: Click to get more settings, includes Watch faces, Screen time, Menu style, Vibration intensity, language, Fit Notifications, Battery, QR code, Power off, Reset, About.

2. **Message notification:** Swipe from bottom to top on the home screen.

The watch has a message reminder function, which can synchronize and push the call and message notification of the mobile phone after connecting with the phone successfully. (Note: The display app should be compatible with messages from the social software. Can't answer or make calls/Reply or send texts, messages)



3. **Enter the main menu:** Swipe right on the home screen of the watch (Note: swipe right on other interfaces to return to the previous interfaces)

4. **Quick access to activity data, sleep, heart rate, weather, music control interface:** Swipe left on the home screen of the watch

5. **Quickly change dials:** Press and hold the home screen for 3 seconds, then you can swipe left or right to select the watch dial.

Main Functions



[Activity data]: Record the daily steps, distance and calories in detail.



[Heart rate]: Monitoring your heart rate for 24h (Setting in the app can automatically detect every 10 minutes), you can view the historical heart rate data.



[SpO2]: Turn on the blood oxygen monitoring and wait for 30-60 seconds to complete the measurement. During measurement, the red light on the bottom is on.



[Sleep]: Record the sleep time on the watch (View sleep status in detail in the APP).



[Workout]: There are 16 build-in sports mode on the watch: Outdoor Running / Outdoor Walk / Outdoor Cycling / Indoor Running / Strength Training / Football / Basketball / Cricket / Badminton / Jump Rope / Rowing Machine / Elliptical Trainer / Swimming / Yoga / Mountaineering / Free Training.
On the app, there is 100+ exercise push, you can choose to sync to the smartwatch. (One time can only choose to sync one kind of sports mode).

- 06 -



[Workout records]: Record recent exercise data.



[Weather]: After the connection with the mobile phone is successful, authorized to run the APP to obtain your location and push the local weather forecast (the weather is updated every hour).



[Music]: The watch can control the music played by the phone, play/ pause/next/ previous, and increase/ decrease the volume (Note: Compatible with the music player that comes with the phone, not compatible with third-party music players.)



[Camera]: After connecting with your phone successfully, click this to quickly access the camera to remote take a photo.



[Female health]: There is a menstrual period reminder for female users (Need to be set on the APP).



[Setting]: Watch Faces, Screen time, Menu Style, Vibration Intensity, Language, Fit Notifications, Battery, QR code, Power off, Reset and About.

- 07 -

Charging

1. Place the watch on the charger to make the charging contact on the back of the watch fully fit with the metal contact on the charger.

2. Connect the charging cable to the standard charger purchased from the authorized suppliers with an output voltage of 5V and an output current of 1A.

If the watch cannot be powered on without using it for a long time, please wipe the charging contacts of the charging cable to remove residual sweat or moisture.

Note: (If you don't use the watch often, please charge it once a month)

Basic Parameters

Display	1.7 inch Full Touch screen
Wireless	BT5.0
Shell material	ABS+PC
Strap material	Silicone Rubber
Charging mode	Magnetic charging
Compatible systems	Android 5.0 or above; IOS 10.0 or above
Strap Width	0.74inches(wristband mounting pins distance)
Battery and endurance	260mAH polymer lithium battery
	Standby time 10-15 days
Waterproof	5ATM(50m) waterproof (NOT support using it under a hot shower, diving or sauna)

- 08 -

FAQ

①What to do if Bluetooth cannot be connected?

1. Please check whether the operating system of the mobile phone is Android 5.0/ iOS 10.0 or above. You need to download/ registry Onwear Pro APP, then log in, connect it from App, and can not connect the watch directly from the Phone's Bluetooth page. For more details please refer to our video/text tutorial.

2. In order to avoid too many Bluetooth devices disturbing, pls ignore other Bluetooth devices on phone and better find a place without too many Bluetooth devices to connect it. Please check whether the watch is connected to another mobile phone, if so, please unbind it first.

3. If still can not work, please reset watch and re-install onwear pro app, and re-try the connect steps.

②What to do if the watch can not get the message notification?

1. Make sure that the Bluetooth on your mobile phone is turned on, and check whether your phone remains connected to the watch.

2. Check whether you authorize Onwear pro APP to run in the background of your mobile phone (Can not kill the app)

3. Check whether the notification switches of the corresponding application in Onwear pro APP are turned on;

4. Check whether the notification bar of the mobile phone can pop up the application notification or SMS you need. If not, please go to the system settings to enable the permission of

- 09 -

pop-up APP messages in the notification bar. (Need to allow APP notifications).

5. If the above operations cannot solve the problem, please reset the watch and restart the phone, then connect to test again.

6. Check whether the watch is in Do-not-disturb mode. (When the Do Not Disturb mode is turned on, the message reminder and the wrist sensor will not work).




Enable the
Do-not-disturb mode



Disable the
Do-not-disturb mode


③How to choose from 100+ sports modes and synchronize the Exercise Push to the watch?

[Onwear Pro APP] →[Me] →[More Sports] →Choose One to Synchronize to watch(One time can only choose to sync one kind of sports mode) →After synchronizing, this sports mode will be shown on the [workout] function of the watch.



④How to view the watch version, upgrade, change the unit Imperial or Metric,temperature unit, time format, factory reset, and unbind the device?

Select and click Options as shown below



⑤Why can't the watch Stay Connected to my phone?

1. Watch and Phone pairing is through Bluetooth transmission technology, the maximum Bluetooth range is 8-10 meters, if there have metals or wall blocks in the middle, the limited range will be shorter. Out of this range, the watch will disconnect from the phone. Need to wait for it to automatically reconnect or manually connect it.

2. Please make sure to keep Onwear Pro running in the background process and the phone's Bluetooth is always on.

⑥ Why does the APP "Onwear Pro" need permission from your location?

The app needs permission to access your location to get the weather information for each hour.

⑦ Why is the steps/distance track not so accurate?

The G-Sensor Algorithmic system run depending on personal data, age, height, weight, and gender, so please fill in your real correct body information at App. And each brand watch's arithmetic has differences, there is no comparability.

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Safety Instructions

Please consult your doctor before starting a new exercise program. Despite its ability to track your heart rate, this smartwatch is only intended to help people live healthier lives and should not in any case be used for any medical purpose. Remember to consult your doctor before starting any exercise or diet program.

- Do not place the product and its accessories at extreme temperatures, otherwise it may cause hazards such as product failure, fire, or explosion.
- Protect the product from strong impacts or jolts, so as not to damage the product and its accessories, thus avoiding product failures.
- Do not disassemble or modify the product and its accessories by yourself. Contact us for after-sales service when the product fails



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycling valuable raw materials and the treatment of toxic substances.

If you experience discomfort or skin irritation when wearing your smartwatch, then we recommend you try cleaning your device. Sometimes residue or foreign materials build up around your device and may aggravate your skin. It's also possible that you are not wearing the watch correctly. We recommend making sure to clean and adjust your watch regularly for a more comfortable fit.

- If you experience skin irritation when wearing your watch, please refrain from wearing it and wait two to three days to see if your symptoms ease. If symptoms persist or worsen, please consult a physician.
- If you have eczema, allergies, or asthma, you may be more likely to experience skin irritation or allergy from a wearable device.
- Risk of explosion if the battery is replaced by an incorrect type, disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.