


# RU-DD05

## Beverage Refrigerator

### User Manual

SKU:BR005-150SI-USEH





# THANK YOU

for purchasing the Euhomy beverage refrigerator



Scan the QR code using  
a mobile device

ACTIVATE YOUR WARRANTY

<https://euhomy.com/pages/activate-warranty>



## RECORD THIS INFORMATION

Model Number RU-DD05

Serial Number \_\_\_\_\_

Date of Purchase \_\_\_\_\_

Store of Purchase \_\_\_\_\_  
(Keep receipt)

### TIP

Check the back or side of the  
machine for the serial number  
on the nameplate.

If you can't find it, don't worry—it won't  
affect your warranty registration.

## CUSTOMER SERVICE



1-833-362-2655



support@euhomy.com



<https://euhomy.com>

## JOIN US



euhomyofficial



EuhomyOfficial



Euhomy\_global



euhomy



SCAN HERE to share tips, get  
support, and connect with fellow  
enthusiasts!

# Contents

Important Safety Instructions	02
Key Components and Structure	04
Installation Instructions	05
Control Panel And Display Overview	07
Cleaning And Maintenance	08
FAQs	10
Troubleshooting	11
Specifications	14
Warranty Policy	15
Return Policy	16

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, it is essential to follow basic safety precautions to minimize the risk of fire, electric shock, and injury to persons or property. Read all instructions before using the appliance.

## **Risk of Fire or Explosion—Flammable Refrigerant Used**

**Risk of fire or explosion.** Flammable refrigerant used. Consult the repair manual or owner's guide before attempting to service this product. All safety precautions must be followed.

**Risk of fire or explosion.** Dispose of property in accordance with federal and local regulations. Flammable refrigerant used.

**Risk of fire or explosion.** These hazards can result due the puncture of refrigerant tubing. Follow handling instructions carefully. Flammable refrigerant used.

## **Child Safety**

1. Always supervise children around the appliance.
2. **NEVER** allow children to operate, play with, or climb inside the unit.
3. Before disposing of the unit, remove the drawers, latches, and locks to prevent child entrapment.

## **Installation & Placement**

4. Ensure the power plug is fully inserted into the wall outlet.
5. Plug the unit into a dedicated electrical outlet that matches the rating on the appliance label (115 AC, 60Hz, 10A).
6. Always use **two** people to move the appliance to avoid personal injury.

## Electrical Safety


7. Improper use of the grounded plug can result in electric shock.
8. Avoid damaging or rolling over the power cord when moving the unit.
9. If the power cord is damaged, it must be replaced by a qualified technician or service center.
10. **DO NOT** immerse the beverage refrigerator, plug, or cord in water or any other liquids.
11. **DO NOT** operate the refrigerator with wet hands or while standing on a wet surface.
12. **DO NOT** cut or remove the grounding prong from the power cord under any circumstances.
13. Always unplug the appliance before cleaning or servicing to avoid the risk of electric shock.
14. Replace any damaged power cords immediately.
15. **DO NOT** use a cord with visible cracks or wear.
16. **DO NOT** use an extension cord or adapter. If absolutely necessary, use only a UL-listed, 3-wire, grounded extension cord rated at minimum of 10A and 120V.

## Hazard Prevention & Disposal

17. **NEVER** use flammable liquids or cleaning agents to clean the appliance.
18. This appliance may require special disposal procedures. Contact local authorities for proper disposal methods.
19. **DO NOT** store or use gasoline or other flammable vapors and liquids near this or any other appliance, as the fumes may cause fire or explosion.

# KEY COMPONENTS AND STRUCTURE

- 1.Outer Shell
- 2.Refrigerated Drawers
- 3.Control Panel
- 4.Stainless Steel Handles
- 5.Air Vent
- 6.Leveling Legs



## Accessories

- 2 x Stainless Steel Handles
- 4 x Extra Leveling Legs
- 1 x User Manual

# INSTALLATION INSTRUCTIONS

## 1.Installing the Beverage Refrigerator

### Step 1: Preparing before First Use

1.Remove all packaging material. This includes the foam base and all adhesive tape holding the accessories inside and outside.

2.Check that all accessories are included. If anything is missing, contact our customer service. (email [support@euhomy.com](mailto:support@euhomy.com) or call us at +1-833-632-0897(US)).

### Step 2: Choosing a suitable position

1.This appliance is designed for both built-in and free-standing installation. Since the air vent of this beverage refrigerator is located at the front, leave a **25cm (10 inches)** clearance at the front and at least **5cm (2 inches)** on the top, sides, and back.

2.Place in a well-ventilated area with an ambient temperature between **10°C (50°F)** and **32°C (90°F)** and humidity below **60%**.

3.Ensure that the front of the refrigerator is completely unobstructed.

4.This unit must be installed in an area away from wind, rain, water spray, or drips.

5.Level the unit to ensure proper operation; multiple adjustments may be needed.

### Step 3: Allowing the unit to settle

Before plugging in the beverage refrigerator, let it stand upright for at least **24 hours** to let the refrigerant settle down.

### Step 4: Cleaning the beverage refrigerator

Clean the interior surface with lukewarm water using a soft cloth before plugging.

## 2.Installing Stainless Steel Handle

### Step 1:

Pull away the drawer gasket in the area where the handle is to be installed. (as in fig 3.2.1)

**Step 2:**

Align the handle with the pre-installed screws on the drawer frame. Use a Phillips screwdriver to tighten the screws until the handle is firmly secured against the frame. (as in fig 3.2.2)

**Step 3:**

Return the drawer gasket to its original position.

**Note:**

- 1.The gasket is easily removed by hand; no tools are necessary.
- 2.**DO NOT** over-tighten screws when installing the drawer handles.
- 3.Each drawer contains a movable grid organizer to keep your food and drinks neat and tidy. (as in fig 3.2.3)




fig 3.2.1




fig 3.2.2

- 1 Gasket
- 2 Screw
- 3 Phillips screwdriver
- 4 Handle





fig 3.2.3

# CONTROL PANEL AND DISPLAY OVERVIEW

1. After plugging the beverage refrigerator into a wall outlet, the refrigerator will turn on automatically, and the LCD screen will display the temperature inside the unit.
2. After setting your desired serving temperature, allow the refrigerator to cool down for **3 to 4 hours** before placing drinks in the beverage refrigerator.



	Press once to turn ON the cooler. Press and hold  about 3 seconds to turn OFF
	Press  to increase or press  to decrease the temperature in 1-degree increments between 3°C and 18°C or between 37°F and 65°F.
	Press to begin adjusting the temperature for the upper or lower zone.
	Toggles the temperature display between Celsius and Fahrenheit
	Press  once to turn the interior light ON or OFF.

## Recommended temperature settings

- Beverage: 3°C - 10°C (37°F - 50°F)
- Sparkling wines: 5°C - 8°C (41°F - 46°F)
- Dry/white wines: 9°C - 14°C (48°F - 57°F)
- Rose Wines 10°C - 11°C (50°F - 52°F)
- Red wines: 15°C - 18°C (59°F - 64°F)

# CLEANING AND MAINTENANCE

**Caution:** Unplug the beverage refrigerator before cleaning or performing maintenance.  
**Never** use harsh cleansers or scouring pads to clean any part of the beverage refrigerator.

## Cleaning the machine

1. Turn off the power, unplug the beverage refrigerator and remove all drinks.
2. Wash the inside surfaces with a solution of warm water and baking soda. The solution should be about two tablespoons of baking soda to one quart of water.
3. Wring excess water out of the sponge or cloth when cleaning the area near the controls, or any electrical parts.
4. Maintaining the cleanliness and suppleness of the gaskets is imperative to guarantee an effective seal. Adhere to the general guidelines to clean the drawer gaskets every three months. A light application of petroleum jelly on the hinge side of the gaskets will preserve their suppleness and ensure a secure seal.
5. Dry the whole unit thoroughly.

## Defrosting the machine

1. Turn off the machine, stop the compressor, and unplug the power cord to melt the frost layer.
2. Allow the frost to melt on its own, making sure that the internal drain is not blocked.
3. During this time, the melted frost will flow through the internal drain pipe into the water collection tray located to the **right** of the compressor. If the drip tray is too full, it will need to be emptied and cleaned manually.
4. Clean the interior with warm water and a soft cloth, wipe dry thoroughly, and reset the temperature and cool for **3-4** hours after power is restored.
5. Put the drinks back into the beverage refrigerator.

### **Note:**

**Never** use mechanical devices or methods not recommended by the manufacturer to accelerate the defrosting process.

## Moving the machine

- 1.Remove all items (e.g., bottles) from the refrigerator.
- 2.Securely tape down all loose components inside the unit.
- 3.Rotate the adjustable leveling leg upward toward the base to prevent damage.
- 4.Tape the drawer securely shut.
- 5.Ensure the beverage refrigerator remains upright and stable during transportation. Cover the exterior of the unit with a blanket or similar protective material.

## Power Interruptions

Most power failures are corrected within a few hours and should not affect the temperature of your beverage refrigerator. If the power is off for an extended period of time, proper steps should be taken to protect the contents.

## Saving energy tips

- 1.The beverage refrigerator should be located in the coolest area of the room.
- 2.Ensure that the beverage refrigerator is adequately ventilated. **Never** cover air vents.
- 3.Only open the refrigerator drawers for as long as necessary. Frequently opening the drawers will affect the internal temperature.

## FAQs

### Q: Why can't the refrigerator maintain a stable temperature?

A: Due to external factors such as the compressor cycle switch, frequent drawer openings, high ambient temperatures, or overloading, slight temperature fluctuations are normal. Please ensure good airflow around stored items and avoid overloading to maintain optimal performance. Minor temperature changes help sustain cooling efficiency.

### Q: What are the warranty specifications?

A: We provide a 12-month warranty and lifetime technical support for this refrigerator. For more information, please contact our customer service team.

### Q: What is the return and exchange policy for this product?

A: Our return and exchange policy for this product is designed to ensure your happiness. If there are any quality issues or damage, we will take full responsibility and provide a return label for your convenience. However, if you wish to return the product due to reasons such as no longer needing it or an incorrect purchase, and there are no quality issues, you will be responsible for covering the return shipping cost. For more detailed information or assistance, please don't hesitate to reach out to our customer service team.

For further support, feel free to reach out to the Euhomy support team!



1-833-362-2655(US)







support@euhomy.com



<https://euhomy.com>


# TROUBLESHOOTING

Problem	Possible Cause(s)	Solution(s)
<b>The beverage refrigerator does not run.</b>	The beverage refrigerator may not be plugged in, or the plug may be loose.	Ensure the refrigerator is plugged in and the power outlet has power.
	A house fuse has blown, or the circuit breaker is tripped.	Replace the broken fuse or reset the circuit breaker.
	The beverage refrigerator is turned off.	Press  to turn on the refrigerator.
<b>The beverage refrigerator is not cold enough.</b>	Frequent drawer openings or incomplete drawer closures.	Close the drawers tightly and <b>DO NOT</b> open the drawers too frequently or for an extended period.
	Temperature setting is not suitable.	Adjust the temperature control to a cooler setting.
	The drawers do not be closed completely.	Ensure the drawers are closed completely.
	External environment may require a higher setting.	Set to colder setting. Allow several hours for the temperature to stabilize.
	The beverage refrigerator has recently been disconnected for a period of time.	It takes <b>3-4</b> hours for the refrigerator to cool down completely.
<b>The compressor turns on and off frequently.</b>	The room temperature is hotter than normal.	It's normal for the beverage refrigerator to work harder under these conditions.
	A large amount of content has been added to the refrigerator.	A large amount of content causes the beverage refrigerator to run more often until the desired temperature is reached.
	Prolonged or frequent drawer openings.	Open the drawers less often.
	The temperature has not been set correctly.	Press either  or  to check the set temperature, and adjust it accordingly.
	The drawers are not closed completely.	Close the drawers to ensure a proper seal.

Problem	Possible Cause	Solution
	Not plugged in.	Plug the refrigerator in.
<b>The light does not work.</b>	The circuit breaker tripped, or a fuse blew.	Check the breaker and/or fuses.
	The light button is "off".	Press  to turn the light ON.
	The refrigerator is not leveled.	Ensure the refrigerator is level.
<b>Vibrations/Unusual noises.</b>	The bottles are vibrating.	Ensure the bottles do not touch each other.
	There is an object under the refrigerator.	Remove the object under the refrigerator.
	The refrigerator is not level.	Level the refrigerator.
<b>The beverage refrigerator seems to make too much noise.</b>	Normal noise from the flow of the refrigerant.	The rattling noise may be caused by the flow of refrigerant, which is a normal occurrence. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your refrigerator. Contraction and expansion of the inside walls may cause popping and crackling noises.
	The refrigerator is not level.	Level the refrigerator.
<b>The drawers will not close completely.</b>	The drawers are dirty.	Clean the drawers.
	High humidity has caused this to occur.	This is normal during periods of high humidity. Lower the room humidity
<b>Moisture build-up on the interior or exterior of the beverage refrigerator.</b>	Prolonged or frequent drawer openings.	Open the drawers less often.
	The drawers do not seal completely.	Check drawers for proper seal.
	This is normal in a high-temperature environment.	Move the refrigerator to a cooler location and avoid placing it in direct sunlight or near heat sources.

Problem	Possible Cause	Solution
<b>Error Code: E1-E2-E3-E4-E7-E8</b>	A sensor has failed	Contact customer service.
<b>The beverage refrigerator was damaged upon receipt</b>	It may have been caused by bumps during transport.	Please kindly contact support@euhomy.com
<b>The beverage refrigerator arrived missing legs or other parts.</b>	The unit comes with four legs, plus four extra legs as spares, together with the manual. The handles, screws, legs, and other accessories are located inside the refrigerator. Please check inside for these accessories.	If you still can't find them, feel free to contact our support team at support@euhomy.com. They will respond within 24 hours on business days.
<b>The beverage refrigerator was received with the outer box placed upside down.</b>	It may have been caused by the staff responsible for delivering the package accidentally making an error.	Please don't worry! Just be careful when opening the outer box to check for any damage. Once you have the refrigerator out, please let it sit for 24 hours before plugging it in. If you encounter any issues, please don't hesitate to contact our customer service team at your convenience. We're here to help!

# SPECIFICATIONS



BR005-150 Beverage Refrigerator	
SKU	BR005-150SI-USEH
MODEL	RU-DD05
VOLTAGE	115V~60HZ
RATED CURRENT	1.5A
REFRIGERANT	R600a, 1.1Oz/30g
FOAMING	CYCLOPENTANE
DIMENSIONS(W×D×H)	23.4*24.4*34.5 inches
NET WEIGHT	92.6lbs

# WARRANTY POLICY

Euhomy is dedicated to delivering top-notch products and outstanding customer service. We back our products 100% and are here to support you every step of the way.

To activate your warranty, please visit <https://euhomy.com>

To request customer service, feel free to contact us anytime!

For further support, feel free to reach out to the Euhomy support team!



1-833-362-2655(US)



[support@euhomy.com](mailto:support@euhomy.com)



<https://euhomy.com>

***Business Time: 9AM - 6PM ET, Mon to Fri,***

## Euhomy 1-Year Limited Warranty

The One-Year (1) Limited Warranty is valid for purchases from this website or official Euhomy purchase channels such as Amazon, TikTok, and Walmart. It covers the original owner and product only and isn't transferable. For purchases made through unauthorized resellers, we recommend you contact them directly.

Euhomy guarantees the unit is free of material and workmanship defects for one year from the purchase date, as long as it's used under normal household conditions and maintained per the User Manual. This is subject to certain conditions and exclusions as follows:

### What is covered?

If the original unit or non-wearable parts are found defective, as determined by Euhomy, we will arrange repair or replace it within one year from the purchase date. If you receive a replacement unit, the warranty lasts for the remainder of the original warranty.

## What is not covered?

- (a) Normal wear and tear on the unit or parts, as well as any parts lost or damaged due to human factors after delivery; replacement parts are available for purchase. Feel free to contact us using the methods provided below.
- (b) Damage from misuse, mishandling, accidents, or not following the operating instructions.
- (c) Damage caused by exposure to liquids other than water or foreign substances.
- (d) Repairs or modifications not performed by Euhomy.
- (e) Use in commercial settings or non-household environments (except for commercial models).

## How to get service?

If your appliance isn't working properly or if you need any assistance, we offer several ways for you to get in touch with us.

You can reach us by calling **+1-833-362-2655 (US)** or emailing **support@euhomy.com** directly. For specific product categories, we also offer potential upgrades to enhance your warranty to our VIP service.

Our phone lines are open from **Mon to Fri, 8 AM - 4 PM (PT)**, and we normally respond to emails and forms within **24 business** hours. To help us assist you better, we recommend that you register your product online at **+1-833-362-2655 (US)** and have the appliance with you when you call us. If you reach out via email, sometimes our emails might end up in your spam folder, so please check there to make sure you don't miss our response. The proof of purchase will be needed when you request a warranty service.

In addition to our one-year warranty, we offer lifetime technical support. After the warranty expires, you can arrange for service at an additional cost.

**Feel free to contact us anytime with any issues.**

# EUHOMY

# Live the *cool life*



[support@euhomy.com](mailto:support@euhomy.com)



<https://euhomy.com>



1-833-362-2655(US)