

MADGE TECH HiTemp140X2 Series High Temperature Dual Probe Data Logger Series User Guide

Contents

- [1 HiTemp140X2 Series High Temperature Dual Probe Data Logger Series](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
 - [3.1 Installation Guide](#)
 - [3.2 Device Operation](#)
 - [3.3 Documents / Resources](#)

HiTemp140X2 Series High Temperature Dual Probe Data Logger Series

Product Information

Product Name: HiTemp140X2 Series

Product Type: High Temperature Dual Probe Data Logger Series

Product Overview: The HiTemp140X2 Series of dual probe high temperature data loggers are comprised of a stainless steel data logger body and feature either two remote temperature probes or one ambient and one remote temperature probe combination. This data logger series offers extreme flexibility for high temperature monitoring applications. The dual probes of the HiTemp140X2 Series allow for simultaneous temperature monitoring and are ideal for applications such as oven mapping, surface temperature monitoring, autoclave validation, food processing, sterilization processes and much more.

Water Resistance: The HiTemp140X2 Series data loggers are rated IP68 and are fully submersible. They can be placed in environments up to 230 ft (70 m) of water.

Bend Radius: The bendable RTD probe on the HiTemp140X2 Series data loggers can be bent to a 0.25 inch bend radius. The probe should not be bent within 1 inch of either weld joint.

Temperature Channels: All HiTemp140X2 Series data loggers feature two temperature channels. The channel number for each probe is identified on the top of the logger as shown to the right.

Product Usage Instructions

Installation Guide

Installing the Software:

1. The Software can be downloaded from the MadgeTech website at madgetech.com.
2. Follow the instructions provided in the Installation Wizard.

Installing the Docking Station:

- IFC400 or IFC406 (sold separately) — Follow the instructions provided in the Installation Wizard to install the USB Interface Drivers. Drivers can also be downloaded from the MadgeTech website at madgetech.com.

Device Operation

Connecting and Starting the Data Logger:

1. Once the software is installed and running, plug the interface cable into the docking station.
2. Connect the USB end of the interface cable into an open USB port on the computer.
3. Place the data logger into the docking station.
4. The data logger will automatically appear under Connected Devices within the software.
5. For most applications, select Custom Start from the menu bar and choose the desired start method, reading rate and other parameters appropriate for the data logging application and click Start. (Quick Start applies the most recent custom start options, Batch Start is used for managing multiple loggers at once, Real Time Start stores the dataset as it records while connected to the logger.)
6. The status of the device will change to Running or Waiting to Start, depending upon your start method.

[View Fullscreen](#)

HiTemp140X2 Series

High Temperature Dual Probe Data Logger Series

PRODUCT USER GUIDE

To view the full MadgeTech product line, visit our website at madgetech.com.

HiTemp140X2 Series

PRODUCT USER GUIDE

Product Overview

The HiTemp140X2 Series of dual probe high temperature data loggers are comprised of a stainless steel data logger body and feature either two remote temperature probes or one ambient and one remote temperature probe combination. This data logger series offers extreme flexibility for high temperature monitoring applications.

The dual probes of the HiTemp140X2 Series allow for simultaneous temperature monitoring and are ideal for applications such as oven mapping, surface temperature monitoring, autoclave validation, food processing, sterilization processes and much more.

The HiTemp140X2-TD data logger models feature a 2 inch rigid, fast response, transitional diameter probe to measure ambient temperature, combined with a second stainless steel bendable or flexible RTD probe option.

The HiTemp140X2-FP data logger models feature a 6 inch, 12 inch, 36 inch or 72 inch, lightweight flexible RTD probe with stainless steel tip, combined with a second stainless steel bendable probe or a second flexible RTD probe.

Water Resistance The HiTemp140X2 Series data loggers are rated IP68 and are fully submersible. They can be

placed in environments up to 230 ft (70 m) of water.

Bend Radius The bendable RTD probe on the HiTemp140X2 Series data loggers can be bent to a 0.25 inch bend radius. The probe should not be bent within 1 inch of either weld joint.

Temperature Channels All HiTemp140X2 Series data loggers feature two temperature channels. The channel number for each probe is identified on the top of the logger as shown to the right.

Rigid Transitional Diameter Probe (TD) Flexible RTD Probe (FP) Stainless Steel Bendable RTD Probe (PT)
Product User Guide | 2

HiTemp140X2 Series PRODUCT USER GUIDE

Installation Guide

Installing the Software

The Software can be downloaded from the MadgeTech website at madgetech.com. Follow the instructions provided in the Installation Wizard.

Installing the Docking Station

IFC400 or IFC406 (sold separately) — Follow the instructions provided in the Installation Wizard to install the USB Interface Drivers. Drivers can also be downloaded from the MadgeTech website at madgetech.com.

Device Operation

Connecting and Starting the Data Logger

1. Once the software is installed and running, plug the interface cable into the docking station.
2. Connect the USB end of the interface cable into an open USB port on the computer.
3. Place the data logger into the docking station.
4. The data logger will automatically appear under Connected Devices within the software.
5. For most applications, select Custom Start from the menu bar and choose the desired start method, reading rate and other parameters appropriate for the data logging application and click Start. (Quick Start applies the most recent custom start options, Batch Start is used for managing multiple loggers at once, Real Time Start stores the dataset as it records while connected to the logger.)
6. The status of the device will change to Running or Waiting to Start, depending upon your start method.
7. Disconnect the data logger from the interface cable and place it in the environment to measure.

Note: The device will stop recording data when the end of memory is reached or the device is stopped. At this point the device cannot be restarted until it has been re-armed by the computer.

Downloading Data from a Data Logger

1. Place the logger into the docking station.
2. Highlight the data logger in the Connected Devices list. Click Stop on the menu bar.
3. Once the data logger is stopped, with the logger highlighted, click Download.
4. Downloading will offload and save all the recorded data to the PC.

Trigger Settings

The device can be programmed to only record based off user configured trigger settings.

1. In the Connected Devices panel, click the device desired.
2. On the Device Tab, in the Information Group, click Properties. Or, right-click the device and select Properties in the context menu.
3. Select Trigger in the Properties window.
4. Trigger formats are available in Window or Two Point Mode. Window mode allows a high and/or low trigger set point, and a trigger sample count or "window" of time recorded when set points are exceeded to be defined. Two point allows for different Start and Stop setpoints to be defined for both the high and low triggers. Refer to the Trigger Settings – MadgeTech 4 Data Logger Software video on madgetech.com for instructions on how to configure Trigger Settings.

Set Password

To password protect the device so that others cannot start, stop or reset the device:

1. In the Connected Devices panel, click the device desired.
2. On the Device Tab, in the Information Group, click Properties. Or, right-click the device and select Properties in the context menu.
3. On the General Tab, click Set Password.
4. Enter and confirm the password in the box that appears, then select OK.

HiTemp140X2 Series PRODUCT USER GUIDE

Device Maintenance

O-Rings

O-ring maintenance is a key factor when properly caring for the HiTemp140X2 Series data loggers. The O-rings ensure a tight seal and prevent liquid from entering the inside of the device. Please refer to the application note O-Rings 101: Protecting Your Data, found at madgetech.com, for information on how to prevent O-ring failure.

Recalibration

MadgeTech recommends annual recalibration. To send devices back for calibration, visit madgetech.com.

Battery Replacement Materials: ER14250-SM Battery 1. Unscrew the bottom of the logger and remove the battery. 2. Place the new battery into the logger. Note the polarity of the battery. It is important to insert the battery with positive polarity pointing upward towards the probe. Failure to do so could result in product inoperability or potential explosion if exposed to high temperatures. 3. Screw the cover back onto the logger.

Note: This product is rated for use up to 140 °C (284 °F). Please heed the battery warning. The product will explode if exposed to temperatures above 140 °C (284 °F).

Product Support & Troubleshooting:

· Visit our Resources online at madgetech.com/resources. · Contact our friendly Customer Support Team at (603) 456-2011 or support@madgetech.com.

MadgeTech 4 Software Support:

· Refer to the built-in help section of the MadgeTech 4 Software. · Download the MadgeTech 4 Software Manual at madgetech.com. · Contact our friendly Customer Support Team at (603) 456-2011 or support@madgetech.com.

HiTemp140X2 Series PRODUCT USER GUIDE

Ordering Information

HITEMP140X2-FPST-6 HITEMP140X2-FPST-12 HITEMP140X2-FPST-24 HITEMP140X2-FPST-36
HITEMP140X2-FPST-72

PN 902335-00 PN 902331-00 PN 902333-00 PN 902318-00 PN 902321-00

HITEMP140X2-FPST-6-FPST-12 PN 902334-00

HITEMP140X2-FPST-6-FPST-36 PN 902328-00

HITEMP140X2-FPST-12-PT-1

PN 902332-00

HITEMP140X2-FPST-36-PT-1

PN 902319-00

HITEMP140X2-FPST-72-PT-1

PN 902322-00

HITEMP140X2-FPST-36-PT-5

PN 902320-00

HITEMP140X2-FPST-72-PT-5

PN 902323-00

HITEMP140X2-TD-FPST-6

PN 902338-00

HITEMP140X2-TD-FPST-12

PN 902329-00

HITEMP140X2-TD-FPST-36

PN 902324-00

HITEMP140X2-TD-FPST-72

PN 902325-00

HITEMP140X2-TD-PT-1

PN 900281-00

HITEMP140X2-TD-PT-5

IFC400 IFC406 ER14250-SM Formerly ER14250MR-145

PN 900283-00 PN 900319-00 PN 900325-00 PN 900097-00

High Temperature dual probe data logger with two 6 inch flexible probes with stainless steel tips

High Temperature dual probe data logger with two 12 inch flexible probes with stainless steel tips

High Temperature dual probe data logger with two 24 inch flexible probes with stainless steel tips

High Temperature dual probe data logger with two 36 inch flexible probes with stainless steel tips

High Temperature dual probe data logger with two 72 inch flexible probes with stainless steel tips

High Temperature dual probe data logger with a 6 inch flexible probe and 12 inch flexible probe with stainless steel tips

High Temperature dual probe data logger with a 6 inch flexible probe and 36 inch flexible probe with stainless steel tips

High Temperature dual probe data logger with a 12 inch flexible probe with stainless steel tip and 24 inch bendable probe with a 1 inch piercing tip


High Temperature dual probe data logger with a 36 inch flexible probe with stainless steel tip and 24 inch bendable probe with a 1 inch piercing tip

High Temperature dual probe data logger with a 72 inch flexible probe with stainless steel tip and 24 inch

bendable probe with a 1 inch piercing tip
High Temperature dual probe data logger with a 36 inch flexible probe with stainless steel tip and 24 inch bendable probe with a 5 inch piercing tip
High Temperature dual probe data logger with a 72 inch flexible probe with stainless steel tip and 24 inch bendable probe with a 5 inch piercing tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 6 inch flexible probe with stainless steel tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 12 inch flexible probe with stainless steel tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 36 inch flexible probe with stainless steel tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 72 inch flexible probe with stainless steel tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 24 inch bendable probe with a 1 inch piercing tip
High Temperature dual probe data logger with 2 inch transitional diameter probe and 24 inch bendable probe with a 5 inch piercing tip
Docking station with USB cable
6 Port, Multiplexer docking station with USB cable
Replacement battery for the HiTemp140X2

6 Warner Road, Warner, NH 03278 (603) 456-2011
info@madgetech.com madgetech.com
DOC-1297036-00 | REV 8 2022.07.05

Documents / Resources

	<p>MADGE TECH HiTemp140X2 Series High Temperature Dual Probe Data Logger Series [pdf] User Guide</p> <p>HiTemp140X2-TD, HiTemp140X2-FP, HiTemp140X2 Series High Temperature Dual Probe Data Logger Series, HiTemp140X2, Series High Temperature Dual Probe Data Logger Series, High Temperature Dual Probe Data Logger Series, Temperature Dual Probe Data Logger Series, Probe Data Logger Series, Data Logger Series, Logger Series, Series</p>
---	---