

Manhattan T3-R USB Stick 4K Smart Recorder Receiver User Guide

Home » Manhattan » Manhattan T3-R USB Stick 4K Smart Recorder Receiver User Guide





Manhattan T3•R v2.06 USB **Update Guide**

Contents

- 1 T3-R USB Stick 4K Smart Recorder Receiver
- 2 How to Format a USB stick for FAT32 using **Windows**
- 3 Documents / Resources
 - 3.1 References

T3-R USB Stick 4K Smart Recorder Receiver

You need a USB stick formatted with the FAT32 filesystem and 128MB of free space. Many sticks will be formatted with FAT32 out of the box. However, if necessary please see formatting instructions for Windows on page 2 and Mac on page 3. We have occasionally found some USB sticks to be incompatible with the T3•R. If a USB stick isn't recognised, please try another one.

- 1. Use your computer to unzip the downloaded file Manhattan T3-R 2.06.zip and extract the folder Manhattan T3-R v2.06.
- 2. The folder contains the release notes and two upgrade files: Copy autoupgrade.cfg and Manhattan_T3-R 2.06 0099.usb to the root of the USB stick.



3. Connect the USB stick to the USB port on the back of the T3•R and wait a few seconds for the USB Update Detected screen to be shown.

Press OK to select Install Update.

 The T3•R will reboot and display the S/W Upgrade – USB screen.

IMPORTANT: Please DO NOT turn off the power to your T3•R during the update.

5. After the update is complete the T3•R will automatically reboot. The Software Updated screen will be shown along with the updated version 2.06 Disconnect the USB and then press OK to continue.



Tip: After updating you can also check the software version by pressing HOME and selecting: Settings > Information.

How to Format a USB stick for FAT32 using Windows

- 1. Connect the USB stick to the computer.
- 2. Open the Computer or This PC window, depending on your OS version.
 - Windows Vista and Windows 7:
 - Click Start
 - Click Computer
 - Windows 8/8.1:

- Type Computer in the search area from the Start screen
- Tap or click Computer
- Windows 10:
- Type This PC in the search area from the Start screen
- Tap or click This PC
- 3. In the Computer or This PC window, right-click USB stick's drive icon.
- 4. From the menu, click Format....

WARNING: Formatting the USB storage device will delete all content on the device.

- 5. In the Format device name (drive letter) window, under File system, click the drop-down arrow, select FAT32 and then click Start.
- 6. At the WARNING... message, click OK to continue.
- 7. At the Format Complete message, click OK.

How to Format a USB stick for FAT32 using Mac

- 1. Connect the USB stick to the computer.
- 2. Browse or search for the Disk Utility application.
 - To browse to it:
 - · Open the Applications folder.
 - Open the Utilities folder.
 - Open the Disk Utility application.
 - To search for it:
 - · Click the magnifying glass icon in the top right of your Mac's screen
- 3. Click to select the USB stick in the left panel.
- 4. Click the Erase button.
- 5. In the Format selection box, click MS-DOS (FAT).

NOTE: If you see a MS-DOS (FAT32) option that is 'greyed out' this is just to inform you of how the stick is currently formatted. You shouldn't need to format the stick but if you've had a problem with it then it is worth trying.

6. Click Erase.

WARNING: Erasing the USB device will delete all content on the device.



Documents / Resources



Manhattan T3-R USB Stick 4K Smart Recorder Receiver [pdf] User Guide

T3-R, T3-R USB Stick 4K Smart Recorder Receiver, USB Stick 4K Smart Recorder Receiver, 4K Smart Recorder Receiver, Smart Recorder Receiver, Receiver, Receiver

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.