



Mattel HRR48-4B70 Minecraft Exploding RC Creeper Instruction Manual

[Home](#) » [Mattel](#) » Mattel HRR48-4B70 Minecraft Exploding RC Creeper Instruction Manual 

Mattel HRR48-4B70 Minecraft Exploding RC Creeper Instruction Manual



Adult supervision is recommended when the RC figure is being operated.



Please keep these instructions for future reference as they contain important information.



IMPORTANT: Please read all instructions before operating your RC figure

Contents

[1 FEATURES](#)

[2 SET UP](#)

[3 A. BATTERY INSTALLATION](#)

[4 SET UP \(CONTD.\)](#)

[5 PAIRING THE REMOTE CONTROLLER AND
FIGURE](#)

[6 TO PLAY](#)

[7 CONTROLS](#)


[8 Documents / Resources](#)

[8.1 References](#)

[9 Related Posts](#)

FEATURES

- **A JOYSTICK**




- **B ACTION BUTTON**
- **C LED INDICATOR**
- **D BATTERY BOX**




BOTTOM VIEW

- **E EXPLOSION PARTICLES STORAGE SLOTS**



- F LED LIGHT
- G BATTERY BOX




BOTTOM VIEW

- H POWER SWITCH

SET UP

A. BATTERY INSTALLATION




1. Unscrew the battery covers on both the figure and the remote controller with a Phillips head screwdriver (not included).
2. Install 3 AA (LR6) 1.5V alkaline batteries (not included) in the figure's battery box.
3. Install 2 AAA (LR03) 1.5V alkaline batteries (not included) in the remote controller's battery box.
4. For best performance, use alkaline batteries.
5. Replace both battery covers and tighten screws.
6. Replace the batteries in the figure and the remote controller if the figure begins to run slowly or does not respond or if the figure's lights and sounds dim and distort.


SET UP (CONTD.)

LOADING THE EXPLOSION PARTICLES


1. Load the explosion particles into the slots on the figure.



2. Close the figure's sides.



3. Reattach the figure's head.




TIPS

- Each storage slot can fit a maximum of 5 explosion particles.


- Press and hold the action button to open the figure and detach the head if the figure is already closed before loading the explosion particles.

PAIRING THE REMOTE CONTROLLER AND FIGURE

1. Slide the power switch to ON (I) on the figure.




2. Push the remote controller's joystick forward or backward after switching on the figure.



3. Pairing is complete when the LED changes from flashing red to solid red on the remote controller.

NOTE: If the figure does not respond to the remote controller after pairing, switch the figure off then back on to try pairing again or replace the batteries in the figure and remote controller if the batteries are drained.



Pairing is complete



TIP: The figure will go into sleep mode if left idle for approximately 15 minutes to preserve battery life. To resume normal play, slide the figure's power switch to OFF then ON again, and then push the remote controller's joystick forward or backward to pair the figure and remote controller


TO PLAY

CHECKLIST


- Are the remote controller and figure equipped with fresh batteries?
- Is the remote controller paired with the figure?

CONTROLS


- FORWARD




- REVERSE & TURN



- Press the action button for lights and sounds



- Press and hold the action button to explode!




NOTE

Operating range of the remote controller is up to 30 m (98 ft).

WARNING: Do not aim at eyes or face. Only use projectiles supplied with this toy. Do not fire at point blank range.





Documents / Resources



[Mattel HRR48-4B70 Minecraft Exploding RC Creeper](#) [pdf] Instruction Manual
HRR48-4B70 Minecraft Exploding RC Creeper, HRR48-4B70, Minecraft Exploding RC Creeper,
Exploding RC Creeper, RC Creeper, Creeper

References

-  [Les Jouets Mattel France - Bienvenue sur Les Jouets Mattel](#)
-  [MATTEL & FISHER-PRICE CUSTOMER SERVICE](#)
-  [Mattel](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.