

Megger MST210 Socket Tester



Megger MST210 Socket Tester User Guide

[Home](#) » [Megger](#) » Megger MST210 Socket Tester User Guide 

Contents

- [1 Megger MST210 Socket Tester](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Instructions for Use](#)
- [5 Specifications](#)
- [6 FAQ](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

Megger[®]

Megger MST210 Socket Tester



Specifications

- **Indicators:** Single colour bright LED
- **Supply Rating:** 230V 50Hz
- **Current Draw:** 3mA max
- **Humidity:** < 95% non-condensing
- **Size:** 69mm x 67mm x 32mm
- **Weight:** 80g

Product Usage Instructions

Safety Warnings

Before using the MST210 Socket Tester, please take note of the following safety warnings:

- The MST210 cannot identify a Neutral to-Earth reversal.
- This tester does not replace the need for a full electrical test of circuits as specified by BS7671.
- It is intended for the initial diagnosis of simple wiring faults only.
- If any problems are found or suspected, refer to a qualified electrician for repair.

Instructions for Use

1. Verify the operation by plugging the MST210 into a known good 13A socket.
2. Plug the tester into the socket to be tested and switch it on.
3. Check the indication displayed by the leds against the provided table for diagnosis of the wiring status.

Cleaning Instructions

To clean the MST210 Socket Tester, follow these instructions:

- Wipe clean with a dry cloth.
- Do not use water, chemicals, or detergents of any kind.

The Megger MST210 Socket Tester is designed to provide a quick and easy indication of wiring errors that may be present at a socket outlet. Using simple green and red LEDs, correct wiring can be verified with no need to isolate the supply or disassemble the socket.

Simply plug the tester into the socket. If the wiring is correct, two green LEDs will illuminate. If either the green LED does not light or the red LED comes on, there is a wiring fault. By referring to the table below, the combination of LEDs shown will indicate the wiring fault present. Technical advice may be obtained from Megger Product Support at +44 (0) 1304 502102.

Safety Warnings

NOTES: The MST210 cannot identify a Neutral to Earth reversal. The Megger MST210 Socket Tester does not eliminate the need for a full electrical test of circuits as specified by BS7671 and is supplementary to it.

The Megger MST210 Socket Tester is intended for the initial diagnosis of simple wiring faults, and any problem found or suspected must be referred to a suitably qualified electrician for repair. Observe all of the safety information provided on the product and in this User Guide

WEEE Directive

The crossed-out wheeled bin symbol on the instrument and the batteries is a reminder not to dispose of them with general waste at the end of their life.

- Megger is registered in the UK as a Producer of Electrical and Electronic equipment.
- The registration no is; WEE/
- DJ2235XR.
- Users of Megger products in the UK may dispose of them at the end of their useful life by contacting B2B Compliance at www.b2bcompliance.org.uk or by telephone at 01691 676124. Users of
- Megger products in other parts of the EU should contact their local Megger company or distributor.
- **CATIV** – Measurement category IV: Equipment connected between the origin of the low-voltage mains supply outside the building and the consumer unit.
- **CATIII** – Measurement category III: Equipment connected between the consumer unit and the electrical outlets.
- **CATII** – Measurement category II: Equipment connected between the electrical outlets and the user's equipment.

Warning – Electric Shock Hazard

Contact with live circuits can result in severe injury or death. Before use check the tester and pins for any sign of damage. Do not use if the instrument is damaged or broken in any way.

- Do not use in damp conditions
- This unit is not designed to be used continuously for more than 5 minutes. Do not leave plugged into a live

socket for extended periods.

- Do not cover vent slots
- Suitable for use on 230 V ac 13A BS1363 socket outlets only. Do not attempt to adapt it for any other use.
- This product is maintenance-free and contains no user-serviceable components.
- Do not attempt to disassemble.

Instructions for Use

1. Verify the operation of the MST210 by plugging it into a known good 13A socket before use.
2. Plug the tester into the socket to be tested and switch on.
3. Check the indication displayed by the LEDs against the table for diagnosis of the wiring status.

Specifications

- **Indicators** Single colour bright LED
- **Supply Rating** 230V 50Hz
- **Current Draw** 3mA max
- **Operating Temperature** 0 to 40°C
- **Humidity** < 95% non-condensing
- **Size** 69mm x 67mm x 32mm
- **Weight** 80g

Cleaning instructions

- Wipe clean with a dry cloth. Do not use water, chemicals or detergents of any kind. Suitable for sale within the EU
- Megger Limited, Archcliffe Road, Dover, Kent, CT17 9EN, United Kingdom.

MST210 Fault Combination Chart

Plug Pins			Fault	LED Combination		
N	E	L		Green LED 1	Green LED 2	Red LED
N	E	L	Correct Polarity	ON	ON	
N		L	Earth missing	ON		
N	L	E	Earth pin connected to Live; Live pin connected to Earth		ON	ON
	L	E	Earth pin connected to Live; Live pin connected to Earth; missing Neutral		ON	
	L	N	Earth pin connected to Live; Live pin connected to Neutral; missing Earth		ON	
N	L		Earth pin connected to Live; missing Earth	ON	ON	ON
	N	L	Earth pin connected to Neutral; missing Earth		ON	
	E	L	Neutral missing		ON	
E	L	N	Neutral pin connected to Earth; Earth pin connected to Live; Live pin connected to Neutral		ON	ON

E	L		Neutral pin connected to Earth; Earth pin connected to Live; missing Neutral	ON	ON	ON
E		L	Neutral pin connected to Earth; missing Neutral	ON		
L	N	E	Neutral pin connected to Live; Earth pin connected to Neutral; Live pin connected to Earth	ON		ON
L	N		Neutral pin connected to Live; Earth pin connected to Neutral; missing Earth	ON	ON	ON
L		E	Neutral pin connected to Live; Live pin connected to Earth; missing Neutral	ON		
L	E	N	Neutral pin connected to Live; Live pin connected to Neutral	ON		ON
L		N	Neutral pin connected to Live; Live pin connected to Neutral; missing Earth	ON		
L	E		Neutral pin connected to Live; missing Neutral	ON	ON	ON


- Tests 13 A sockets with no disassembly
- Easy to use
- Instant error reporting
- Simple fault diagnosis
- Identifies 17 wiring fault conditions
- Rugged and reliable

FAQ

(Frequently Asked Questions)

- **Q: What does the MST210 Socket Tester identify?**
 - A: The MST210 can identify 17 different wiring fault conditions, providing instant error reporting for easy fault diagnosis.
 - **Q: Can I use the MST210 to test sockets without disassembly?**
 - A: Yes, the MST210 is designed to test 13A sockets without the need for disassembly, making it convenient and easy to use.
 - **Q: How reliable is the MST210 Socket Tester?**
 - A: The MST210 is described as rugged and reliable, ensuring consistent performance when diagnosing wiring faults.
-

Documents / Resources

 The image shows the Megger MST210 Socket Tester, a white rectangular device with a red indicator light and a small display screen. The Megger logo is visible at the top, and the text 'MST210 Socket tester' is at the bottom.	<p>Megger MST210 Socket Tester [pdf] User Guide MST210 Socket Tester, MST210, Socket Tester, Tester</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.