



MPF200T-FCG784
PolarFire Ethernet
Sensor Bridge



MICROCHIP MPF200T-FCG784 PolarFire Ethernet Sensor Bridge User Guide

[Home](#) » [MICROCHIP](#) » MICROCHIP MPF200T-FCG784 PolarFire Ethernet Sensor Bridge User Guide 

Contents

- [1 MICROCHIP MPF200T-FCG784 PolarFire Ethernet Sensor Bridge](#)
- [2 Introduction](#)
- [3 Hardware Features](#)
- [4 Demo Requirements](#)
- [5 Running the Demo](#)
- [6 Running Examples](#)
- [7 Microchip FPGA Support](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)



MICROCHIP MPF200T-FCG784 PolarFire Ethernet Sensor Bridge



Introduction

The PolarFire® Ethernet Sensor Bridge is part of Nvidia’s Holoscan Ecosystem and extends multi-protocol signal conversion to NVIDIA® Jetson®, Orin®, AGX and IGX developer kits via Ethernet. The sensor bridge is based on Microchip’s power-efficient PolarFire Field-Programmable Gate Array (FPGA), MPF200T-FCG784. It has two 10G SFP+ Ethernet ports that connect to the Jetson AGX Orin and IGX developer kits and two MIPI CSI-2 receive ports for connecting cameras. The included FMC slot provides expansion options for protocols like Scalable Low-Voltage Signaling with Embedded Clock (SLVS-EC), CoaXPress, JESD 204B, Serial Digital Interface (SDI), and so on. The sensor bridge also has DDR4 for frame buffering and SPI Flash for enabling field upgrades.

The following table lists the Ethernet Sensor Bridge (ESB) kit contents.

Table 1. Kit Contents

Quantity	Description
1	PolarFire ESB board
1	12.3 MP IMX477M Camera Module from Arducam Part Number: B0466R
1	10 Gb SFP+ to RJ45 Module Part Number: SFP-10G-T-S
1	10G Ethernet Cable
1	12V/5A AC Adapter
1	12V Power Cord
1	Type-C USB cable
1	QuickStart Card

The following figure shows the PolarFire ESB Kit contents.


Figure 1. PolarFire Ethernet Sensor Bridge Kit Contents



Hardware Features

The following figure shows the board components.

Figure 1-1. Board Components



Demo Requirements

Table 2-1. Pre-requisites for the Demo

Requirement	Description
Hardware and Accessories	
PolarFire® ESB	MPF200-ETH-SENSOR-BRIDGE
NVIDIA® Jetson AGX Orin™ Developer Kit 1	A MIPI CSI-2 camera is attached to the sensor bridge and connected to the AGX Orin Devkit via Ethernet. Th is kit has to be bought separately.
One MIPI CSI-2 Camera module	IMX477-based Arducam Camera module is included in the kit
One 10G Ethernet Cable	Included in the kit
SFP+ to RJ45 converter	Included in the kit
12V/5A Power Supply	Included in the kit
Monitor with DisplayPort Input	Display for the AGX Orin Devkit
Keyboard and Mouse	Required to configure the AGX Orin Devkit.


Note: The Quick Start Guide provides setup instructions for use with a Jetson Orin AGX Developer Kit. If you are using an IGX Developer Kit, follow the specific steps intended for the IGX kit. We highlight the sections where instructions differ for each kit.

Running the Demo

The scope of this quick start guide is to get you set up and run a single MIPI CSI-2 camera streaming video via 10G Ethernet to the NVIDIA Jetson AGX Orin Developer Kit, which connects to a monitor via DisplayPort. The PolarFire ESB is pre-programmed to support two IMX477 MIPI CSI-2 cameras from Arducam. However, only one Camera module is provided in the box. The following figure shows the functional block diagram.

Figure 3-1. Functional Block Diagram

Figure 3-1. Functional Block Diagram



Setting up the Demonstration

The following table list the setup summary.

Steps	What	Description
Step 1	PolarFire® ESB	Steps covering connecting the image sensor to the sensor bridge and ethernet cable between sensor bridge and the AGX Orin devkit.
Step 2	AGX Orin Devkit setup	Steps covering AGX Orin devkit set up, updating packages and doing a ping test on the sensor bridge.
Step 3	Running examples	Running examples.

Setting up the PolarFire ESB

The following table lists the jumpers and their default position, ensure that the jumpers in the ESB are set correctly.

Table 3-1. Jumper setting for ESB


Jumper	Default Position
J4	Closed
J7	Closed
J18	Close pins 2 and 3
J21	Close pins 2 and 3
J15	Close pins 1 and 2 (3.3V)
J20	Close pins 2 and 3
J16	Close pins 2 and 3
J24	Close pins 9 and 10 (3.3V)

Camera Setup

To set up the camera, perform the following steps:


1. Make sure the MPF200-ETH-SENSOR-BRIDGE board is powered OFF.
2. Connect the IMX477 Camera module to J14 MIPI connector using the 22-pin to 22-pin camera cable, as shown in the following figure.

Figure 3-2. Connecting the Image Sensor to the MIPI CSI-2 Port of the Sensor Bridge



3. Insert SFP+ to RJ45 converter into the SFP cage on J5.
4. Connect the Ethernet cable from the SFP+ RJ45 port to the Ethernet port on NVIDIA Jetson AGX Orin Developer Kit, as shown in the following figure.

Figure 3-3. Jetson AGX Orin Developer Kit Callout



5. Connect the 12V power adapter to the J25 power input port.
6. To turn on the board, slide the switch SW1 to the ON position.

Setting up the AGX Orin developer kit

1. Run the steps in the Getting Started with Jetson AGX Orin Developer Kit.
2. While on the getting started page, choose the “Default setup flow” instead of the “Optional Setup Flow” and when scrolling down, choose “Initial setup with display attached” instead of the “Initial setup in a headless configuration”.

Note: This step can take a long time. Make sure you have a stable internet connection.

Jetson AGX Orin Developer Kit Setup Host Setup

The PolarFire sensor bridge is supported on AGX Orin systems running JP6.0 release 2. In this configuration, the on-board Ethernet controller is used with the Linux kernel network stack for data I/O; all network I/O is performed by the CPU without network acceleration.

After the PolarFire Ethernet Sensor Bridge board is set up, configure a few prerequisites in your host system. While sensor bridge applications run in a container, these commands are all to be executed outside the container, on the host system directly. These configurations are remembered across power cycles and therefore only need to be set up once.

1. Install git-lfs.

Some data files in the sensor bridge source repository use GIT LFS.

```
sudo apt-get update
```

```
sudo apt-get install -y git-lfs
```

2. Grant your user permission to the docker subsystem:

```
$ sudo usermod -aG docker $USER
```

Reboot the computer to activate this setting.

Demos and examples in this package assume a sensor bridge device is connected to eth0, which is the RJ45 connector on the AGX Orin.

3. Linux sockets require a larger network receiver buffer.

Most sensor bridge self-tests use Linux's loopback interface; if the kernel starts dropping packets due to out-of-buffer space then these tests will fail.

```
echo 'net.core.rmem_max = 31326208' | sudo tee /etc/sysctl.d/52-hololink-rmem_max.conf
sudo sysctl -p /etc/sysctl.d/52-hololink-rmem_max.conf
```

4. Configure eth0 for a static IP address of 192.168.0.101.

L4T uses NetworkManager to configure interfaces; by default, interfaces are configured as DHCP clients. Use the following command to update the IP address to 192.168.0.101. For more information about configuring your system, see Holoscan sensor bridge IP address configuration (If you cannot use the 192.168.0.0/24 network in this way).

```
sudo nmcli con add con-name hololink-eth0 ifname eth0 type ethernet ip4 192.168.0.101/24
sudo nmcli connection up hololink-eth0
```

Apply power to the sensor bridge device, ensure that it's properly connected, then ping 192.168.0.2 to check connectivity.

5. For the Linux socket-based examples, isolating a processor core from Linux kernel is recommended. For high bandwidth applications, like 4k video acquisition, isolation of the network receiver core is required. When an example program runs with processor affinity set to that isolated core, performance is improved, and latency is reduced. By default, sensor bridge software runs the time-critical background network receiver process on the third processor core. If that core is isolated from Linux scheduling, no processes will be scheduled on that core without an explicit request from the user, and reliability and performance is greatly improved.

Isolating that core from Linux can be achieved by editing /boot/extlinux/extlinux.conf.

Add the setting isolcpus=2 to the end of the line that starts with APPEND. Your file should look like something like this:

```
TIMEOUT 30
DEFAULT primary
MENU TITLE L4T boot options
LABEL primary
MENU LABEL primary kernel
LINUX /boot/Image
FDT /boot/dtb/kernel_tegra234-p3701-0000-p3737-0000.dtb
INITRD /boot/initrd
APPEND ${cbootargs} root=/dev/mmcblk0p1 rw rootwait ...<other-settings>... isolcpus=2
```

Sensor bridge applications can run the network receiver process on another core by setting the environment variable HOLOLINK_AFFINITY to the core it should run on. For example, to run on the first processor core, HOLOLINK_AFFINITY=0 python3 examples/linux_imx477_player.py

Setting HOLOLINK_AFFINITY to blank will skip any core affinity settings in the sensor bridge code.

6. Run the "jetson_clocks" tool on startup, to set the core clocks to their maximum.

```
JETSON_CLOCKS_SERVICE=/etc/systemd/system/jetson_clocks.service
cat <<EOF | sudo tee $JETSON_CLOCKS_SERVICE >/dev/null
[Unit] Description=Jetson Clocks Startup
After=nvpmode.service
[Service] Type=oneshot
ExecStart=/usr/bin/jetson_clocks
```




```
[Install] WantedBy=multi-user.target
```

```
EOF
```

```
sudo chmod u+x $JETSON_CLOCKS_SERVICE
```

```
sudo systemctl enable jetson_clocks.service
```

7. Set the AGX Orin power mode to 'MAXN' for optimal performance, as shown in the following figure. The setting can be changed via L4T power drop down setting found on the upper left corner of the screen:



8. Restart the AGX Orin. This allows core isolation and performance settings to take effect. If configuring for 'MAXN' performance doesn't request that you reset the unit, then execute the reboot command manually:

```
reboot
```

9. Log in to Nvidia GPU Cloud (NGC) with your developer account:
 - a. If you don't have a developer account for NGC please register at NVIDIA.
 - b. Create an API key for your account, thru API Key.
 - c. Use your API key to log in to nvcr.io:

```
$ docker login nvcr.io
Username: $oauthtoken
Password: <Your token key to NGC>
WARNING! Your password will be stored unencrypted in /home/<user>/.docker/config.json.
Configure a credential helper to remove this warning. See
https://docs.docker.com/engine/reference/commandline/login/#credentials-store

Login Succeeded
```

Build and Test the Sensor Bridge Demo Container

Holoscan sensor bridge host software includes instructions for building a demo container. This container is used to run all holoscan tests and examples.

1. Fetch the sensor bridge source code from [GitHub](https://github.com/nvidia-holoscan/holoscan-sensor-bridge).

```
$ git clone https://github.com/nvidia-holoscan/holoscan-sensor-bridge
```

2. Build the sensor bridge demonstration container. For systems with iGPU,

```
$ cd holoscan-sensor-bridge
$ sh docker/build.sh --igpu
```

Note: igpu is appropriate for systems running on a system with iGPU (e.g. AGX or IGX without a dGPU). This requires an OS installed with iGPU support (For example: for AGX: JetPack 6.0, and for IGX: IGX OS with iGPU configuration).

Run Tests in the Demo Container

To run the sensor bridge demonstration container, from a terminal in the GUI,

```
xhost +  
sh docker/demo.sh
```

This brings you to a shell prompt inside the Holoscan sensor bridge demo container.

Note: iGPU configurations, when starting the demo container it will display the message “Failed to detect NVIDIA driver version”: this can be ignored.

Now you’re ready to run sensor bridge applications.

Sensor Bridge Software Loopback Tests

Sensor bridge host software includes a test fixture that runs in loopback mode, where no sensor bridge equipment is necessary. This test works by generating UDP messages and sending them over the Linux loopback interface.

In the shell in the demo container:

```
pytest
```

Note: The test fixture intentionally introduces errors into the software stack. If pytest indicates that all tests have passed, any error messages published by individual tests can be ignored.

Running Examples

Two examples are described in this section

1. Streaming camera video
2. Running a pose estimation demo

Streaming the Video on AGX Developer Kit

This demonstration shows the output of the IMX477 camera module on the monitor connected via displayport. To run the high-speed video player with IMX477 setup, perform the following steps:

1. Open a new terminal and navigate to the holoscan-sensor-bridge folder by using the following command.
`cd <PATH/TO/holoscan-sensor-bridge>`
2. To run the sensor bridge demonstration container, from a terminal in the GUI
Note: Ignore the step if the docker is running already `xhost + sh docker/demo.sh`
It runs the holoscan-sensor-bridge docker container.
3. Set up the camera and run the high-speed video player (Holoviz) with live video using the following command:
`python examples/linux_imx477_player.py`
4. To close the Holoviz application and exit the docker, exit

Running Pose Estimation on GPU

To run this example, perform the following steps:

1. Download the file mpf_an522_v2023v2_jb.zip from AN5522.

```
mpf_an5522_v2023p2_jb
|--PF_ESK_C2_2407.job
|--linux_body_pose_estimation_imx477.py
```

2. Copy the file linux_imx477_pose_estimation.py into the folder holoscan-sensorbridge/ examples
3. Open a new terminal and navigate to the holoscan-sensor-bridge folder by using the following command.
`cd <PATH/TO/holoscan-sensor-bridge>`
4. The next step involves downloading ffmpeg and ultralytics packages to run the pose estimation demo from Running Holoscan Sensor Bridge examples – NVIDIA Docs. Rather than going to the link above, type the following in the console
`apt-get update && apt-get install -y ffmpeg`
`pip3 install ultralytics onnx`
`cd examples`
`yolo export model=yolov8n-pose.pt format=onnx`
`cd`
Note: This conversion step only needs to be executed once; the yolov8n-pose.onnx file contains the converted model and is all that's needed for the demo to run. The installed components will be forgotten when the container is exited; those do not need to be present in future runs of the demo.
5. To run the sensor bridge demonstration container, from a terminal in the GUI,
Note: Ignore the step if the docker is running already
`xhost +`
`sh docker/demo.sh`
6. To run the pose estimation demo,
`python examples/linux_imx477_pose_estimation.py`
7. Close the Holoviz application and exit the docker to terminate the application

Documentation Resources

For more information on the PolarFire ESB, including schematics and user's guides, see the MPF200-Eth-sensor-bridge.

Microchip FPGA Support

Microchip FPGA products group backs its products with various support services, including Customer Service, Customer Technical Support Center, a website, and worldwide sales offices. Customers are suggested to visit Microchip online resources prior to contacting support as it is very likely that their queries have been already answered.

Contact Technical Support Center through the website at www.microchip.com/support. Mention the FPGA Device Part number, select appropriate case category, and upload design files while creating a technical support case.

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

- From North America, call 800.262.1060

- From the rest of the world, call 650.318.4460
- Fax, from anywhere in the world, 650.318.8044

Microchip Information

Trademarks

The Microchip name and logo, the Microchip logo, Adaptec, AVR, AVR logo, AVR Freaks, BesTime, BitCloud, CryptoMemory, CryptoRF, dsPIC, flexPWR, HELDO, IGLOO, JukeBlox, KeeLoq, Kleer, LANCheck, LinkMD, maXStylus, maXTouch, MediaLB, megaAVR, Microsemi, Microsemi logo, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, PolarFire, Prochip Designer, QTouch, SAM-BA, SenGenuity, SpyNIC, SST, SST Logo, SuperFlash, Symmetricom, SyncServer, Tachyon, TimeSource, tinyAVR, UNI/O, Vectron, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AgileSwitch, ClockWorks, The Embedded Control Solutions Company, EtherSynch, Flashtec, Hyper Speed Control, HyperLight Load, Libero, motorBench, mTouch, Powermite 3, Precision Edge, ProASIC, ProASIC Plus, ProASIC Plus logo, Quiet-Wire, SmartFusion, SyncWorld, TimeCesium, TimeHub, TimePictra, TimeProvider, and ZL are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, Augmented Switching, BlueSky, BodyCom, Clockstudio, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, Espresso T1S, EtherGREEN, EyeOpen, GridTime, IdealBridge, IGaT, In-Circuit Serial Programming, ICSP, INICnet, Intelligent Paralleling, IntelliMOS, Inter-Chip Connectivity, JitterBlocker, Knob-on-Display, MarginLink, maxCrypto, maxView, memBrain, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, mSiC, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICKit, PICtail, Power MOS IV, Power MOS 7, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, RTAX, RTG4, SAM-ICE, Serial Quad I/O, simpleMAP, SimpliPHY, SmartBuffer, SmartHLS, SMART-I.S., storClad, SQL, SuperSwitcher, SuperSwitcher II, Switchtec, SynchroPHY, Total Endurance, Trusted Time, TSHARC, Turing, USBCheck, VariSense, VectorBlox, VeriPHY, ViewSpan, WiperLock, XpressConnect, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

The Adaptec logo, Frequency on Demand, Silicon Storage Technology, and Symmcom are registered trademarks of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2024, Microchip Technology Incorporated and its subsidiaries. All Rights Reserved.

ISBN: 979-8-3371-0032-6

Legal Notice

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at www.microchip.com/en-us/support/design-help/client-support-services

THIS INFORMATION IS PROVIDED BY MICROCHIP "AS IS". MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.


Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip Devices Code Protection Feature










Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip product is strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is “unbreakable”. Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.

Documents / Resources

	MICROCHIP MPF200T-FCG784 PolarFire Ethernet Sensor Bridge [pdf] User Guide MPF200T-FCG784 PolarFire Ethernet Sensor Bridge, MPF200T-FCG784, PolarFire Ethernet Sensor Bridge, Ethernet Sensor Bridge, Sensor Bridge, Bridge
---	--

References

-  [Microchip Lightning Support](#)
-  [Products-SFP,SFP+,QSFP+,QSFP28 DAC AOC Module](#)
-  [Buy the Latest Jetson Products | NVIDIA Developer](#)
-  [Getting Started with Jetson AGX Orin Developer Kit | NVIDIA Developer](#)
-  [Running Holoscan Sensor Bridge examples - NVIDIA Docs](#)
-  [Important notes - NVIDIA Docs](#)
-  [GitHub - nvidia-holoscan/holoscan-sensor-bridge: NVIDIA Holoscan Sensor Bridge - Bring Your Own Sensor \(BYOS\) over Ethernet](#)
-  [ngc.nvidia.com/setup/api-key](#)
-  [Shop-Arducam - Arducam](#)

-  [Client Support Services | Microchip Technology](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.