



MikroTik RB941-2ND Hap Lite Classic Routerboard User Manual

[Home](#) » [Mikrotik](#) » MikroTik RB941-2ND Hap Lite Classic Routerboard User Manual

MikroTik RB941-2ND Hap Lite Classic Routerboard User Manual



Contents [[hide](#)]

- [1 Quickstart](#)
- [2 MikroTik mobile app](#)
- [3 Powering](#)
- [4 Configuration](#)
- [5 Mounting](#)
- [6 Expansion slots and ports](#)
- [7 Reset button](#)
- [8 Accessories](#)
- [9 Operating system support](#)
- [10 Federal Communication Commission Interference Statement](#)
- [11 Industry Canada](#)
- [12 CE Declaration of Conformity](#)
- [13 MPE statement](#)
- [14 Frequency bands terms of use](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)

Quickstart

Please follow these quick steps to set up your device:

- Connect your ISP Ethernet cable to the Ethernet port 1.
- Connect the device to the power source (see “**Powering**”). Open network connections on your PC, mobile phone or other device and search for MikroTik wireless network and connect to it.
- The configuration has to be done through the wireless network using a web browser or mobile app – (see “**MikroTik mobile app**”). Alternatively, you can use the WinBox configuration tool <https://mt.lv/winbox>.
- Once connected to the wireless network, open **https://192.168.88.1** in your web browser to start configuration, user name: admin and there is no password by default.
- When using a mobile application choose Quick setup and it will guide you through all necessary configuration in six easy steps.
- We recommend clicking the “Check for updates” button and updating your RouterOS software to the latest version to ensure the best performance and stability.
- Choose your country, to apply country regulation settings and set up your password in the screen that loads.

MikroTik mobile app

Use the MikroTik smartphone app to configure your router in the field, or to apply the most basic initial settings for your MikroTik home access point.



1. Scan QR code and choose your preferred OS.
2. Install and open application.
3. By default, the IP address and user name will be already entered.
4. Click Connect to establish a connection to your device through a wireless network.
5. Choose Quick setup and application will guide you through all basic configuration settings in a couple of easy steps.
6. An advanced menu is available to fully configure all necessary settings.

Powering

The device accepts power in the following ways:

- microUSB accepts 5 V DC .

The power consumption under maximum load can reach 5 W.

Configuration

Once logged in, we recommend clicking the “Check for updates” button in the QuickSet menu, as updating your RouterOS software to the latest version ensures the best performance and stability. For wireless models, please make sure you have selected the country where the device will be used, to conform with local regulations. RouterOS includes many configuration options in addition to what is described in this document. We suggest starting here to get yourself accustomed to the possibilities: <https://mt.lv/winbox>. In case IP connection is not available, the Winbox tool (<https://mt.lv/winbox>) can be used to connect to the MAC address of the device from the LAN side (all access is blocked from the Internet port by default).

For recovery purposes, it is possible to boot the device for reinstallation, see section **Buttons and Jumpers**.

Mounting

The device is designed to be used indoors and placed on a flat surface with all needed cables connecting to the front of the unit.

Alternatively, unit can be mounted on the wall, mounting points are located on the bottom side of the device, screws are not included in the package. Screws with size 4×25 mm fit nicely, depending on your wall structure you can use dowels 6×30 mm and 6 mm drill bit if needed.



- When mounting on the wall, please ensure that cable feed is pointing downwards.

The IP rating scale of this device is IPX0. We recommend using Cat6 shielded cables. Warning! This equipment should be installed and operated with a minimum distance of 20 cm between the device and your body. Operation

of this equipment in the residential environment could cause radio interference.

Expansion slots and ports

- Four 10/100 Ethernet ports, supporting automatic cross/straight cable correction (Auto MDI/X). Either straight or crossover cable can be used for connecting to other network devices.
- Integrated wireless module 2.4 GHz, 802.11b/g/n, antenna gain 1.5 dBi.

Reset button

RouterBOOT reset button has the following functions. Press the button and apply the power, then:

- Release the button when green LED starts flashing, to reset RouterOS configuration to defaults.
- Release the button when the LED turns solid green to clear all configuration and defaults.
- Release the button after LED is no longer lit (~20 seconds) to cause a device to look for Netinstall servers (required for reinstalling RouterOS over the network).

Regardless of the above option used, the system will load the backup RouterBOOT loader if the button is pressed before power is applied to the device. Useful for RouterBOOT debugging and recovery.

Accessories

Package includes the following accessories that come with the device:

- EU Switching Power Supply 5 V, 1 A, 5 W, Level VI, cable:1.5 m, MicroUSB.

Operating system support

The device supports RouterOS software version 6. The specific factory-installed version number is indicated in the RouterOS menu /system resource. Other operating systems have not been tested.

Federal Communication Commission Interference Statement



FCC ID: TV7RB941-2ND

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna must not be co-located or operation in conjunction with any other antenna or transmitter.

IMPORTANT: Exposure to Radio Frequency Radiation.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and any part of your body.

Industry Canada

IC:7442A-9412ND

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

IMPORTANT: Exposure to Radio Frequency Radiation.

This equipment complies with the IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and any part of your body.

CAN ICES-3 (B)/NMB-3(B)FCC

CE Declaration of Conformity

Manufacturer: Mikrotiks SIA, Brivibas gatve 214i Riga, Latvia, LV1039.

Hereby, Mikrotiks SIA declares that the radio equipment type RouterBOARD is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<https://mikrotik.com/products>

MPE statement

This equipment complies with EU radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body, unless specifically stated otherwise in page 1 of this document. In RouterOS you must specify your country, to make sure local wireless regulations are observed.

Frequency bands terms of use

Frequency range (for applicable models)	Channels used	Maximum Output Power (EIRP)	Restriction
2412-2472 MHz	1 – 13	20 dBm	Without any restriction to use in all EU Member States
5150-5250 MHz	26 – 48	23 dBm	Restricted to indoor use only*
5250-5350 MHz	52 – 64	20 dBm	Restricted to indoor use only*
5470-5725 MHz	100 – 140	27 dBm	Without any restriction to use in all EU Member States


- It is the customer's responsibility to follow local country regulations, including operation within legal frequency channels, output power, cabling requirements, and Dynamic Frequency Selection (DFS) requirements. All Mikrotik radio devices must be professionally installed!

Note. Information contained here is subject to change. Please visit the product page on www.mikrotik.com for the most up to date version of this document.

Connect the power adapter to turn on the device. Open 192.168.88.1 in your web browser, to configure it. More information on {+}<https://mt.lv/help+>

<https://help.mikrotik.com/docs/display/UM/hAP+lite>

Documents / Resources

	MikroTik RB941-2ND Hap Lite Classic Routerboard [pdf] User Manual RB941-2ND, Hap Lite Classic Routerboard
-------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------

References

- [▲ Collaboration software for software, IT and business teams](#)
- [📁 MikroTik Routers and Wireless](#)
- [📁 Pages - User manuals - MikroTik Documentation](#)
- [📁 hAP lite - User manuals - MikroTik Documentation](#)
- [📁 User Manuals - User manuals - MikroTik Documentation](#)
- [📁 Wireless for home and office - User manuals - MikroTik Documentation](#)
- [📁 Labeled content - User manuals - MikroTik Documentation](#)
- [📁 Labelled content - User manuals - MikroTik Documentation](#)

-  [MikroTik Routers and Wireless - Products: hAP lite](#)
-  [Manual:TOC - MikroTik Wiki](#)
-  [MikroTik Routers and Wireless](#)