




Milesight SC541 X1 Sensing Camera User Guide

[Home](#) » [Milesight](#) » Milesight SC541 X1 Sensing Camera User Guide 



BETTER INSIDE, MORE IN SIGHT
QUICK START GUIDE
SC541



Contents

- [1 Packing List](#)
- [2 Hardware Introduction](#)
- [3 Installation](#)
- [4 Access from Web Browser](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Packing List



Hardware Intro duction





Installation



Installation Notes

- Before installing the device, please make sure the device has two AA batteries installed or use Type-C power supply.
- Need to use bracket or other way to fix the device, there are bracket holes on the back and bottom of the device.
- To avoid reflections from the meter surface, make sure the device is angled to the meter, not directly in front of it.
- The best distance between the device and the target to be captured is 15~25cm, you can also log in to the webpage to view the live image stream for adjustment.

Access from Web Browser

SC541 device provides user-friendly web GUI for configuration and users can access it via Wi-Fi.
The default IP address: 192.168.1.1

Step1:

Press the external button once to wake up the device.

Step2:

Connect the device to WiFi, then type 192.168.1.1 to access the web GUI.

Note:

When there is no operation for 5 minutes, the device will enter sleep mode. To wake up the device again, please press the external button again.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Documents / Resources

	Milesight SC541 X1 Sensing Camera [pdf] User Guide 2AYHY-SC541, 2AYHYSC541, SC541, X1 Sensing Camera, SC541 X1 Sensing Camera, Sensing Camera, Camera
	Milesight SC541 X1 Sensing Camera [pdf] User Guide SC541, SC541 X1 Sensing Camera, X1 Sensing Camera, Sensing Camera, Camera

References

- [Support : IoT Support](#)