



MiSensors B08LXQ2676 MiTag Multi Sensor User Guide

[Home](#) » [MiSensors](#) » **MiSensors B08LXQ2676 MiTag Multi Sensor User Guide** 



WELCOME TO THE
MISENSOR FAMILY

Contents

- [1 STEP 1 ACCOUNT SETUP](#)
- [2 STEP2 MIGATEWAY SETUP](#)
- [3 MITAG SENSOR SETUP](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

STEP 1 ACCOUNT SETUP

Create your MiSensors administration account.

1. CREATE ACCOUNT

Visit signup.misensors.com and click "Sign Up to create your Admin account."

2. CONFIRM EMAIL

After creating your account you will receive an email to confirm your account.

3. EIIBEGIN SETUP

Once your account is confirmed you will need to select the 'Begin Setup' button.

4. ACTIVATION CODE


Enter the activation code found on the front of this card when requested during the onboarding process.

5. COMPLETE THE ONBOARDING STEPS

Follow the steps to complete your account setup.

STEP2 MIGATEWAY SETUP


Plug in the USB cable to the USB power adapter, then the USB cable into the gateway. Connect MiGateway using the ethernet cable into an RJ45 Ethernet port on your router/switch or cellular gateway.



Note: A QR code and MAC Address are located on the gateway Label. It will be used to add your Gateway to the MiSensors software application.

MITAG SENSOR SETUP










Before you install your MiTag Sensors be sure to add them to your account in the MiSensors software application. Use the MiTag Mounting Bracket for a secure installation. Hold the Alarm button for 3-5 seconds to activate transmitting mode. All lights will begin to blink and then a blue light will blink once it is transmitting.



Note: A QR code and MAC Address are located on the MiTag Labels. It will be used to add your Sensor to the MiSensors software application.

- 1 – MIGATEWAY
- 2 – MITAG MULTI-SENSORS
- 2 – MITAG MOUNTING BRACKETS
- 1 – ETHERNET CABLE
- 1- USB POWER CABLE
- 1 – USB POWER ADAPTER
- 2 – PROXIMITY MAGNETS

8 – #6 X 1.0" SCREWS
8 – M5 WALL ANCHORS

1 – MIGATEWAY	
2 – MITTAG MULTI-SENSORS	
2 – MITTAG MOUNTING BRACKETS	
1 – ETHERNET CABLE	
1- USB POWER CABLE	
1 – USB POWER ADAPTER	
2 – PROXIMITY MAGNETS	
8 – #6 X 1.0" SCREWS	
8 – M5 WALL ANCHORS	

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and all persons. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Canadian Compliance Statement This device contains license-exempt transmitters)/receiver(s) that comply with Innovation, Science, and Economic Development Canada license-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

NOTE: This equipment complies with RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

REMOTE MONITORING MADE EASY
www.MiSensors.com
FOR ADDITIONAL INFORMATION & SUPPORT:



[MiSensors.com](http://www.MiSensors.com)



support@MiSensors.com



866.MiSensors

Documents / Resources

	<p>MiSensors B08LXQ2676 MiTag Multi Sensor [pdf] User Guide MITAG, 2AXOO-MITAG, 2AXOOMITAG, B08LXQ2676 MiTag Multi Sensor, B08LXQ2676, MiTag Multi Sensor</p>
---	---