



MONSTER Huma H5 V3.2 Notebook User Manual

[Home](#) » [Monster](#) » **MONSTER Huma H5 V3.2 Notebook User Manual** 

Contents

- [1 MONSTER Huma H5 V3.2 Notebook](#)
- [2 Product Information](#)
- [3 Product Usage](#)
- [4 Start Menu](#)
- [5 Safety Notices](#)
- [6 Configuration information](#)
- [7 Device overview](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



MONSTER Huma H5 V3.2 Notebook

MONSTER Huma H5 V3.2 Notebook-fig1

Product Information

The H5 V3.2 is a device that allows you to get online, connect to Bluetooth devices, sign in with a Microsoft account, and access various apps, settings, and files from the Start menu. It has an Action Center that allows you to quickly open or close tablet mode, rotation mode, flight mode, VPN, power-saving mode, networking, Bluetooth, location, project, and adjust brightness. The device comes with safety notices that should be read carefully before use.

Product Usage

Basic Operation

- **Boot:** Press the power button to turn on the device.
- **Shutdown:** Select the Power icon from the Start menu and choose Shutdown.
- **Standby:** Press the power button once to put the device in standby mode.

- **Restart:** Select the Power icon from the Start menu and choose Restart.
- **Get online:** Connect to a Wi-Fi network to get online.
- **Connect to Bluetooth devices:** Make your Bluetooth device discoverable and follow the prompts to connect to the H5 V3.2. Consult the manual of your Bluetooth device for more information on how to make it discoverable.
- **Sign in with a Microsoft account:** Go to Settings > Accounts > Email & app accounts and select Add a Microsoft account. Follow the prompts to add your Microsoft account.

Start Menu

- **Apps, settings, files:** All these can be found on the Start menu. Just select the Start button on the taskbar. You can pin apps and programs, or move and regroup tiles. If you need more space, resize the Start menu.
- **Your apps and programs:** Open File Explorer, Settings, and other apps you use often from the left side of the Start menu. Scroll down the app list to see all apps and programs alphabetically, from A to Xbox.
- **Pin your apps:** Select the app you want to pin from the Start menu, then press and hold (or right-click) it. Select Pin to Start. You can resize the app tile by pressing and holding (or right-clicking) the tile and selecting Resize. Drag and drop apps from the apps list to pin them to the Start menu as tiles.
- **Group your apps:** Move apps up or down until a group divider appears, then release the tile. To give your new group a name, select the open space above your new group and type a name.

Action Center

Click in the lower right corner of the taskbar to open the Action Center. You can quickly open or close tablet mode, rotation mode, flight mode, VPN, power-saving mode, networking, Bluetooth, location, project, and adjust brightness.

You no longer need to open Action Center to see how many notifications you have—the number on the Action Center icon shows you how many notifications are waiting for you. Other apps pinned to the taskbar can also show the number of notifications you've missed.

Safety Notices

Read all safety notices carefully before using the H5 V3.2.
Follow all instructions that appear on the screen.

Safety Notices

- Avoid dropping the unit on the ground or by another strong impact.
- Do not use in extreme cold, heat (<35°C), excessively humid, dusty environments, long-term use, do not let the machine in the sun.
- Try to avoid using in magnetic, strong electrostatic environments.


- Once water or other liquids to spill on the unit, should be immediately shut down, the unit wipe dry before use.
- Do not use any cleaner or other liquid containing chemical ingredients to clean the machine to avoid corrosion and moisture damage, if absolutely necessary cleaning, use a soft, dry cloth or paper towel.
- The company's hardware and software were non-normal operation, the machine repair or other data loss resulting from unforeseen circumstances or delete is not responsible for, nor bear the losses caused.
- When using the file card of T-Flash, do not remove the card to avoid damage to the memory card or device.
- Please feel free to back up your important data to avoid loss.
- Do not disassemble the unit, otherwise it will lose warranty rights.
- Manual and related software updates at any time without notice, and Quick Start Guide found discrepancies, please prevail in kind.

Configuration information

Intel® Core™ i7-1165G7 Processor,12M Cache, up to 4.70 GHz
GPU
Intel® Iris® Xe Graphics
RAM
2 x DDR4 SODIMM
SSD
1x M2 2280 PCIE Gen4 (SATA/PCle)
Display
15,6" FHD, 16:9 Narrow Border
I/O Ports
DC Jack Ø3.5*1.35mm HDMI 1*Standart(HDMI 2.0) USB Type-A 1*USB3.2 Gen1 USB Type-C 1*TBT4.0 Audio Jack Ø3.5mm USB Type-A 1*USB3.2 Gen1 Cardreader 1*Micro SD

WIFI
Intel WiFi6 AX series
Bluetooth
BT 5.1
Camera
2.0 megapixel
Power adapter
DC Output (19V – 3.42A) 65W
Battery
11.4V / 4700mAh
Operating system
Windows 11

Device overview



1. 3,5mm DC Interface
2. USB Port
3. HDMI Interface
4. Thunderbolt

5. Power Indicator
6. Charging Indicator
7. TF Card Slot
8. USB Port
9. 3,5mm DC Interface
10. Fingerprint

Boot

Press the power button 3-5 seconds and release the seed.

(Note: There is no response when you press the power button, the device may need to recharge).

Shutdown

1. Press 4 seconds to force shutdown.
2. Hit the Start menu, click on the “Power” button, select “Off”



Standby

In the power-on state Short press the power button to enter standby or wakes


Restart

Open the Start menu, click on the “Power” button, select “Restart” button.

Get Online

To connect to a Wi- Fi network in Windows, select the Network icon [ or ] (or on the taskbar. Select the Wi-Fi network you want > Connect, then type the password and follow the instructions. That's it—you're connected!

This icon  will appear in the taskbar.




After you're connected, you're ready to set up email, browse the web, and do a whole lot more online. If Wi- Fi isn't available, or you just want the assurance of a wired connection, the Ethernet cable is your friend—just connect your PC to your router or modem, and then do your thing.

Connect to Bluetooth devices


Thanks to Bluetooth, you can use all sorts of wireless devices with your Win-dows PC—Bluetooth headphones, speakers, phones, fitness trackers—just to name a few. Start by pairing your Bluetooth device with your PC. The way you do this depends on the kind of Bluetooth you're using.

To connect a Bluetooth headset, speaker, or another audio device.

1. Turn on your Bluetooth audio device and make it discoverable. The way you make it discoverable depends on the device. Check the device or visit the manufacturer's website to learn how.
2. Turn on Bluetooth on your PC if it's not on already.

To do this, on the taskbar, select action center  Bluetooth.



3. In action center, select Connect> the device name.



4. Follow any more instructions that might appear. Otherwise, you're done and connected. Your Bluetooth device and PC will usually automatically connect anytime the two devices are in range of each other with Bluetooth turned on.

To connect a Bluetooth mouse or other devices

1. Turn on your device and make it discoverable.


2. Select the Start  button, then select Settings  Devices>Bluetooth.

3. Turn on Bluetooth > select the device > Pair.

4. Follow any more instructions if they appear.

Sign in with a Microsoft account

Select the Start  button, then select Settings  > Accounts > Email & app accounts. Under Accounts used by other apps, select Add a Microsoft account. Follow the prompts to add your Microsoft account. You may need to verify your identity by entering a confirmation code.




Start Menu

Apps, settings, files—they can all be found on the Start  menu. Just select the Start button on the taskbar. Next, make it yours by pinning apps and programs, or moving and regrouping tiles. If you need more space, resize the Start menu.

Your apps and programs—right at your fingertips

Open File Explorer, Settings, and other apps you use often from the left side of the Start menu. Scroll down the app list to see all apps and programs alphabetically, from A to Xbox.




1. Menu (expands to show names for all menu items)
2. Account
3. File Explorer
4. Settings
5. Power

Organize your apps

To see live updates on what's happening in your world—such as new email, your next appointment, or the weekend weather. When you pin an app, it's added to the Start menu as a new tile.

Pin apps to Start.

1. Select the Start  button, then press and hold (or right-click) the app you want to pin.
2. Select Pin to Start.




Once you pin a new app, resize it. Press and hold (or right-click) the app tile, select **Resize**, and then choose the tile size you want.

Tip

Drag and drop apps from the apps list to pin them to the Start menu as tiles.


Group your apps

After you've pinned an app, move it into a group. To create a new group of tiles, move an app's tile up or down until a group divider appears, and then release the tile. Move apps in or out of the group to organize your tiles for perfect productivity.




To give your new group a name, select the open space above your new group and type a name.


Action Center

Click in the lower right corner of the taskbar  to open the "Action Center", you can quickly open or close the tablet mode, rotation mode, flight mode, VPN, power-saving mode, the networking, Bluetooth, location, project and adjust brightness.



You no longer need to open action center to see how many notifications you have—the number on the action center icon  shows you how many notifications are waiting for you. Other apps pinned to the taskbar can also show the number of notifications you've missed.

Documents / Resources

	<p>MONSTER Huma H5 V3.2 Notebook [pdf] User Manual Huma H5 V3.2 Notebook, Huma H5 V3.2, Notebook</p>
-------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------

References

- yoursmarthome.de steht zum Verkauf!