



# mooas Multi Hexagon Clock Timer Instruction Manual

[Home](#) » [mooas](#) » mooas Multi Hexagon Clock Timer Instruction Manual 

## Contents

- [1 mooas Multi Hexagon Clock Timer](#)
- [2 Composition](#)
- [3 Features](#)
- [4 Time Configuration](#)
- [5 Precaution](#)
- [6 Specification](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

**Mooas**

**mooas Multi Hexagon Clock Timer**



## Composition

- Multi-Hexagon Clock Timer 2nd Generation
- Manual

## Features

- 3 in 1: Clock, Alarm and Timer multi-function
- Various usage with 6 timer variation: studying, cooking, working etc
- Timer configuration applicable for Pomodoro Technique and Tabata workout
- No need for an additional setting using simple operation
- Two ways alarm method with sound and alarm indicator
- Convenient to use in quiet spaces such as study room with mute alarm mode
- Pause, reset, and time can be changed while using
- Count up : can be set up to 99 min 59 sec 12/24H mode and rotating display for user convenience
- Convenient time check with backlight
- Neat color and simple design

## Time Configuration

- White : 3/5/25/30/10/20 Minutes
- yellow : 5/10/50/30/25/60 Minutes
- Mint: 1/3/5/10/30 Minutes/TBT

A White / Yellow timer can be used for the Pomodoro Technique and Mint timer for Tabata workout.

- Pomodoro: 25 minutes for study or work followed by 5 minutes of rest
- Tabata: Interval training repeating high-intensity workout followed by rest or a few sets of low-intensity workout

## Details




1. Clock mode
2. Timer mode
3. Count up : when alarming is ringing, the count up starts with a + mark
4. Clock mode : Hour
  - Timer mode Minute
  - Alarm setting Alarm "Hour"
  - [Mint] Tabata mode- the number of sets
5. Clock mode : Minute
  - Timer mode Second
  - Alarm setting Alarm "Minute"
  - (Mint) Tabata mode – second
6. Afternoon mark in 12B mode
7. Alarm
8. Clock/Timer mode setting switch button
  - Clock mode / Timer mode
9. Battery Cover
10. Time/Alarm time/Alarm ON,OFF setting button
11. Increase numbers
12. Decrease numbers
  - Alarm mode switch button
  - Sound mode / Mute mode
  - [Mint] T20 : 20 second mode
  - T 30 : 30 second mode

### How to use


Slide down to open the battery cover like FIG1

After inserting 2 AAA battery in the correct polarity (+.-), FIG2  
slide the cover upwards with open guideline facing up like FIG3



### Mode setting (Clock mode, Timer mode)

- Clock mode : Slide the mode setting switch button toward left clock icon CLOCK mark displays on the screen.

- Timer mode Slide the mode setting switch button toward right timer icon  TIMER mark displays on the screen.

## Time & Alarm time setting

- Long press the SET button in the clock mode to set time and alarm time.
  - Default setting : 24B mode, 0:00 Alarm time Of 7:00
  - Setting order: 12/24H mode –Hour Minute — Alarm •Hour” Alarm ‘Minute
- Press A/ V button to change numbers. Long press the button to increase decrease the numbers consecutively, press SET button to confirm the setting and go to the next step.
- If there is no button operation for about 15 seconds while setting, the setting is confirmed and going back to the clock display afterward.,
- In 12H mode setting, PM icon appears in the afternoon. AM icon does not appear separately.



## Alarm and snooze setting

1. In clock mode, short press SET button to turn on/Off the alarm When the alarm is activated, AL icon is displayed on the screen.
2. When the alarm rings, press any button at the back to stop the alarm. Alarm icon is displayed on the screen and the alarm rings at the same time next day
3. When the alarm rings and there is no button operation, the alarm rings for 1 minute With the alarm icon blinking. When the alarm rings, backlight is on for 10 seconds.
4. If you turn the timer to other sides when the alarm is ringing, the snooze is activated. When the snooze Starts, AL icon blinks. Snooze rings for 9 Min. and the number of repetition is not limited.

## How to use

Press any button at the back to stop the snooze. When the snooze stops, AL icon stops blinking and the alarm rings at the same time next day.

## Timer setting

1. After setting timer mode, choose sound or mute mode using alarm mode switch button
  - Sound Mode  : When the alarm is ringing, red alarm indicator blinks with alarm sound
  - Mute Mode  Red alarm indicator blinks only
  - When the alarm is ringing, the backlight is on for about 10 sec.
2. Place the time side you want face up and the timer starts with a beep sound, the remaining time is on the LCD screen.

### Timer Operation TIP

- Pause: Place the LCD screen to face up.
- Restart: Turn the time side face up again, the timer will run continuously.
- Reset: Place the LCD screen to face down.
- Time change: Turn the different time side face up, the timer restarts with changed time.

- An alarm is ringing with LCD backlight when comes the time set. Red alarm indicator blinks 10 seconds earlier before the alarm, the indicator turns off as well with the end of the alarm.
- Press SET ▲, ▼ buttons end the alarm
- If there is no button operation while ringing, the alarm rings for 1 minute and ends.
- When alarming is ringing, the count up starts with + mark on the screen. Count up is available up to 99 min 59 sec.

### **TBT (Tabata) Timer Operation (Mint only)**

- Tabata timer supports repetition of workout for 20 or 30 seconds and rest for 10 seconds.
- Use the alarm mode switch to set desired time. (T 20 : 20-second mode / T30 : 30 second mode)
- 20-second / 30-second work out followed by 10-second rest is 1 set. Once 1 set is finished, the number of sets are displayed on the left.

### **Backlight**

Turn the timer or press the SET ▲, ▼ buttons to turn on the backlight. The backlight is turned off in 10 seconds to minimize power consumption.

### **Precaution**

- Do not use other than the intended purpose Watch out for shock and fire
- Do not use under direct sunlight or areas with high temperature and humidity
- Keep Out of reach of children.
- Do not disassemble, repair or modify if the product is damaged or not functioning properly.
- Place the battery in the correct polarity Of (+), (-) to prevent leakage and rupturing
- Do not disassemble, short or heat the battery
- Do not mix with other batteries.
- use the new battery and do not mix it with the used one.
- Do not dispose the used batteries with general waste. Please dispose them separately in a battery disposal bin
- Please remove the batteries when not in use for a long time

### **Specification**


- Product: Mooas Multi-hexagon Clock Timer 2nd Generation
- Model: MT-C4
- Components:” Clock timer, Manual
- Size: 62.5 x 70.4 x 60 mm (W x D x H)
- Material: ABS
- Weight”:About 84g (Excluding Battery)
- Power: AAA Battery x 2ea (Not Included)
- Operating Temp: -20°C -50°C
- Manufacturer: Mooas Inc. [www.mooas.com](http://www.mooas.com)
- C/S: +82-31-757 3309

- Address: C-821, Munjeong Hyundai Knowledge Industry Center, 7, Beobwon ro Il-gilf Songpa gu, Seoul, Korea
- MFG Date: Marked Separately / Made in Chin

Copyright 2022. Mooas Inc. All rights reserved. Product specifications may be changed without notice to improve performance.

---

## Documents / Resources

	<p><a href="#">mooas Multi Hexagon Clock Timer</a> [pdf] Instruction Manual Multi Hexagon Clock Timer, Hexagon Clock Timer, Clock Timer, Timer</p>
--	--

## References

- [User Manual](#)