



MOOV Rybit820-NA IOT-BOX User Manual

Home » MOOV » MOOV Rybit820-NA IOT-BOX User Manual

Contents

- 1 MOOV Rybit820-NA IOT-BOX
- **2 Product Usage Instructions**
- 3 Introduction
- **4 Safety Information**
- **5 Product Features**
- **6 Technical Specification**
- **7 FCC Statement**
- 8 Acronyms and
- **Abbreviations**
- 9 Documents / Resources
 - 9.1 References

MOOV

MOOV Rybit820-NA IOT-BOX



Specifications:

Model: Rybit820-NAInput Voltage: 20-56V

• Communication: 4G LTE/3G UMTS WWAN, Bluetooth 5.0

• Features: GPS navigation, audio codec, speaker, telemetry, remote control

Product Usage Instructions

Introduction

Rybit820-NA is designed for bike or ebike management. It supports a wide voltage range, communication systems, GPS navigation, Bluetooth connectivity, and more. Here's how you can use it:

Telemetry and Remote Control:

Use WWAN and BLE 5.0 for telemetry, remote control, location tracking, bike locking/unlocking, and BMS health checks.

Positioning and Navigation:

Utilize the integrated GNSS solution for high-accuracy positioning and navigation.

HMI (Human Machine Interface):

Interact with users using the audio codec and speaker. Voice prompt files can be updated via the OTA service.

Low Power Consumption:

The system enters standby mode when inactive. It can be woken up via WWAN, BT, IMU, timer, or button. A backup battery ensures system operation continuity.

OTA (Over-The-Air):

Supports OTA upgrades for efficient system updates.

Safety Information

Read all safety warnings before use to prevent electric shock or injury. Do not disassemble the device; have it serviced by a qualified repair person.

Battery:

CAUTION: Internal Lithium battery – do not disassemble or dispose of improperly.

Radio Wave Propagation:

WWAN and GPS may not function properly in areas with poor radio signal reception.

Product Features

· Power Source:

Input voltage is 48V via a 5-pin connector.

· Power-On:

The IOT-Box powers on automatically with applied power.

Standby and Wakeup:

The system enters standby mode when inactive and can be woken up by various events.

· Voice Prompt:

Interact with users using the integrated audio codec and speaker with flash memory storage for voice prompts.

· CAN Bus:

Communicate with the motor controller, BMS, hub lock, and battery lock via the integrated CAN Bus interface.

FAQ:

• Q: How do I update the voice prompt files?

A: Voice prompt files can be updated via the OTA service. Simply follow the instructions provided in the user manual to perform the update.

• Q: What should I do in case of battery issues?

A: If you encounter any battery-related problems, do not attempt to disassemble the device. Contact a qualified repair person for assistance to ensure safety.

Introduction

- Rybit820-NA is designed for sharing and rental bike or ebike management systems. Rybit820-NA supports a
 wide range of voltage inputs from 20 to 56V, integrated 4G LTE/3G UMTS WWAN communication system, GPS
 navigation system, Bluetooth 5.0 (Low Energy), high performance/low power consumption architecture, audio
 codec and speaker. In addition, MOOV provides a total solution from cloud management to diagnostic in every
 single unit and also supports locking management and BMS health checks.
- Telemetry and Remote Control

Through WWAN and BLE 5.0, you can easily accomplish telemetry, remote control, location acquisition, lock/unlock bike and BMS health checking.

High-Accuracy Positioning and Navigation
 Integrated GNSS solution, built-in highly customized active ceramic GPS antenna and Qualcomm Gen8C
 GNSS solution to achieve high-accuracy positioning and navigation.

• HMI (Human Machine Interface)

Integrated audio codec and speaker, allowing easy interaction directly with users.

Voice prompt files are stored in the flash memory, which can be updated via OTA service.

• Low Power Consumption

Integrated deep power management, the system will enter standby mode when the service is inactive automatically. The system can be woken up by WWAN, BT, IMU, timer and button. It also built-in a backup battery to keep the system alive when the main battery pack was removed or damaged.

• OTA (Over-The-Air)

Supporting OTA upgrade, including both full and delta methods. Delta upgrade only needs to download different portions, it can reduce transfer time and operation costs.

Safety Information

Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

Qualified Repair Service

There are no user-serviceable parts. Have the device serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the device is maintained.

Battery

CAUTION: This device contains an internal Lithium battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, or puncture the device, and do not dispose of the device in fire or water.

Radio Wave Propagation

Due to the property of radio wave propagation, the WWAN and GPS in this device may not work properly in the tunnel or any other place where the radio signals are hard to receive.

Product Features

Power Source

The rating Input voltage is 48V via 5 pins connector.

Power-On

IOT-Box will power on automatically during the power applied.

Standby and Wakeup

- Standby: No ongoing housekeeping job and service inactive, the system will enter standby mode.
- Wakeup: Can be woken up by WWAN, BT, IMU, timer and button event.

Voice Prompt

Integrated audio codec and speaker, allowing easy interaction directly with users. Voice prompt files are stored in the flash memory, it can be updated via OTA service.

CAN Bus

Integrated CAN Bus interface to communicate with motor controller, BMS, hub lock and battery lock. It can be recovered automatically or isolated failure node(s) during bus health/conditions change.

WWAN and BT 5.0

WWAN supports LTE Cat 1/B2 B4 B12, DL 10 Mbps, UL 5 Mbps. WCDMA/B2 B4 B5, DL 384 Kbps, UL 384 Kbps. Bluetooth 5.0 (Low Energy), 1 Mbps.

Backup Battery

Built-in a 3.7V/3400mAh backup battery to keep system alive when main battery pack was removed or damaged

Technical Specification

Hardware Specification

General Specifications

• Dimension: 85mm*45mm*40mm

• Weight: 250g

• Operating Temp: -10°C to +55°C

• Storage Temp: -20°C to +60°C

· Connectors:

- 5 pins (2 pins for power input, 2 pins for CAN bus and 1 pin for I/O)
- 4 pins (2 pins for LED and 2 pins for button)

Electronic Specifications

• Input Voltage: 48V (typical)

• Backup Battery: 3.7V/3400mAh

• Speaker: 2W (Rating)100dB@10cm 1KHz

• Lock/Unlock duration: Depends on network condition, less than 5 secs typically Built-in IMU Sensor

RF Module

Rybit820-NA provides data communication between LTE-FDD and WCDMA networks, it also supports GNSS and BT5.0.

| Model | LTE-FDD | WCDMA | GNSS | BT 5.0 |
|-------------|-----------|----------|------|--------|
| Rybit820-NA | B2/B4/B12 | B2/B4/B5 | YES | YES |

GNSS include GPS L1

- Cold start positioning < 35s (open conditions)
- Hot start positioning < 1s (open conditions)
- Positioning accuracy < 5m (open conditions)

BT5.0 supports 2402~2480MHz bandwidth, and output power is set to 0 dBm

• LTE-FDD: 23 dBm ±2.0dB (Power Class 3)

WCDMA: 24 dBm +1/-3dB (Power Class 3)

Caution

- Risk of explosion if battery replaced by an incorrect type.
- · Dispose of used batteries according to the instructions.
- Please make sure the temperature for the device will be -10 to 55°C.

• LTE-FDD: 23 dBm ±2 dB (Power Class 3)

WCDMA: 24 dBm +1/-3dB (Power Class 3)

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Acronyms and Abbreviations

| ADC | Analog to Digital Converter |
|------|---|
| ВТ | Bluetooth |
| CE | European Conformity |
| CMOS | Complementary Metal Oxide Semiconductor |
| DC | Direct Current |
| DL | Downlink |
| EIA | Electronic Industries Association |
| EMC | Electromagnetic Compatibility |
| ESD | Electro-Static Discharge |
| FDD | Frequency Division Duplex |
| GPIO | General-Purpose I/O |
| GPS | Global Positioning System |
| GPRS | General Packet Radio Service |
| I2C | Inter Integrated Circuit |
| 128 | Inter-IC Sound |
| LDO | Low-Dropout |
| LED | Light Emitting Diode |
| LTE | Long Term Evolution |
| NC | Not Connected |
| PCB | Printed Circuit Board |
| RTC | Real-Time Clock |
| SMT | Surface Mount Technology |
| SPI | Serial Peripheral Interface |
| TIS | Total Isotropic Sensitivity |
| TRP | Total Radiated Power |

| TVS | Transient Voltage Suppressor |
|------|---|
| UART | Universal Asynchronous Receiver-Transmitter |
| UMTS | Universal Mobile Telecommunications System |
| USIM | Universal Subscriber Identity Module |
| WWAN | Wireless Wide Area Network |

 $Copyright © 2023 \; MOOV \; TECHNOLOGY \; (S) \; PTE. \; LTD. \; All \; rights \; reserved. \; Reproduction \; in \; whole \; or \; in \; part \; is prohibited \; without the prior \; written \; permission \; of the \; copyright \; holder.$

Documents / Resources



MOOV Rybit820-NA IOT-BOX [pdf] User Manual Rybit820-NA IOT-BOX, Rybit820-NA, IOT-BOX, BOX

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.