



# MOXA EDS-4012 Series EtherDevice Switch Installation Guide

[Home](#) » [MOXA](#) » MOXA EDS-4012 Series EtherDevice Switch Installation Guide 

## Contents

- [1 MOXA EDS-4012 Series EtherDevice Switch](#)
- [2 Package Checklist](#)
- [3 Default Settings](#)
- [4 Panel Views of EDS-G4012 Series](#)
- [5 Installation](#)
- [6 Wiring Requirements](#)
  - [6.1 Grounding the Moxa EDS Series](#)
- [7 Communication Connections](#)
- [8 Console Port Connection](#)
- [9 USB Connection](#)
- [10 Reset Button](#)
- [11 Turbo Ring DIP Switch Settings](#)
- [12 LED Indicators](#)
- [13 Specifications](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)



**MOXA EDS-4012 Series EtherDevice Switch**



## Package Checklist

The EDS-G4012 Series industrial DIN-rail EtherDevice Switch (EDS) is shipped with the following items. If any of these items are missing or damaged, please contact your customer service representative for assistance.

- 1 EDS-G4012 Ethernet switch
- Quick installation guide (printed)
- Warranty card
- Substance disclosure table
- Product certificate of quality inspection (Simplified Chinese)
- Product notices (Simplified Chinese)

**NOTE** You can find information and software downloads on the relevant product pages located on Moxa's website: [www.moxa.com](http://www.moxa.com)


## Default Settings

- **IP address:** 192.168.127.253
- **Subnet Mask:** 255.255.255.0
- **Username:** admin
- **Password:** moxa


## Panel Views of EDS-G4012 Series

### Front Panel View


## EDS-4012-4GC



## EDS-4012-4GS




## EDS-4012-8P-4GS



1. 100BaseT(X) LED indicator
2. 10BaseT(X) LED indicator
3. 10/100BaseT(X) ports, ports 1 to 8
4. 10/100/1000BaseT(X) or 100/1000BaseSFP combo ports, ports G1 to G4
5. 100/1000BaseSFP LED indicator
6. 100/1000BaseSFP ports, ports G1 to G4
7. Grounding connector screw
8. Terminal blocks for power input, digital input, and relay output
9. LED indicators: STATE (S), FAULT (F), PWR1 (P1), PWR2 (P2), MSTR/HEAD (M/H), CPLR/TAIL (C/T), SYNC
10. Console port (RJ45, RS-232)
11. USB storage port (type A, currently disabled)
12. Model name
13. SmartPoE LED indicator of PoE





### Bottom Panel View



1. microSD card slot (currently disabled)
2. Reset button
3. DIP switches for Turbo Ring, Ring Master, and Ring Coupler

### Mounting Dimensions

Unit: mm (inch)




## DIN-rail Mounting

The DIN-rail mounting kit is fixed to the back panel of the EDS device when you take it out of the box. Mount the EDS device on corrosion-free mounting rails that meet the EN 60715 standard.

## Installation

**STEP 1**—Insert the upper lip of the DIN rail into the DIN-rail mounting kit.


**STEP 2**—Press the EDS device towards the DIN rail until it snaps into place.



#### Removal

**STEP 1**—Pull down the latch on the mounting kit with a screwdriver.

**STEP 2 & 3**—Slightly pull the EDS device forward and lift up to remove it from the DIN rail.




**NOTE** Our DIN rail kit now utilizes a quick release mechanism to make it easier for users to remove the DIN rail from the EDS device.


### Wall Mounting (Optional)

For some applications, you will find it convenient to mount the Moxa EDS device on a wall, as shown in the following illustrations:

- **STEP 1**—Remove the aluminum DIN-rail attachment plate from the rear panel of the EDS device, as illustrated in the diagram on the right.



- **STEP 2**—Mounting the EDS device on a wall requires six screws. Use the EDS device, with wall mount plates attached, as a guide to mark the correct locations of the six screws. The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown in the figure on at right.




**NOTE** Before tightening the screws into the wall, make sure the screw head and shank size are suitable by inserting the screw through one of the keyhole-shaped apertures of the Wall Mounting Plates.

**NOTE** Do not screw the screws in all the way—leave about 2 mm to allow room for sliding the wall mount panel between the wall and the screws.

- **STEP 3**—Once the screws are fixed to the wall, insert the four screw heads through the wide parts of the keyhole-shaped apertures, and then slide the EDS device downwards, as indicated in the figure at the right. Tighten the four screws for more stability.





## Wiring Requirements

### Safety First!

External metal parts are hot. Take the necessary precautions if you are required to handle the device.

### ATTENTION

In order to ensure reliable operations, please make sure the operating temperature of the environment does not exceed the specifications. When mounting an EDS device with other operating units in a cabinet without forced ventilation, a minimum of 4 cm space on both the left and right of the switch is recommended.

### Safety First!

Be sure to disconnect the power cord before installing and/or wiring your EDS device. Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size. If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

Be sure to read and follow these important points below:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.

NOTE Do not run signal or communications wiring and power wiring through the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.

- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- You should separate input wiring from output wiring.
- We advise that you label the wiring to all devices in your system.

## Grounding the Moxa EDS Series

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.

### ATTENTION


This product is intended to be mounted to a well-grounded mounting surface such as a metal panel.

### Suggested Wire Type for Wiring Relay Contact (R), Digital Input (DI), and Power Inputs (P1/P2)

The EDS device includes two 4-pins 3.5 mm pin-pitch terminal blocks. When wiring the relay contact (R), digital input (DI), and power inputs (P1/P2) for the EDS device, we suggest using the cable type – AWG 18-24 and the corresponding pin type cable terminals.

**NOTE** The wire must be able to withstand at least 105°C and the torque value should be 4.5 lb-in (0.51 N-m).


**NOTE** We suggest the length of the pin type cable terminal is 8 mm. In order to tighten the wire properly, ① use a small flathead screwdriver to press the push-in button beside each terminal of the terminal block connector before and during ② inserting the wire. ③ Release the screwdriver after the wire has been fully inserted. Please refer to the diagram below.




### Wiring the Relay Contact

The EDS device has one set of relay output. This relay contact uses two contacts of the terminal block on the EDS's power module. Refer to the section for detailed instructions on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.

## LV Models




## HV Models



### Relay:


The two contacts of the 4-pin terminal block connector are used to detect user-configured events. The two wires attached to the relay contact form an open circuit when a user-configured event is triggered or there is no power supply to the switch. If a user-configured event does not occur, the relay circuit remains closed.




### Wiring the Redundant Power Inputs

The EDS device includes both high-voltage and low-voltage products. For the low-voltage (LV models) products, there are two power inputs for redundancy; for the high-voltage (HV models) products, there is only one power input. Refer to the instructions and diagram below on how to connect the wires to the terminal block connector on the receptor.

## LV Models




## HV Models



- **STEP 1:** Insert the Positive/Negative DC or Line/Neutral AC wires into the V+/V- or L/N terminals, respectively.

- **STEP 2:** To keep the DC or AC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp button on the front of the terminal block connector.
- **STEP 3:** Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the EDS devices' right side.

## LV Models




## HV Models




### Wiring the Digital Inputs

The EDS device has one set of digital input (DI). The DI consists of two contacts of the 4-pin terminal block connector on the EDS's right-side panel. Refer to the instructions and diagram below on how to connect the wires to the terminal block connector on the receptor.

## LV Models



## HV Models




- **STEP 1:** Insert the negative (ground)/positive DI wires into the  $\perp$ /I terminals, respectively.
- **STEP 2:** To keep the DI wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp button on the front of the terminal block connector.
- **STEP 3:** Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the EDS devices' right side.

### Rotating the Power Module

The power module for the EDS device can be rotated to make it easier to fit your field site application.

- **Step 1:** Remove the two screws that fasten the power module to the EDS device and remove the module.

- **Step 2:** Turn the power module clockwise so that the power, digital input, and relay output connectors can be moved upwards.
- **Step 3:** Replace the module back on to the EDS device.
- **Step 4:** Fasten two screws on to the module.



## Communication Connections

Each EDS-G4012 Series switch has various types of communication ports:


- RJ45 console port (RS-232 interface)
- USB storage port (type A connector, currently disabled)
- 10/100/1000BaseT(X) Ethernet ports
- 10/100/1000BaseT(X) or 100/1000BaseSFP combo ports
- 1000/2500BaseSFP slots
- microSD card slot (currently disabled)

## Console Port Connection

The EDS device has one RJ45 console port (RS-232), located on the front panel. Use either an RJ45-to-DB9 (see the cable following wiring diagrams) to connect the EDS's console port to your PC's COM port. You may then use a console terminal program, such as Moxa PComm Terminal Emulator, to access the EDS that has a baud rate of 115200.

## RJ45 Console Port Pinouts

Pin	Description
1	DSR
2	RTS
3	—
4	TxD
5	RxD
6	GND
7	CTS
8	DTR



## USB Connection

**NOTE** The USB function is currently reserved and may be required in the future. It should be noted that this port cannot be used for charging any devices.

## 10/100/1000BaseT(X) Ethernet Port Connection

1000BaseT(X) data is transmitted on differential TRD+/- signal pairs over copper wires.


### MDI Port Pinouts

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-


### MDI-X Port Pinouts

Pin	Signal
1	Rx+
2	Rx-
3	Tx+
6	Tx-


## 8-pin RJ45



### RJ45 (8-pin) to RJ45 (8-pin) Straight-through Cable Wiring



### RJ45 (8-pin) to RJ45 (8-pin) Cross-over Cable Wiring




### 1000BaseT(X) Ethernet Port Connection

1000BaseT(X) data is transmitted on differential TRD+/- signal pairs over copper wires.

### MDI/MDI-X Port Pinouts

Pin	Signal
1	TRD(0)+
2	TRD(0)-
3	TRD(1)+
4	TRD(2)+
5	TRD(2)-
6	TRD(1)-
7	TRD(3)+
8	TRD(3)-




### 100/1000BaseSFP (mini-GBIC) Fiber Port

The Gigabit Ethernet fiber ports on the switch are 100/1000BaseSFP fiber ports, which require using 100M or 1G mini-GBIC fiber transceivers to work properly. Moxa provides a complete selection of transceiver models for different distance requirements.

The concept behind the LC port and cable is quite straightforward. Suppose that you are connecting devices I and II; contrary to electrical signals, optical signals do not require a circuit in order to transmit data. Consequently, one of the optical lines is used to transmit data from device I to device II, and the other optical line is used transmit data from device II to device I, for full-duplex transmission.

Remember to connect the Tx (transmit) port of device I to the Rx (receive) port of device II, and the Rx (receive) port of device I to the Tx (transmit) port of device II. If you make your own cable, we suggest labeling the two sides of the same line with the same letter (A-to-A and B-to-B, as shown below, or A1-to-A2 and B1-to-B2).

### LC-Port Pinouts




### LC-Port to LC-Port Cable Wiring





## Cable Wiring



### ATTENTION

This is a Class 1 Laser/LED product. To avoid causing serious damage to your eyes, do not stare directly into the Laser Beam.

### Reset Button

The reset button can perform two functions. One is to reset the Ethernet switch to factory default settings by pressing and holding the reset button for longer than five seconds. Use a pointed object, such as a straightened paper clip or toothpick, to depress the reset button. This will cause the STATE LED to blink once a second. After depressing the button for 5 continuous seconds, the STATE LED will start to blink at 4 times/sec. This indicates that factory default settings have been loaded and you can release the reset button. The other function is to reboot the device by depressing reset button for less than five seconds.


### Turbo Ring DIP Switch Settings

The EDS devices are plug-and-play managed redundant Ethernet switches. The proprietary Turbo Ring protocol was developed by Moxa to provide better network reliability and faster recovery time. Moxa Turbo Ring's recovery time is less than 50 ms (Turbo Ring V2) —compared to a 3- to 5-minute recovery time for commercial switches—decreasing the possible loss caused by network failures in an industrial setting.

There are five Hardware DIP Switches for Turbo Ring on the bottom panel of the EDS device that can help setup the Turbo Ring easily within seconds. If you do not want to use a hardware DIP switch to setup the Turbo Ring, you can use a web browser, telnet, or console to disable this function.

**NOTE** Please refer to the Turbo Ring section in User's Manual for more detail information about the setting and usage of Turbo Ring V2.

### Turbo Ring DIP Switch Settings



The default setting for each DIP Switch is OFF. The following table explains the effect of setting the DIP Switch to the ON position.

Remove the rubber cover on the bottom panel of the device to expose the DIP switches.

#### DIP Switch Settings

DIP 1	DIP 2	DIP 3	DIP 4	DIP 5
	<b>ON:</b> Enables the	<b>ON:</b> Enables	<b>ON:</b>	<b>ON:</b> Activates
	default “Ring	this EDS as	Enables the	DIP switch 2,
	Coupling	the Ring	default	3, and 4 to
	(backup)” port	Master.	“Ring	configure
	when DIP switch		Coupling”	Turbo Ring V2
Reserved for future use	4 is already enabled.		port.	settings.
	<b>OFF:</b> Enables the default Ring	<b>OFF:</b> This EDS will not	<b>OFF:</b> This EDS will not	<b>OFF:</b> DIP switch 2, 3,
	Coupling	be the Ring	be the Ring	and 4 will be
	(primary) port	Master.	Coupler.	disabled.
	when DIP switch			
	4 is already			
	enabled.			

**NOTE** You must enable the Turbo Ring (DIP switch 5) first before using the DIP switch to activate the Master and Coupler functions.

**NOTE** If you do not enable any of the EDS switches to be the Ring Master, the Turbo Ring protocol will

automatically choose the EDS switch with the smallest MAC address range to be the Ring Master. If you accidentally enable more than one switch to be the Ring Master, these switches will auto-negotiate to determine which one will be the Ring Master.

## LED Indicators

The front panel of the Moxa EDS-G4012 Series contains several LED indicators. The function of each LED is described in the following table:

### Device LED Indicators

LED	Color	State	Description
STATE	Green	On	When system has passed power- on self-test (POST ) and is ready to run.
		Blinking (1 time/sec)	Press the reset button for five seconds to reset to factory default settings
		Blinking (4 times/sec)	When pressing the reset button depress for 5 seconds to reset to factory default.
		Off	N/A
	Red	On	The system has initially failed the boot-up process <ul style="list-style-type: none"> <li>System Info. Read Fail or EEPROM information error</li> </ul>
		On	<ol style="list-style-type: none"> <li>The relay contact has been triggered</li> <li>The ingress rate limit has been exceeded and the port has entered shut down mode</li> <li>Invalid Ring port connection</li> </ol>

<b>FAULT</b>	<b>Red</b>	<b>Off</b>	When the system boots up and runs correctly or a user- configured event is not triggered.
<b>P1</b>	<b>Amber</b>	<b>On</b>	Power is being supplied to power input PWR.
		<b>Off</b>	Power is not being supplied to power input PWR.
<b>P2</b>	<b>Amber</b>	<b>On</b>	Power is being supplied to power input PWR.
		<b>Off</b>	Power is not being supplied to power input PWR.
<b>MSTR/ HEAD (M/H)</b>	<b>Green</b>	<b>On</b>	When the switch is Master/Head/Root of Turbo Ring/Turbo Chain/Fast RSTP.
		<b>Blinking (4 times/sec)</b>	<ol style="list-style-type: none"> <li>1. The switch has become the Master of Turbo Ring after Turbo Ring has gone down</li> <li>2. The switch is set as Head of Turbo Chain and Turbo Chain has gone down</li> <li>3. The switch is set as the Turbo Ring's Member and the corresponding Ring port is down</li> <li>4. The switch is set as the Turbo Chain's Member/Tail and the corresponding Head-end Chain port is down.</li> </ol>
		<b>Off</b>	When the switch is not the Master/Head/Root of this Turbo Ring/ Turbo Chain/Fast RSTP.

LED	Color	State	Description
CPLR/ TAIL	Green	On	<ol style="list-style-type: none"> <li>1. The switch's ring coupling or dual homing function is enabled.</li> <li>2. The switch is set as the Tail of Turbo Chain.</li> </ol>
		Blinking (4 times/sec)	<ol style="list-style-type: none"> <li>1. The switch is set as the Tail of Turbo Chain and the Chain has gone down.</li> <li>2. The switch is set as the Turbo Chain's Member/ Head and the corresponding Tail-end Chain port is down.</li> </ol>
		Off	When the switch disables the coupling or tail role of Turbo Chain.
System LED (Except PWR)	Green + Amber + Red	Blinking (2 times/sec)	The switch is being discovered/located by the locator function.
System LED (Except PWR)	Green + Amber + Red	Rotate On -> Off Sequentially	The switch is importing/exporting a file via ABC-02-USB or SD card. (currently disabled)

#### Smart PoE LED Indicators

LED	Color	State	Description
Smart PoE+ LED Indicators	Green	On	When the port is connected to IEEE 802.3bt powered device and powered at: <ul style="list-style-type: none"> <li>Single signature (PD) Class 5 to 8</li> <li>Dual signature (PD) Class 1 to 5</li> </ul>
		Off	<ol style="list-style-type: none"> <li>When the power is not being supplied to a powered device (PD)</li> <li>The port is not connected to an IEEE 802.3bt powered device</li> </ol>
	Amber	On	When the port is connected to IEEE 802.3af/at powered device and powered at: <ul style="list-style-type: none"> <li>Single signature (PD) 0 to 4</li> </ul>
		Blinking (4 times/sec)	The PoE power supply has been shut off because of low power budget.
		Off	<ol style="list-style-type: none"> <li>Power is not being supplied to the powered device (PD)</li> <li>The port is not connected to an IEEE 802.3af/at standard PD</li> </ol>

LED	Color	State	Description
	Red	On	Powered device (PD) detection failure
		Blinking (4 times/sec)	Overcurrent or short circuit has occurred on the powered Device (PD)
		Off	PoE is operating normally

#### Ports LED Indicators

LED	Color	State	Description
10M/ 100M/ 1000M Copper top LED	Green	On	When the port is active and links at 1000Mbps.
		Blinking (4 times/sec)	When the port's data is being transmitted at 1000Mbps.
		Off	When the port is inactive or link down.
10M/ 100M/ 1000M Copper bottom LED	Amber	On	When the port is active and links at 10/100Mbps.
		Blinking (4 times/sec)	When the port's data is being transmitted at 10/100Mbps.
		Off	When the port is inactive or link down.
100M/ 1000M (SFP port)	Green	On	When the port is active and links at 1000Mbps.
		Blinking (4 times/sec)	When the port's data is being transmitted at 1000 Mbps.
		Off	When the port is inactive or link down.
		On	When the port is active and links at 100Mbps.



	<b>Amber</b>	<b>Blinking (4 times/sec)</b>	When the port's data is being transmitted at 100M bps.
		<b>Off</b>	When the port is inactive or link down.
<b>1000M/ 2500M (SFP port)</b>	<b>Green</b>	<b>On</b>	When the port is active and links at 2500Mbps.
		<b>Blinking (4 times/sec)</b>	When the port's data is being transmitted at 2500 Mbps.
		<b>Off</b>	When the port is inactive or link down.
	<b>Amber</b>	<b>On</b>	When the port is active and links at 1000M.
		<b>Blinking (4 times/sec)</b>	When the port's data is being transmitted at 1000M.
		<b>Off</b>	When the port is inactive or link down.

## Specifications

<b>Interface</b>	
RJ45 Ports	10/100/1000BaseT(X)
Fiber Ports	EDS-G4012-4GC: 100/1000BaseSFP EDS-G4012-8P-4QGS: 1000/2500BaseSFP
Console Port	RS-232 (RJ45)

Button	Reset button
LED Indicators	STATE (S), FAULT (F), PWR1 (P1), PWR2 (P2), MSTR/HEAD (M/H), CPLR/TAIL (C/T), SYNC
Alarm Contact	1 normally open electromagnetic relay output with current carrying capacity of 1 A @ 24 VDC
Digital Input	1 isolated digital input: +13 to +30V for state "1" -30 to +3V for state "0" Max. input current: 8 mA
<b>PoE</b>	
Total Power Budget	Power Bypass (-LVA model): 240 W @ 48 VDC power input Power Boost (-LVB model): 62 W @ 12 VDC, 150 W @ 24 VDC (120 W for -T model), 180 W @ 48 VDC
PoE Output Voltage	55 VDC
PoE Output Power	15.4 W for the 802.3af standard, 30 W for the 802.3at standard, 36 W in high power mode, 60 W in 802.3bt standard
PoE Output Current	350 mA for the 802.3af standard, 600 mA for the 802.3at standard, 1960 mA for the 802.3bt standard
Overload Current Protection at Port	Present

PoE Pinout	<p>Mode A: Pair 1,2 (V+); Pair 3,6 (V-)</p> <p>Mode B: pair 4,5 (V+); pair 7,8 (V-)</p>
<b>Power</b>	
Pre-installed Power Module	<p>-LV/-LV-T models: PWR-100-LV</p> <p>-HV/-HV-T models: PWR-105-HV-I</p> <p>-LVA/-LVA-T models: PWR-101-LV-BP-I</p> <p>-LVB/-LVB-T models: PWR-103-LV-VB-I</p>
Note	<p>The EDS-G4012 Series supports modular power supplies. The model names and power parameters are determined by the installed power module.</p> <p>For example:</p> <p>EDS-G4012-T + PWR-100-LV = EDS-G4012-LV-T  EDS-G4012-T + PWR-105-HV-I = EDS-G4012-HV-T</p> <p>If you install a different power module, refer to the specifications of the corresponding model. For example, if you replace the power module of the EDS-G4012-LV-T with the PWR-105-HV-I, refer to the specifications of the EDS-G4012-HV-T.</p>
Rated Voltage	<p>-LV/-LV-T models: 12/24/48 VDC, redundant dual inputs</p> <p>-HV/-HV-T models: 110/220 VDC/VAC, single input</p> <p>-LVA/-LVA-T models: 48 VDC, redundant dual inputs</p> <p>-LVB/-LVB-T models: 12/24/48 VDC, redundant dual inputs</p>

Operating Voltage	<p>-LV/-LV-T models: 9.6 to 60 VDC</p> <p>-HV/-HV-T models: 88 to 300 VDC, 85 to 264 VAC</p> <p>-LVA/-LVA-T models: 44 to 57 VDC (&gt;52 VDC for PoE+ output recommended)</p> <p>-LVB/-LVB-T models: 12 to 57 VDC (&gt;52 VDC for PoE+ output recommended)</p>
Rated Current	<p>-LV/-LV-T models: 12-48 VDC, 1.50-0.40 A or 24 VDC, 0.70 A</p> <p>-HV/-HV-T models: 110-220 VAC, 50-60 Hz, 0.30-0.20 A or 110-220 VDC, 0.30-0.20 A</p> <p>-LVA/-LVA-T models: 48 VDC, 5.42 A</p> <p>-LVB/-LVB-T models: 12/48 VDC, 7.46/4.27 A or 24 VDC, 7.26 A</p>
Power Consumption	<p>EDS-G4012-4GC-LV(-T) models: 12.68 W EDS-G4012-4GC-HV(-T) models: 15.8 W EDS-G4012-8P-4QGS-LVA(-T) models:</p> <p>Without PoE: 15.58 W</p> <p>With PoE: Max. 240 W for total PD power consumption @ 48 VDC input</p> <p>EDS-G4012-8P-4QGS-LVB(-T) models:</p> <p>Without PoE: 17.96 W</p> <p>With PoE: Max. 180 W for total PD power consumption @ 48 VDC input; Max. 150 W for total PD power consumption @ 24 VDC input; Max. 62 W for total PD power consumption @ 12 VDC input</p>
Inrush Current	Max. 0.8 A @ 48 VDC (0.1 – 1 ms) (Applies to -LV models)
Overload Current Protection at Input	Present
Reverse Polarity Protection	Present

Connection	2 removable 4-contact terminal blocks
<b>Physical Characteristics</b>	
Housing	Metal, IP40 protection
Dimension	55 x 140 x 122.5 mm (2.17 x 5.51 x 4.82 in)
Weight	EDS-G4012-4GC (-T) models: 881.5 g (1.94 lb) EDS-G4012-8P-4QGS (-T) models: 972 g (2.14 lb)
Installation	DIN-rail mounting, wall mounting (with optional kit)
<b>Environmental Limits</b>	
Operating Temperature	-10 to 60°C (14 to 140°F) for standard models -40 to 75°C (-40 to 167°F) for -T models
Storage Temperature	-40 to 85°C (-40 to 185°F)
Ambient Relative Humidity	5 to 95% (non-condensing)
Altitude	Up to 2000 m  Note: Please contact Moxa if you require products guaranteed to function properly at higher altitude.
<b>Regulatory Approvals</b>	
Industrial Cybersecurity	IEC 62443-4-1, IEC 62443-4-2







Safety	UL 61010-2-201, EN 62368-1(LVD)
EMC	EN 55022/24, EN 61000-6-2/6-4
EMI	FCC Part 15 Subpart B Class A
EMS	EN 61000-4-2 (ESD) Level 4 EN 61000-4-3 (RS) Level 3 EN 61000-4-4 (EFT) Level 4 EN 61000-4-5 (Surge) Level 4 EN 61000-4-6 (CS) Level 3 EN 61000-4-8 Level 4
Shock	IEC 60068-2-27
Free Fall	IEC 60068-2-32
Vibration	IEC 60068-2-6
Rail Traffic (Wayside)	EN 50121-4
Traffic Control	NEMA TS2
<b>Warranty</b>	
Warranty	5 years

## ATTENTION

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.

## Documents / Resources

<div><div>EDS-4012 Series Quick Installation Guide</div><div>Moxa EtherDevice™ Switch</div><div>Version 1.0, October 2021</div><div>Tutorial of Support Contact Information www.moxa.com/support</div><div> © 2021 Moxa Inc. All rights reserved.</div><div></div></div>	<div><div><a href="#">MOXA EDS-4012 Series EtherDevice Switch</a> [pdf] Installation Guide</div><div>EDS-4012 Series, EtherDevice Switch</div></div>
<div><div>EDS-4012 Series Quick Installation Guide</div><div>Moxa EtherDevice™ Switch</div><div>Version 1.0, March 2022</div><div>Tutorial of Support Contact Information www.moxa.com/support</div><div> © 2022 Moxa Inc. All rights reserved.</div><div></div></div>	<div><div><a href="#">MOXA EDS-4012 Series EtherDevice Switch</a> [pdf] Installation Guide</div><div>EDS-4012 Series, EtherDevice Switch, EDS-4012 Series EtherDevice Switch, Switch</div></div>
<div><div>EDS-4012 Series Quick Installation Guide</div><div>Moxa EtherDevice™ Switch</div><div>Version 1.0, March 2022</div><div>Tutorial of Support Contact Information www.moxa.com/support</div><div> © 2022 Moxa Inc. All rights reserved.</div><div></div></div>	<div><div><a href="#">MOXA EDS-4012 Series EtherDevice Switch</a> [pdf] Installation Guide</div><div>EDS-4012 Series EtherDevice Switch, EDS-4012 Series, EtherDevice Switch, Switch</div></div>

References

- [M Moxa - Your Trusted Partner in Automation](#)
- [M Moxa - Support](#)