

NICE SpA On/Off Control2 NICE On/Off-Control2 Manual

Contents

- 1 NICE SpA On/Off Control2 SKU: NICE On/Off-Control2
- 2 On/Off Control2
 - 2.1 SKU: NICE On/Off-Control2
 - 2.2 Quickstart
 - 2.3 Important safety information
 - 2.4 What is Z-Wave?
 - 2.5 Product Description
 - 2.6 Prepare for Installation / Reset
 - 2.6.1 Safety Warning for Mains Powered Devices
 - 2.7 Inclusion/Exclusion
 - 2.8 Quick trouble shooting
 - 2.9 Association – one device controls an other device
 - 2.9.1 Association Groups:
 - 2.10 Configuration Parameters
 - 2.10.1 Parameter 1: Restore state after power failure
 - 2.10.2 Parameter 154: First channel – auto off
 - 2.10.3 Parameter 155: Second channel – auto off
 - 2.10.4 Parameter 20: Switch type
 - 2.10.5 Parameter 200: Voltage measurement
 - 2.10.6 Parameter 201: Voltage value for notification
 - 2.10.7 Parameter 202: Outputs mode
 - 2.10.8 Parameter 24: Buttons orientation
 - 2.10.9 Parameter 40: First button – scenes sent
 - 2.10.10 Parameter 41: Second button – scenes sent
 - 2.11 Technical Data
 - 2.12 Supported Command Classes
 - 2.13 Explanation of Z-Wave specific terms
 - 2.13.1 References
 - 2.14 Related Posts

NICE SpA

On/Off Control2

SKU: NICE On/Off-Control2

ZWave+

Security V2

Quickstart

This is a
secure
Binary Switch DT
for
.

To run this device please connect it to your mains power supply.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.

This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

On/Off-Control 2 is designed to be installed in standard wall switch boxes or anywhere else where it's necessary to control electric devices.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Safety Warning for Mains Powered Devices

ATTENTION: only authorized technicians under consideration of the country-specific installation guidelines/norms may do works with mains power. Prior to the assembly of the product, the voltage network has to be switched off and ensured against re-switching.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number	Maximum Nodes	Description
1	0	
2	5	
3	5	

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a

parameter to 200â€”it may be needed to set a value of 200 minus 256 = minus 56.
In case of a two byte value the same logic applies: Values greater than 32768 may
needed to be given as negative values too.

Parameter 1: Restore state after power failure

This parameter determines if the device will return to the state prior to the power failure after power is restored.
Size: 1 Byte, Default Value: 1

Setting	Description
0	0

Parameter 154: First channel – auto off

This parameter allows to set the auto off time for the first channel. For the value 0 the functionality is disabled.
Size: 2 Byte, Default Value: 0

Setting	Description
0	0

Parameter 155: Second channel – auto off

This parameter allows to set the auto off time for the second channel. For the value 0 the functionality is disabled.
Size: 2 Byte, Default Value: 0

Setting	Description
0	0

Parameter 20: Switch type

This parameter defines as what type the device should treat switches connected to S1 and S2 terminals.
Size: 1 Byte, Default Value: 2

Setting	Description
0	0

Parameter 200: Voltage measurement

This parameter allows to set the value by which the mains voltage must change for the device to send the voltage measurement report. For the value 0 the functionality is disabled.
Size: 1 Byte, Default Value: 0

Setting	Description
0	0

Parameter 201: Voltage value for notification

This parameter allows to set the value that the mains voltage must exceed for the device to send the voltage notification report. For the value 0 the functionality is disabled.
Size: 2 Byte, Default Value: 0

Setting	Description
0	0

Parameter 202: Outputs mode

This parameters allows you to connect both channels and control them simultaneously.

Size: 1 Byte, Default Value: 0

Setting	Description
0	0

Parameter 24: Buttons orientation

This parameter enables changing inputs orientation without the need of changing electrical connections.

Size: 1 Byte, Default Value: 0

Setting	Description
0	0

Parameter 40: First button – scenes sent

This parameter determines which actions result in sending scene IDs assigned to them.

Size: 1 Byte, Default Value: 15

Setting	Description
0	0

Parameter 41: Second button – scenes sent

This parameter determines which actions result in sending scene IDs assigned to them.

Size: 1 Byte, Default Value: 15

Setting	Description
0	0

Technical Data

Hardware Platform	EFR32ZG23B
Device Type	Binary Switch DT
Network Operation	Always On End Node
Firmware Version	HW: 05 FW: 08.00
Z-Wave Version	7.22.2
Certification ID	ZC14-24110481
Z-Wave Product Id	0x010F.0x0205.0x1000
Security V2	S2_UNAUTHENTICATED ,S2_AUTHENTICATED
Frequency	XXfrequency
Maximum transmission power	XXantenna

Supported Command Classes

- Application Status
- Association Grp Info V3
- Association V2
- Basic V2
- Switch Binary V2
- Central Scene V3
- Configuration V4
- Device Reset Locally
- Firmware Update Md V5
- Indicator V3
- Manufacturer Specific V2
- Meter V5
- Multi Channel Association V3
- Multi Channel V4
- Notification V8
- Powerlevel
- Protection V2
- Security
- Security 2
- Supervision
- Transport Service V2
- Version V3
- Zwaveplus Info V2

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.
Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network.

Slaves can be sensors, actuators and even remote controls.

- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.