

**Olex
OS1 Black Box
Echosounder
Module**



Olex OS1 Black Box Echosounder Module Installation Guide

[Home](#) » [Olex](#) » Olex OS1 Black Box Echosounder Module Installation Guide 

Contents

- [1 Olex OS1 Black Box Echosounder Module](#)
- [2 Content of the package](#)
- [3 Connections scheme](#)
- [4 Product conformity information](#)
- [5 Safety Information](#)
- [6 Technical Specifications](#)
- [7 Warranty and warnings](#)
- [8 CONTACT](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

Olex

Olex OS1 Black Box Echosounder Module




Technical Specifications

- OS1 is a plug-and-play echosounder module to add fishfinder and echosounder capabilities to the Olex system.

Content of the package

- OS1 Echosounder, including:
 - Serial cable with female DB-9 connector, 3.0 m (10 feet)
 - Power cable with bare wires, 1.5 m (5.0 feet)
- Transducer adapter cable with BlackBox 8 pin Male connector & Bare Wires, 0.9 m (3 feet)
- Fuse holder with 5A fuse
- Installation Manual

Connections scheme



NOTE: Serial ground and transducer shield/negative are interconnected to the device ground.

Product conformity information

FCC compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes or modifications not expressly approved by AvMap Satellite Navigation Inc. could void the user's authority to operate the equipment.

Compliance information statement

Identification of the product	Name	P/N
	OS1	UX0BBF20OL
Applicable compliance statements	<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and</p> <p>(2) This device must accept any interference received, including interference that may cause undesired operation.</p>	
Responsible party	Name	AvMap Satellite Navigation Inc.
	Address	25 Enterprise Zone Drive, Riverhead, NY 11901 USA
	Phone	+1- 800-363-2627
	Website	www.avmap.us

EU declaration of conformity

- This device complies with Directive 2014/30/EU and Directive 2014/35/EU.
- The full text of the EU Declaration of conformity is available at the following internet address: declaration.map.it

Simplified UK declaration of conformity

- This device complies with the Electromagnetic Compatibility Regulations 2016 (SI 2016/1091) and Electrical Equipment (Safety) Regulations 2016 (SI 2016/1101).
- The full text of the UK Declaration of conformity is available at the following internet address: declaration.map.it

Safety Information

OLEX AS disclaims any liability deriving from an improper use or installation of the product in a way that may violate the regulations and safety. It is highly recommended that the installation of the product will be performed by a qualified maintenance technician. Consult the Installation manual for the correct installation procedure.

Technical Specifications

- Size: 196.4mm x 164.9mm x 50mm (7,73" x 6,49" x 1,9")

- Weight: 600 g
- Supply Voltage: 10-35 Vdc
- Transducer Frequency: CHIRP LF/MF/HF (40 to 210 kHz) | CW 50/200 kHz
- Transducer Power: From 300 W to 1 kW
- Compatible with Echonautics, Airmar, Radarsonics, and Simrad transducers.
- IPX6 Waterproof and shock-resistant housing
- Operating temperature: -20°C / +60°C (-4°F / +140°F)
- Storage Temperature: -40°C / +85°C (-40°F / +185°F)







NOTE: Check at www.olex.no for the latest Olex software version to be compatible with this device.

Warranty and warnings

Olex AS warrants every unit to be free from defects in material and workmanship under normal use and service for a period of 12 months from original retail purchase. During the warranty period, Olex AS will repair or replace any component which fails in normal use without charges for parts or labor. Technological developments, modifications and upgrades of software are not covered by warranty (except commercial decisions). To receive warranty service, contact your local authorized dealer for shipping instructions. The device should be securely packed with its tracking code clearly written on the outside of the package, shipping to be paid by the customer. Include a copy of the original sales receipt as the proof of purchase. This limited warranty does not extend to any device that has been subjected to misuse, neglect, accident, incorrect wiring or improper installation. Olex AS reserves the right to repair or replace the device at its sole discretion.

For more warranty information please see the web site: www.olex.no


For technical advice or assistance contact: olex@olex.no

	If water leaks into the equipment, immediately turn off the power at the switchboard. Fire or electrical shock can result.
	If the equipment is giving off smoke or fire, immediately turn off the power at the switchboard. Fire or electrical shock can result.
	Do not open the equipment. The equipment operates at high voltage which can cause electrical shock.
	Extensive exposure to heat may result in damage to the device.
	Please read the device manual before the first operation. If you have any questions, please contact customer service or your local dealer.
	<p>CAUTION: Risk of electric shock!</p> <p>Do not connect or disconnect peripheral instruments before completely powering down your navigation system. Failure to power down may result in electric shock and/or damage to your equipment, especially in the case of depth sounder and fish finder transducers, which employ powerful electrical impulses.</p>

CONTACT

- Olex AS
- Pirsenteret
- Havnegata 9
- N – 7010 Trondheim, Norway
- Phone: +47 73 54 61 99
- E-mail: olex@olex.no

Documents / Resources

	<p>Olex OS1 Black Box Echosounder Module [pdf] Installation Guide</p> <p>OS1 Black Box Echosounder Module, OS1, Black Box Echosounder Module, Echosounder Module</p>
---	--

References

- [A veudeclaration.avmap.it](https://www.aveudeclaration.avmap.it)
- [!\[\]\(fd4127b9e2af37bd6ea0fa06afa8e6d8_img.jpg\) AVMAP](#)
- [!\[\]\(3278d6283d12f18012b5aa7d40747611_img.jpg\) Olex hjemmeside](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.