

PDP Xbox Series Wired Controller User Manual

Home » PDP » PDP Xbox Series Wired Controller User Manual





Contents

- 1 Mute microphone
- 2 Control volume
- 3 Control balance
- **4 LIMITED WARRANTY**
- **5 Documents** /

Resources

Mute microphone

Press the function button twice to mute your microphone.



Control volume

While holding down the function button, press D-Pad Up/Down to adjust game volume.



Control balance

While holding down the function button, press D-Pad Left/Right to adjust game/chat balance.



Need Help?

Visit <u>support.pdp.com</u> or talk to us at (800) 331-3844 (USA and Canada only) or +442036957905 (UK only). <u>www.pdp.com</u>

4225 W Buckeye Rd #2, Phoenix, AZ 85009

104 Bld Sebastopol 75003, Paris France GPO Box 457 Brisbane,

QLD 4001, Australia US Patents/Brevets aux É.-U.: www.pdp.com/patents

This product is manufactured and imported by Performance Designed Products LLC. Designed in the U.S.A. by PDP. Made in China

© 2020 Performance Designed Products LLC. PDP, PDP Gaming, Level Up Your Game, and their respective logos are trademarks and/or registered trademarks of Performance Designed Products LLC. All rights reserved. Microsoft,

Xbox, Xbox "Sphere" Design, Xbox Series X|S, Xbox One, and Windows are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners. Please keep this information for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



LIMITED WARRANTY


Coverage and Term • PDP warrants that this product will be free from manufacturing defects for two years from the original date of purchase. Manufacturing defects are those defects in materials and/or workmanship, subject to final determination by PDP's customer service department. This warranty applies only to original purchasers with a valid proof of purchase from an authorized PDP retailer that clearly shows the date of purchase. Exclusive Remedy and Exclusions

- The exclusive remedy for valid claims will be the replacement, or refund of the product. This warranty does not cover defects caused by accidents, improper or abusive use of the product, unauthorized or improper modifications, repairs, or handling. How to Get Service
- Purchasers with product issues should not return the product to the store, but instead contact PDP's customer service department first. You can contact PDP customer service by phone at 1-800-331-3844 (US and Canada only), Monday to Friday from 8 AM to 6 PM PST. International customers can contact us by phone at +442036957905. You can always reach us, 24/7, by visiting support.pdp.com and clicking the "Submit a Request" button top right of the page to open a support ticket. Inquiries are typically answered within 24 business hours. Your Rights Under Applicable Law

- This warranty does not affect the legal rights of customers under applicable state, provincial, or national laws governing the sale of consumer goods.
 - Additional Information for Australian Consumers
- PDP products come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits given to you under our express warranty are in addition to other rights and remedies you have under the Australian Consumer Law and other laws.



Documents / Resources



Manuals+,