



# POLAR CT330-A Top Loading Bottle Cooler Instruction Manual

[Home](#) » [Polar](#) » POLAR CT330-A Top Loading Bottle Cooler Instruction Manual 

## Contents

- [1 CT330-A Top Loading Bottle Cooler](#)
- [2 Product Information](#)
- [3 Operation](#)
- [4 Safety Instructions](#)
- [5 Installation](#)
- [6 Operation](#)
- [7 Cleaning, Care & Maintenance](#)
- [8 Troubleshooting](#)
- [9 DECLARATION OF CONFORMITY](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)



## CT330-A Top Loading Bottle Cooler



## Product Information

The Top Loading Bottle Cooler is a product designed to keep bottles cool. It comes in three different models: CT330-A with a width of 935mm, CT331-A with a width of 1255mm, and CT332-A with a width of 1634mm. The product is packaged with all necessary components and is designed to be operated with a minimum clearance of 2.5cm between the unit and walls or other objects. The product has a control panel that allows you to set the operating temperature and manually defrost the unit. The appliance must be cleaned regularly for optimal performance.

## Product Usage Instructions

Before using the Top Loading Bottle Cooler, please read the instruction manual carefully. The correct maintenance and operation of the machine will provide the best possible performance from your POLAR product.

## Installation

1. Remove the appliance from the packaging and ensure all protective plastic film and coatings are removed from all surfaces.
2. Ensure a minimum clearance of 2.5cm is maintained between the unit and walls or other objects, with a minimum 5cm clearance on the top. NEVER LOCATE NEXT TO A HEAT SOURCE.
3. Level the appliance by adjusting the screw feet.
4. Clean the interior with soapy water before using the appliance for the first time.

## Operation

### To set the operating temperature:

1. Hold the SET button for 3 seconds. The value of the current set point will be displayed.
2. Press the or buttons to display the required temperature.
3. Press the SET button to store the temperature.

### To manually defrost the unit:

1. Press and hold the defrost button aux for 2 seconds to begin a manual defrost. The defrost light illuminates.

## Cleaning, Care & Maintenance

Switch off and disconnect from the power supply before cleaning.

Condensation will form in refrigeration on hot humid days, please ensure condensation is allowed to drain properly or is wiped dry.

Clean the condenser regularly for optimal performance.

## Troubleshooting

If your POLAR appliance develops a fault, please check the following table before making a call to the Helpline or your POLAR dealer. A POLAR agent or qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Mains power supply fault	Check mains power supply
The appliance turns on, but the temperature is too high/low	Too much ice on the evaporator or condenser blocked with dust or doors are not shut properly	Clean the condenser and ensure doors are shut properly

## Safety Instructions

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your POLAR product.

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - Fire Precautions
  - Wiring Regulations
  - Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use this appliance to store medical supplies.
- DO NOT stand or support yourself on the base, drawers or doors.
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- Bottles that contain a high percentage of alcohol must be sealed and placed vertically in the refrigerator.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- POLAR recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

## Caution:



Risk of Fire

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.  
**Warning:** Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.
- **Warning:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Warning:** Do not damage the refrigerant circuit.
- **Warning:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are the type recommended by the manufacturer.

## Product Description

- CT330-A – Polar Top loading Bottle cooler – 935mm Width
- CT331-A – Polar Top loading Bottle cooler – 1255mm Width
- CT332-A – Polar Top loading Bottle cooler – 1634mm Width

## Pack Contents

The following is included:

- POLAR Refrigerator
- Instruction Manual

POLAR prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your POLAR dealer immediately.


## Installation

**Note:** If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.

1. Remove the appliance from the packaging. Make sure that all protective plastic film and coatings are thoroughly removed from all surfaces.
2. To optimize performance and longevity, ensure a minimum clearance of 2.5cm is maintained between the unit and walls and other objects, with a minimum 5cm clearance on the top. NEVER LOCATE NEXT TO A HEAT SOURCE.
3. Level the appliance by adjusting the screw feet.

## Operation

### Control Panel



### Set the Operating Temperature

1. Hold the SET button for 3 seconds. The value of the current set point will be displayed.
2. Press the ▲ or ▼ buttons to display the required temperature.
3. Press the SET button to store the temperature.

### Manual Defrost

Press and hold the defrost button “aux” for 2 seconds to begin a manual defrost. The defrost light illuminates.

### Cleaning, Care & Maintenance

Switch off and disconnect from the power supply before cleaning.

- Clean the interior of the appliance as often as possible.
- Do not use abrasive cleaning agents. These can leave harmful residues.
- Clean the door seal with warm soapy water.
- Always wipe dry after cleaning.

Do not allow water used in cleaning to run through the drain hole into the evaporation pan.

Take care when cleaning the rear of the appliance. Sharp edges can cut.

**Note:** Condensation will form in refrigeration on hot humid days, please ensure condensation is allowed to drain properly or is wiped dry.

### Cleaning the Condenser

- Periodically cleaning the condenser can extend the life of the appliance.
- POLAR recommend that a POLAR agent or qualified technician clean the condenser.

### Troubleshooting

If your POLAR appliance develops a fault, please check the following table before making a call to the Helpline or your POLAR dealer. A POLAR agent or qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution
	The unit is not switched on	Check the unit is plugged in correctly and switched on

The appliance is not working	Plug or lead is damaged	Replace plug or lead
	Mains power supply fault	Check mains power supply
The appliance turns on, but the temperature is too high/low	Too much ice on the evaporator	Defrost the appliance
	Condenser blocked with dust	Call POLAR agent or qualified Technician
	Doors are not shut properly	Check doors are shut and seals are not damaged
	Appliance is located near a heat source or air flow to the condenser is being interrupted	Move the refrigerator to a more suitable location
	Ambient temperature is too high	Increase ventilation or move appliance to a cooler position
	Unsuitable foodstuffs are being stored in the appliance	Remove any excessive hot foodstuffs or blockages to the fan
	Appliance is overloaded	Reduce the amount of food stored in the appliance
The appliance is leaking water	The appliance is not properly levelled	Adjust the screw feet to level the appliance (if applicable)
	The discharge outlet is blocked	Clear the discharge outlet
	Movement of water to the drain is obstructed	Clear the floor of the appliance (if applicable)
	The water container is damaged	Call POLAR agent or qualified Technician
	The drip tray is overflowing	Empty the drip tray (if applicable)
The appliance is	Loose nut/screw	Check and tighten all nuts and screws

unusually loud	The appliance has not been installed in a level or stable position	Check installation position and change if necessary
----------------	--	---

## Technical Specifications

Model	Voltage	Power	Current	Temperature Range	Refrigerant	Dimensions H x W x D mm	Weight (kg)
CT330-A	220-240V~ 50Hz	160W	1.4A	2°C ~ 8°C	R600a 55g	888 x 935 x 687	52.5
CT331-A		250W	1.4A	2°C ~ 8°C	R600a 60g	888 x 1255 x 687	67
CT332-A		250W	1.4A	2°C ~ 8°C	R600a 60g	888 x 1634 x 687	78

## Electrical Wiring

The plug is to be connected to a suitable mains socket. This appliance is wired as follows:

- Live wire (colored brown) to terminal marked L
- Neutral wire (colored blue) to terminal marked N
- Earth wire (colored green/yellow) to terminal marked Ez



The appliances must be earthed.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority

responsible for waste disposal in your area. 

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of POLAR. Every effort is made to ensure all details are correct at the time of going to press, however, POLAR reserve the right to change specifications without notice.

## DECLARATION OF CONFORMITY

Equipment Type		Model
G-Series Top loading Bottle cooler – 935mm Width G-Series Top loading Bottle cooler – 1255mm Width G-Series Top loading Bottle cooler – 1634 mm Width		CT330 (& -E -A) CT331 (& -E -A) CT332 (& -E -A)
<b>Application of Territory Legislation</b>	<b>Machinery Directive 2006/42/EC</b>	<b>Electrical Safety</b>
<b>&amp; Council Directives(s)</b>	EN 60335-1:2012 +A11:2014 +A13:2017	IEC 60335-1:2010 +A1:2013 +A2:2015
Toepassings van Europese	EN 60335-2-89:2010 +A1:2016 +A2:2017	IEC 60335-2-89:2010 +A1:2012 +A2:2016
	EN 62233:2008	
directive(s)		
	<b>Electro-Magnetic Compatibility (EMC )</b>	<b>Electromagnetic Compatibility</b>
Direttive	<b>Directive 2014/30/EU – recast of 2004/108/EC</b>	EN 55014-1:2017
	EN 55014-1:2017	EN 55014-2:2015
	EN 55014-2:2015	EN 61000-3-2: 2014
Conselho	EN 61000-3-2: 2014	EN 61000-3-3: 2013
	EN 61000-3-3: 2013	
	Restriction of Hazardous Substances Directive	
	(RoHS) 2015/863 amending Annex II to	
	Directive 2011/65/EU	
<b>Producer Name</b>		<b>Polar</b>

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).


- **Date** : 3rd December 2020
- **Signature:** \_\_\_\_\_
- **Full Name** : Ashley Hooper
- **Position:** Technical & Quality Manager  
Commercial  
Manager/ Importer  
Commercial Manager/ Responsible Supplier
- **Producer Address:** Fourth Way,  
Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom



42 North Point Business Park New Mallow Road Cork Ireland  
15 Bagdally Road, Campbelltown NSW 2560



Documents / Resources

	<p><a href="#">POLAR CT330-A Top Loading Bottle Cooler</a> [pdf] Instruction Manual CT330-A Top Loading Bottle Cooler, CT330-A, Top Loading Bottle Cooler, Loading Bottle Cooler, Bottle Cooler</p>
---	---

References

- [P Polar Refrigeration - Commercial Refrigeration](#)