

POLARMETA
**X1 Multi-Function
Gesture Trackpad**



POLARMETA X1 Multi Function Gesture Trackpad Instruction Manual

[Home](#) » [POLARMETA](#) » POLARMETA X1 Multi Function Gesture Trackpad Instruction Manual 

Contents

- [1 POLARMETA X1 Multi Function Gesture Trackpad](#)
- [2 Product List](#)
- [3 MAC Trackpad Gesture Description](#)
- [4 FCC Warning](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

POLARMETA

POLARMETA X1 Multi Function Gesture Trackpad




Product List

1. Multi-Function Gesture Trackpad

2. Type-C Data Cable





3. USB Receiver



4. Adaptor (Type-C to USB)



5. User Manual



Welcome to Multi-function Gesture Trackpad


Multi-function gesture trackpad is equipped with USB2.4G receiver / type-c data cable. Please use USB receiver or data cable to connect your Computer.

System Version Requirement

- To use trackpad and its full functionality, please update your Mac to the latest version of mac OS (minimum OSX 10.11 required).
- To update to the latest version of mac OS, select Apple menu >'App Store' to check for updates – follow the instructions to update mac OS.

How to connect the trackpad to MAC.

To connect the trackpad to a Mac, use the included USB receiver to plug into the Mac (flip the switch to the left)/or plug the type-c cable into the trackpad's type-c port, and plug the other end into the Mac port. The green light flashes, indicating the trackpad is connecting to the Mac automatically .



Using Multi-Function Gesture Touchpad

Multi-Gesture trackpad has a Force Touch surface for moving mouse pointer and performing gestures. To set up gestures and set other options, select Apple Menu >

System Settings, then click “trackpad”. Place the Multi- Function Gesture Trackpad on a smooth, horizontal surface. When moving mouse pointer or performing a gesture, you can rest your hand comfortably on the trackpad and gently slide your finger across its surface.

MAC gesture setting steps:

1. Open “System Settings”
2. Click “Trackpad”
3. Click to set “Point & Click”
4. Click to set “Scroll & Zoom”
5. Click to set “More Gesture”

Steps to set “Drag & Drop”:

1. Open > “System Setting” > click “Accessibility”.
2. Click > “Pointer Control” > click “Trackpad Options” > turn on “Use trackpad for dragging”
3. Choose “Three Finger Drag”> Click “OK”.

Windows gesture setup steps

Windows system can be connected by a USB receiver and a data cable.

1. **USB receiver connection:** Please flip the switch to the right and plug the receiver into the computer.
2. **USB cable connection:** please flip the switch to the right and insert the usb cable to both sides.

After more than 10 minutes of standby, you need to press to wake up the trackpad.

MAC Trackpad Gesture Description

One Finger Operation



Open file

One-finger double-tap

Two Finger Operation



Flip the page

Slide up and down with two fingers



Switch page

Slide left and right with two fingers



Display notification center

Double finger slide from left edge



Zoom in

Two finger spread



Zoom out

Two-finger pinch



Smart Zoom

Two Finger Double Tap and rotate



Rotating pictures

Two finger rotate

Multi-Finger Operation



Select text

Three-finger slide



Drag the page

Three-finger tap



Show specific windows

Four-finger slide down



Open Dispatch Center

Four-finger slide up



Desktop switching

Four-finger left/right slide



Open the launchpad


Gather your fingers.




Show desktop

Spread your fingers outwards.

Windows trackpad gestures explained



Three- or four-finger gestures can be reset in the system by going to **System Settings > Devices > Trackpad**



Clean Multi-Function Gesture trackpad

Please use a non-pilling cloth to clean the outside of the trackpad. Do not use chemic reagent.

ergonomics

When using trackpad, find a comfortable sitting position, change your body posture from time to time, and take a break. It is very important.

More information

For more information, open “Mac Help” and search “Trackpad”. Please use a none-pilling cloth to clean the outside of the trackpad. Do not use chemic reagent.

ergonomics

When using trackpad, find a comfortable sitting position, change your body posture from time to time, and take a break. It is very important.

More information

For more information, open “Mac Help” and search “Trackpad”.

Product Warranty Card

Thank you for purchasing this product, in order to provide you with better service, please read the following content and keep this warranty card. If a non-human fault occurs during the daily use of the product, you can show this warranty card and a valid proof of purchase to the original dealer to apply for warranty service. However, the following are not included.

1. Damage caused by human factors, including failure caused by not operating in accordance with the manual, or due to poor storage of the product caused by impact, falling, bending and other damage (product surface has obvious wear marks, etc.).
2. Failure caused by private disassembly, repair and modification, or maintenance by non-special maintenance sites.
3. The user is unable to provide product warranty card and valid proof of purchase
4. Artificially altered purchase records or product information.
5. Beyond the product warranty period.

Product Model	User Name	Contact Number	Time of Purchase	Merchant Stamp
User Address				

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources



[POLARMETA X1 Multi Function Gesture Trackpad](#) [pdf] Instruction Manual
2BHNX-X1, 2BHNXX1, X1 Multi Function Gesture Trackpad, X1, Multi Function Gesture Trackpad, Gesture Trackpad, Trackpad

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.