



# Polk Audio React Soundbar with Dolby and DTS Virtua User Guide

[Home](#) » [Polk Audio](#) » Polk Audio React Soundbar with Dolby and DTS Virtua User Guide 

## Contents

- [1 Polk Audio React Soundbar with Dolby and DTS Virtua](#)
- [2 Product Information](#)
- [3 Connecting Your Subwoofer:](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)



## Polk Audio React Soundbar with Dolby and DTS Virtua




## Product Information

### Specifications:

- Product Name: React Sub Wireless Subwoofer
- Manufacturer: Polk Audio


- Model Number: [model number]
- Power Cable Length: [length]
- Wireless Range: Up to 30 ft (10m)

### What's in the Box:



### Positioning the Subwoofer:


1. Unpack the subwoofer and power cable.
2. Place the subwoofer along the same wall as the TV, no more than 30 ft (10m) from the sound bar.
3. Connect the power cord to the back of the subwoofer.
4. Connect the other end of the power cord into an AC power outlet.



### Connecting Your Subwoofer:


Note: Before connecting, make sure your sound bar is in pairing mode.

1. Press and hold the CONNECT button on the back of the sound bar for about four seconds.



2. Press and hold the CONNECT button on the back of the subwoofer for about four seconds.

3. Release the button when the light on the back of the subwoofer is solid green.



4. Press and release the CONNECT button on the back of the sound bar to complete pairing.

### I Do Not Hear Sound from My Subwoofer

- Check that the sound bar is powered on and playing audio.
- Turn up the bass using the provided Polk remote.
- Check that the power cable is secure in the back of the subwoofer and wall outlet.
- Check that a solid green light is visible on the back of the subwoofer.
- Unplug power from the subwoofer for 30 seconds and then plug back in.
- If the light on the back of the subwoofer is flashing green, you will need to reconnect the subwoofer to the sound bar using the instructions in “Connect Your Subwoofer”.

### Updating Your Subwoofer:

The subwoofer is automatically updated whenever your sound bar is connected to the Internet and receives an update. Refer to your sound bar’s Quick Start Guide and make sure your sound bar is properly connected to your home network. For more troubleshooting and information, please visit [polkaudio.com/support](http://polkaudio.com/support).


### Technical Assistance

- North America: 800-377-POLK (7655)
- United Kingdom and Ireland: +44 2890279830
- Netherlands: +31 402507800
- Other countries: +1-410-358-3600
- Email: [polkcs@polkaudio.com](mailto:polkcs@polkaudio.com)
- Polk FAQs: [polk.custhelp.com](http://polk.custhelp.com)

In all other countries, refer to [polk-eu@mailmw.custhelp.com](mailto:polk-eu@mailmw.custhelp.com) for support contact details

---

## Documents / Resources

	<a href="#">Polk Audio React Soundbar with Dolby and DTS Virtua</a> [pdf] User Guide React Soundbar with Dolby and DTS Virtua, React, Soundbar with Dolby and DTS Virtua, Dolby and DTS Virtua
---	---

## References

- [P Find Answers](#)
- [P Polk Audio® | Great Sound for All](#)
- [P Polk Audio® | Great Sound for All](#)
- [User Manual](#)

Manuals+.