

poly Blackwire 5200 Series Corded USB Headset with 3.5 mm Connection User Guide

Home » Poly » poly Blackwire 5200 Series Corded USB Headset with 3.5 mm Connection User Guide 🖺





Blackwire 5200 Series
Corded USB headset with 3.5 mm connection
User Guide

Contents

- 1 Overview
- 2 Setup
 - 2.1 Load software
- 3 Fit
 - 3.1 Position the boom
 - 3.2 Adjust the boom
- 4 Basics
 - 4.1 Make/take/end calls
 - 4.2 Volume
 - 4.3 Mute
- 5 Troubleshooting
 - 5.1 Headset
- 6 Support
- 7 Documents /
- Resources
- **8 Related Posts**


Overview




Icons	Inline control	LEDs	Function
•	Call button	Triple flash green	Incoming call
		Double flash green	Call on hold
		Solid green	On a call
+	Volume up button		Increases the listening volume
_	Volume down button		Decreases the listening volume
4	Mute button	Solid red	Headset is muted

Setup

Power on your headset by connecting to your computer or mobile device via USB or 3.5 mm connector.



IMPORTANT Ensure that your 3.5 mm connector is fully connected to the headset controller.



Load software

Customize your device behavior through advanced settings and options with Poly Lens Desktop App. Some softphones require the installation of Poly software to enable device call control (answer/end and mute) functionality. Download: poly.com/lens.

NOTE Device settings are also available in Plantronics Hub Desktop App.

Update your Poly device


Keep your firmware and software up-to-date to improve performance and add new features to your Poly device. Update your device using your computer with Poly Lens Desktop App. Download at poly.com/lens. While updating:

- Do not use your Poly device until the update is complete.
- Do not start a second update from a second device.
- · Do not stream media.
- Do not answer or place a call.

Fit

Adjust the headband


Lengthen or shorten the band until it fits comfortably. The cushions should sit comfortably over the center of your ears.



Position the boom

The headset can be worn with the boom on your left or right side. For true stereo listening, wear the boom on your left side.

Rotate the boom to align with your mouth.



Adjust the boom

Gently bend the boom in or out so it is approximately one finger width from the corner of your mouth.

Basics



Make/take/end calls

Headset call control is a software feature and dependent on a compatible softphone. If you have not installed Poly Lens Desktop App (poly.com/lens) or do not have a compatible softphone, press the headset call button first and then make/take/end the call using the softphone application.

Answer or end a call

Tap the Call button or use your softphone.

Make a call

Dial using your softphone application.

Redial

When not on an active call, double-tap the call button to redial the last call.

Hold

Double-tap the Call button to put a call on hold.

Volume

Listening volume

Press the Volume up (+) or Volume down (-) button.

Adjust headset microphone volume (softphone)

Place a test softphone call and adjust softphone volume and PC sound volume accordingly.

Mute

During a call, briefly press the mute button to mute the microphone on the inline controller. To unmute press the button again.

Troubleshooting

Headset

I hear a high-pitched noise when wea ring the headset.

• Ensure that your 3.5 mm connector is fully connected to the headset controller.

I cannot hear caller.	 Listening volume is too low. Press the volume up button on the head set. and/or ensure that the volume setting on your computer is set ac curately. Your headset is not set as the default audio device. Use the audio se ttings in your sound control panel/preferences to select your headset as the default audio device. Ensure that your 3.5 mm connector is fully connected to the headset controller. 	
Callers cannot hear me.	 Headset is muted. Tap the mute button to unmute the microphone. Headset microphone boom aligned incorrectly. Align the headset boom with your mouth. Your headset is not set as the default Voice device. Use the audio se ttings in your sound control panel/preferences to change the input de vice. Ensure that your 3.5 mm connector is fully connected to the headset controller. 	
The sound in the headset is distorted . I can hear an echo in the headset.	 Lower the listen volume on your softphone until the distortion disapp ears. Adjust volume on headset. Ensure that your 3.5 mm connector is fully connected to the headset controller. 	
When I use my headset with a softph one. the headset call control and mut e buttons don't work.	 Make sure the softphone you are using is supported by <u>viewingww</u> <u>w.plantronics.com/softphonecompatibility</u>. If required to enable headset control (answer/end and mute) function ality. ensure you have Poly Lens Desktop App installed. See Load so ftware. Your mobile device may not support call control functionality. Check with device manufacturer. 	
The other headset I was using to liste n to music does not work any more.	Your headset will set itself as the default audio device in Windows. U se the audio settings in your sound control panel/ preferences to change the audio device.	

My phone is not finding my headset d uring a call or while listening to music

When on a call or listening to music. make sure that audio is routing t
 o the desired headset by going to your settings and ensuring it is def
 aulted.

Support

NEED MORE HELP?

poly.com/support

Plantronics, Inc. 345 Encinal Street Santa Cruz, CA 95060 United States Plantronics B.V. Scorpius 171 2132 LR Hoofddorp Netherlands

© 2021 Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.

209253-06 06.21



Documents / Resources



poly Blackwire 5200 Series Corded USB Headset with 3.5 mm Connection [pdf] User Guid

Blackwire 5200 Series, Corded USB Headset with 3.5 mm Connection

Manuals+