




# PREWorks DSWG512 DMX-Interface Lighting Controller Owner's Manual

[Home](#) » [PREWorks](#) » PREWorks DSWG512 DMX-Interface Lighting Controller Owner's Manual 

**PREWorks**

...SOWAS VON LICHT!  
DSWG512 DMX-Interface Lighting Controller  
Owner's Manual



# Contents

- 1 FEATURES
- 2 OPERATING INSTRUCTIONS
- 3 Documents / Resources
  - 3.1 References
- 4 Related Posts

- 1 FEATURES
- 2 OPERATING INSTRUCTIONS
- 3 Documents / Resources
  - 3.1 References
- 4 Related Posts

## FEATURES



**CE-label according to:**

2006/95/EC: EN 50178  
2004/108/EC: EN 61000-6-1  
EN 61000-6-3


- Auto address allocation
- internal resolution: 16 Bit [65.536 steps]
- Emergency light function [in case of missing DMX signal]
- Support for instant ON/OFF [flash/blackout]
- Upscaling enables to use low-cost Light-Mixing Tools for professional applications
- Customer specific upgrade options due to firmware update capabilities on request

**Protocol:** DMX-512-A

Supply-Voltage: 12V

Max. Current: 25mA

insulation strength DMX Input: 500V



## OPERATING INSTRUCTIONS

- PRE Works**  
...SOWAS VON LICHT!  
Preworks GmbH  
Technologiepark 4/1, 8510 Stainz, Austria  
+43 3463 82317, [office@preworks.at](mailto:office@preworks.at), [www.preworks.at](http://www.preworks.at)

-  Home DE - Preworks