











Q Q YP10472 Multi Function Sport LCD Watch User Guide

[Home](#) » [Q Q](#) » Q Q YP10472 Multi Function Sport LCD Watch User Guide 

USER'S GUIDE
YP10472(MULTIFUNCTION SPORT LCD WATCH)

	EL Backlight		Stopwatch
	Dual Time		Alarm
	100 Years Calendar		Chime
	100M Water Resistant		Battery(CR2025)

ATTENTION


1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer.
4. Otherwise, it can cause erosion of the metal parts of the watch.
5. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
6. Avoid exposing the watch to temperature extremes.
7. Wipe the watch with a dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
8. Avoid wearing the watch in electromagnetic, static conditions.

Contents

- [1 BUTTONS](#)
- [2 DISPLAY](#)
- [3 MODE SELECTION](#)
- [4 BACKLIGHT](#)
- [5 \(a\) TIMEKEEPING](#)
- [6 \(b\) ALARM](#)
- [7 \(c\) STOPWATCH](#)
- [8 \(d\) DUAL TIME](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)

BUTTONS


- The operation of buttons is indicated by using the letters shown in the illustration.



- A — Reset
- B — Mode
- C — EL backlight
- D — Start / Stop

DISPLAY

- The screen is shown below:



MODE SELECTION

- Press "B" to change mode to mode in the following Sequence:
Timekeeping Mode→Alarm Mode→Stopwatch Mode→Dual Time Mode.

(a) TIMEKEEPING



- 12/24H Format;
- Hour, Minutes, Seconds, Day of Week, Date;
- 100 years Calendar (2000 – 2099).

(b) ALARM



- Hourly time signal;
- The alarm sounds at the preset time each day.

(c) STOPWATCH



- 1/100 second unit;
- Measuring range: 0100"00 – 23:59'59".

(d) DUAL TIME



- The time for another time zone.

BACKLIGHT

- The backlight that uses an EL (electro-luminescent) causes the display to glow for easy reading in the dark.

Use EL Backlight



- In any mode, press "C" to illuminate the display for about 3 seconds.

(a) TIMEKEEPING



12/24H Format

- In the timekeeping mode, press “A” to switch between 12/24H formats.

Calendar



- In the timekeeping mode, press and hold “D” to display: Year, Month, Date.

Time Setting

1. In the timekeeping mode, press and hold “A” until the seconds to flash (flashing indicated in set mode);



2. Press “D” to reset the seconds ;



3. Press “B” change to the next selection;



4. Press “D” to increase the number, press and hold to increase at high speed;
5. Repeat steps 3 and 4, the selection in the following sequence: Seconds – Hour – Minutes-Year – Month – Date;



6. Press “A” to exit the set state after you set(The day of the week is automatically displayed in accordance with the year, month, and date setting).

(b) ALARM

Alarm and Chime



- In the alarm mode, press “D” to on/off the alarm and chime in the following sequences:
 Alarm & Chime off —
 Alarm on —
 Chime on—
 Alarm & Chime on.

Alarm Time Setting

1. In the alarm mode, press “A” the hour flashes, the indicator " " appear(flashing indicated in set mode);



2. Press “D” to increase the hour, press and hold to increase at high speed;



3. Press “B” to select the minutes;



4. Press “D” to increase the minutes, press and hold to increase at high speed;



5. Press “A” to exit the set state, after you set.

* The alarm sounds at the preset time each day for about 60 seconds, press any button to break it.

(c) STOPWATCH

A Lap Time





1. In the stopwatch mode, press "D" to start the stopwatch;



2. To stop the stopwatch by pressing "D" again;



3. Press "A" to reset the stopwatch.

Split Time



1. In the stopwatch mode, press "D" to start the stopwatch;
2. Press "A" to display the split time, stopwatch timing continues internally;



3. Press "A" to clear the split time and to continue time measurement; 4
4. Repeat steps 2 and 3, you can measure the multi-split time;



5. Press "D" to stop the stopwatch.

(d) DUAL TIME

Dual Time Setting

1. In the dual time mode, press "A" the hour to flash (flashing indicated in set mode);



2. Press "ID" to increase the hour, press and hold to increase at high speed;



3. Press “B” to select the minutes;



4. Press “ID” to change the minutes (press once to change 30 minutes);




5. Press “A” to exit the set state, dicer you set.

**UK
CA**

CE





[Q Q YP10472 Multi Function Sport LCD Watch](#) [pdf] User Guide

YP10472, Multi Function Sport LCD Watch, YP10472 Multi Function Sport LCD Watch