

  
SL103 RAK WisNode  
Sensor Hub Modular



# RAKwireless SL103 RAK WisNode Sensor Hub Modular Instruction Manual


[Home](#) » [RAKwireless](#) » RAKwireless SL103 RAK WisNode Sensor Hub Modular Instruction Manual 

## Contents

- 1 RAKwireless SL103 RAK WisNode Sensor Hub Modular
- 2 Specifications
- 3 Product Features
- 4 Device Detail
  - 4.1 Turn On/Off:
- 5 Instructions
- 6 Uplink data format
- 7 Basic sensor data definition
  - 7.1 Details of customized type sensor
- 8 Feature test
- 9 Document version
- 10 FCC statements
- 11 FAQ:
- 12 Documents / Resources
  - 12.1 References



**RAKwireless SL103 RAK WisNode Sensor Hub Modular**



## Specifications

- **Sensor Type:** DS18B20\*3
- **Model No.:** SL103-LF-LED-A0 (CN433/CN479) / SL103-HF-LED-A0 (EU868/US915/AU915/AS923/IN865)
- **CPU:** Cortex-M
- **Wireless Encryption:** SX1268/SX1262 AES128
- **Power:** 120 mA (Peak current), 35 uA (Sleeping current)
- **Working Temperature:** -40°C to 85°C
- **Measuring Range:** -40°C to 125°C
- **Data Speed:** 300 bps to 62.5 kbps
- **Size:** 103mm x 60mm x 27mm
- **TX Power:** 22dBm Max
- **RX Sensitivity:** -140 dBm BW=125K SF=12
- **Working Frequency:** 433-510 MHz / 863-928 MHz

## General Information

SL103 (LoRa version) is a 3-way DS18B20 temperature sensor that uses LoRa spread spectrum wireless communication, supports standard LoRaWAN wireless protocol, and has built-in global regional specifications (such as CN470, CN479, EU433, EU868, US915, AU915, AS923, IN865, etc.). Users can adapt to various LoRaWAN standards in different regions by simply configuring and selecting different regional specifications when using the LoRaWAN mode.

Sensor Type	Model No.	Document
DS18B20*3	SL103-LF-LED-A0 (CN433/CN479) SL103-HF-LED-A0 (EU868/US915/AU915/AS923/IN865)	

## Note

- **LF:**
  - Frequency 433~510 MHz
- **HF:**
  - **Frequency** 863~928 MHz

## Product Features

SL103 supports both LoRa and LoRaWAN, all parameters are open for configuration, easily compatible with allLoRa applications. There is a USB Type-C (USB-C) interface next to the battery for configuring and firmware updating. By default, 2replaceable AA batteries are used, which is convenient to use and easy to deploy. It can be used in low-powerwide area IoT scenarios such as warehouses, computer rooms, smart buildings, and greenhouses. or SensorTool for configuration. In addition, the product supports serial port firmware upgrade for easymaintenance and functional expansion.


## Parameters

Parameters	Feature
CPU	Cortex-M
Wireless	SX1268/SX1262
Encription	AES128
Power	AA*2
Peak current	120 mA
Sleeping current	35 uA
Working temp	-40 ~ 85 °C ≤95%RH

	Parameters	Feature	
	Measuring range	-40 ~ 125 °C	
	Data speed	300 bps ~ 62.5 kbps	
	Size	103mm*60mm*27mm	
	TX power	22dBm Max	
	RX sensitivity	-140 dBm BW=125K SF=12	
	Working frequency	433-510 MHz 863~928 MHz	

Parameters	Feature
CPU	Cortex-M
Wireless	SX1268/SX1262
Encrption	AES128
Power	AA*2
Peak current	120 mA
Sleeping current	35 uA
Working temp	-40 ~ 85 °C ≤95%RH
Measuring range	-40 ~ 125 °C
Data speed	300 bps ~ 62.5 kbps
Size	103mm*60mm*27mm
TX power	22dBm Max
RX sensitivity	-140 dBm BW=125K SF=12
Working frequency	433-510 MHz 863~928 MHz

## Size



## Device Detail

### Interfaces:

#### 1. Indicator

When there is USB-C plug in, indicator is red. Sensor data indicator, indicator is green when data sending.



#### 2. Turn on/off indicator

The button is on the left side of the device. Automatically turn on the device when powered on. After the system is running, you can use this button to turn off or restart it.



#### 3. Data button on the right

The button on the right side is for sending data.

#### 4. Battery compartment

The back cover can be opened to replace the battery. The warehouse provides a USB connection port for users to modify more parameters and upgrade firmware.

### Turn On/Off:

**Turn On:** The factory equipment is turned on by default, and can be pressed and held for 3 seconds to turn off, and indicator will turn off one by one.

**Turn Off:** When the device is turned off, press the button for 3 seconds to turn on the device.

**Note:** The device will be automatically turned on when powered on again.

## Instructions

The USB port is located in the battery compartment, and the device is equipped with a USB to serial port chip. Users can modify the device's parameters through the SensorTool serial port configuration tool on the computer by using a standard USB Type-C data cable. The steps are as follows:

1. Insert the USB-C cable and connect to the computer. Note that the serial port driver needs to be installed in advance, and the serial port to USB chip is CH340.
2. Open the SensorTool, use the default baud rate of 115200, select the COM port corresponding to the device through "Serial Port Selection", and click "Open Serial Port" to automatically read the device parameters. Wait for the reading to complete before viewing or modifying parameters.
3. The configuration interface is shown below. After modifying the parameters, click the "Update Configuration" button to set the parameters.

设备类型: Linux 温度&湿度 SL103A, 2, 1005

数据格式: AppEUI: CACBB8000000001

DevEUI: CACBB8033000061A DevAddr: 3000061A

上报周期: 600

按钮: 读配置, 更新配置, 重启设备, 恢复出厂设置

### Configuration instruction

To adapt to different business scenarios, the device supports parameter modification using USB and button modes. For users, the main modification is data Uplink period.

### Uplink period

The unit of this parameter is seconds, and sensor data is collected and reported when the set time expires. The default data uplink period of the system is 600 seconds (i.e. 10 minutes, equivalent to heartbeat transmission). In a constant environment, data is reported every 10 minutes. This parameter can be adjusted according to the actual situation.

### Firmware update

Use the Sensor Tool to upgrade the firmware of the device. Please refer to the Sensor Tool documentation for specific details. The main steps are shown in numerical order: determine the firmware type, select the firmware file (.bin), and then select the device to be updated in the device list. Click the "Update System" button to upgrade the firmware.

固件更新: LoRa 传感器

清除列表 固件类型: 设备固件 包大小: 256 打开文件 更新系统

序号	地址	版本	包大小	包个数	下一包号	时间	数据
1	CACBB803300001E	0	0	0	0	14:28:20 2023/07/31	

### Wireless data format

In order to support various business models and application scenarios, the terminal can be configured as a nonLoRaWAN or LoRaWAN mode.

### Non-LoRaWAN

Header	DevAddr	FCtrl	SeqNo	Sensor Data 1	...	Sensor Data N	CRC
1 byte	4 bytes	1 byte	2 bytes	Data 1	...	Data N	2 bytes
Protocol header	Device address	Control word	Package number	TLV (refer to specific Type)		TLV (refer to specific Type)	CRC16=Header to Sensor DataN (i.e. all bytes before CRC)

## LoRaWAN

In order to save transmission bytes, duplicate or redundant data items are not reported in LoRaWAN mode, and only sensor data content is uploaded. As shown below, FRMPayload refers to sensor data in non LoRaWAN mode.

MHDR	FHDR	FPort	FRMPayload (SensorData)			MIC
			Data 1	...	Data N	
			TLV (Refer to specific types of SensorData)		TLV (Refer to specific types of SensorData)	

- **FPort 1**
- **FRMPayload** e.g sensor data(message body)

## Uplink data format

### Data type notification

Type	Notification
0x00~0x0F and 0xFF	formats (T+V), basic sensor type, fixed data format, omitting length bytes
0x10~0x1F	Format (T+L+V), universal type, reserved length to meet customized requirements
0x20~0x3F	Format (T+L+V), customized project needs, different projects adapt to different content
0x80~Undefined	Format (T+L+V), user parameter configuration and query, different projects adapt to different content

## Basic sensor type list

Type	Value	Value discription
Universal response 0xFF	2 bytes	The first byte corresponds to the downstream instruction (the answered command)  The second byte corresponds to the result
Device information 0x00	2 bytes	Device information package content is known, so ignoring the length field saves bytes

### Customized type list

Type 1 Byte	Length 1 Byte	Value	Value discription
Multi temp 0x14	N*2	N*2 Byte Content	N sensor temp

### Basic sensor data definition

#### Device infor 0x00

Type	Value	Value	Value
1 Byte	3 bit	5bit	1 Byte
0x00	Version	Voltage Level	Reserve

### Details of customized type sensor

#### Multi temp 0x14

Adapt N-way temperature according to length, and if N is 1, the basic temperature type 0x04 can be directly used. If N>1 channel temperature needs to be transmitted, merge similar data items in the following order.

Type	Length	Value	Value	Value
1 Byte	1 Byte	int16_t	...	int16_t
0x14	2*N	No. 1 temp	...	No. 2 temp

For example, if there are three temperature measuring probes, the type N mentioned above is 3, and the single temperature length (int16\_t) is 2 bytes.

### Query Configuration Type

Read user parameters in related projects, such as period, calibration values, variable settings, etc. Values are listed in order, using Length for adaptive wireless query configuration. If Length is 4, it means that only the reporting and testing cycles are included later. If Length is 8, it means it includes reporting and testing cycles as well as calibration values. Read user parameters in related projects, such as period, calibration value, and change setting. | Type | Length | Value | Value | Value | Value | Value | Value |



: — : | : — : | : — : | : — : | : — : | : — : | : — : |

| 1 Byte | 1 Byte | uint16\_t | uint16\_t | int32\_t | uint8\_t | uint8\_t | uint8\_t | | 0x81 | Value length | Uplink period |  
Check period | Calibration | Chnage 1 | Change 2 | Change 3 |

### Sensor upload example

The device defaults to running in non LoRaWAN mode, including the complete content of prefix parts such as protocol header, device address, and CRC suffix parts. As shown below, the sensor data section mainly includes device information (0x00) and multi-channel temperature (0x14). In LoRaWAN mode, the data only has FRMPayload, which is the sensor data section. Report content of types 0x00 and 0x14 by default.

Header	DevAddr	FCtrl	SeqNo	传感器数据(消息体)			CRC
1 字节	4 字节	1 字节	2 字节	数据 1	...	数据 N	2 字节
协议头	设备地址	控制字	包序号	Type+Data N Bytes	Type+Data N Bytes	Type+Data N Bytes	CRC16= 首字节至 Body

### Sensor downlink data format

The downlink is sent to the gateway by external or platform, and is executed through the gateway. The format of the data message sent to the terminal as a whole is consistent with the data format reported by the terminal.

### Sensor downlink type list

Currently, the downlink content of the device is only applicable in LoRaWAN mode. The supported instructions include reading user configuration parameters, change periods, and variables.

### Detailed format of read instructions

Type 1 Byte	Value	Value discription
0x01	0x81 Read user configuration	Read period and related calibration settings, please refer to the uplink f or return information

### Write instruction detailed format

Type 1 Byte	Value 1 Byte	Value N Byte	Notification
0x02	0x11 Uplink period	uint16_t	e.g LFT unit is second

### Message tail CRC16

The CRC verification algorithm used by the device is as follows.

**static uint16\_t get\_crc16 ( uint16\_t inData, uint16\_t outData )**

- outData = ( outData >> 8 ) | ( outData << 8 );
- outData ^= inData ;
- outData ^= ( outData & 0xff ) >> 4 ;
- outData ^= outData << 12 ;
- outData ^= ( outData & 0xff ) << 5 ;
- return outData ;} .

**static uint16\_t cal\_crc16 ( const uint8\_t \* pData, const uint32\_t len )**


- { uint32\_t l = 0
- ; uint16\_t crc16 = 0xFFFF ;
- for ( l = 0 ; l < len ; ++)
  - { crc16 = get\_crc16 (\*( pData ++), crc16 );}
- return crc16;}

## Feature test

### Sensitivity test

SF	Sensitivity dBm @BW=125K, 470MHz
SF=7	-126
SF=8	-129
SF=9	-131
SF=10	-134
SF=11	-136
SF=12	-139

### TX power test



## Document version

Edit date	version	notification
2023.08	V1.0	First version
2023.10	V1.1	modify 4.2.1 and 4.2.2 indicator discription

This device complies with Part 15 of the FCC Rules.

### Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

## FCC statements

This device complies with part 15 of the FCC rules.

### Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

**If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Federal Communication Commission (FCC) Radiation Exposure Statement


When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.

## FAQ:

### Q: How do I switch between different regional specifications for LoRaWAN mode?

A: Users can adapt to various LoRaWAN standards in different regions by configuring and selecting different regional specifications using the device settings.

## Documents / Resources

	<a href="#">RAKwireless SL103 RAK WisNode Sensor Hub Modular</a> [pdf] Instruction Manual SL103-LF-LED-A0, SL103-HF-LED-A0, SL103 RAK WisNode Sensor Hub Modular, SL103, RAK WisNode Sensor Hub Modular, WisNode Sensor Hub Modular, Sensor Hub Modular, Hub Modular, Modular
---	--

## References

-  [bw \(Brandon Wang\) · GitHub](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.