



Rapsodo Mobile Launch Monitor App User Guide

[Home](#) » [Rapsodo](#) » Rapsodo Mobile Launch Monitor App User Guide 



**MOBILE LAUNCH MONITOR
QUICKSTART GUIDE**

www.rapsodo.com


support@rapsodo.com

Contents

- [1 CHARGE MLM UNIT](#)
- [2 DOWNLOAD THE RAPSODO GOLF APP](#)
- [3 OPEN THE APP TO START USING MLM UNIT](#)
- [4 CALIBRATE FRONT PHONE CAMERA](#)
- [5 UNIT PLACEMENT](#)
 - [5.1 FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT](#)
- [6 LED GUIDE](#)
- [7 STATS](#)
- [8 SHOT SHAPE](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)


CHARGE MLM UNIT

Allow approximately 3 hours for a full charge, your charging time may be longer depending on your USB charger.



DOWNLOAD THE RAPSODO GOLF APP

Go to Apple App Store and Search for Rapsodo



OPEN THE APP TO START USING MLM UNIT

1. Turn charged MLM Unit on
2. Click Play and Follow the Steps to Connect to MLM and start using the MLM

CALIBRATE FRONT PHONE CAMERA

Hold the unit approx. 4 inches from the screen, and move the unit until all red lines change to green. Setup needed only once per phone. If you use a new phone, you will need to calibrate your phone.



UNIT PLACEMENT

Place the unit on a level surface approximately 8 feet behind where the ball will be hit. Ensure you are visible on the screen.



FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.








FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator & your body.

Note: The country code selection is for non-US models only and is not available to all US models. Per FCC regulation, all WiFi products marketed in the US must be fixed to US operation channels only.

www.rapsodo.com
support@rapsodo.com

LED GUIDE

      	RED The unit is waiting to connect to the app.
	BLINKING RED Low Battery
	AMBER Unit Charging
	GREEN Ready for a shot to be taken
	BLINKING GREEN Club recognition in progress
	BLUE Processing Shot
	BLINKING WHITE Firmware Upgrading

STATS

Carry

Total distance traveled from impact to landing. MLM estimates this based on your initial launch conditions, a level surface is assumed.

Ball Speed

Exit speed of the ball immediately after impact

Club Head Speed

Speed of your club moments before impact

Smash Factor

Ball Speed is divided by club speed. The higher your smash factor, the more efficiently you transfer energy from club to ball.


Launch Angle

The angle is of your ball relative to the ground. Combined with ball speed, will be the main components to determine shot distance.

Launch Direction


Measure how far from the ideal line your shot lands. The Center of your camera is assumed to be zero degrees.

SHOT SHAPE



ID: Left Draw	D: Draw	RD: Right Draw
L: Left	ST: Straight	R: Right
LF: Left Fade	F: Fade	RF: Right Fade

Documents / Resources

	Rapsodo Rapsodo Mobile Launch Monitor App [pdf] User Guide MLM11, 2AH3O-MLM11, 2AH3OMLM11, Rapsodo Mobile Launch Monitor, App, Rapsodo Mobile Launch Monitor App
---	---